
GARDNER DENVER[®]

13-10-613
3rd Edition
January, 1998

ELECTRA-SAVER[®]
STATIONARY BASE-MOUNTED
COMPRESSORS

AUTO SENTRY[®]-ES+ CONTROLS

AUTO SENTRY[®]-ES CONTROLS

MODEL

EAY

OPERATING AND
SERVICE MANUAL

Gardner

Denver

MAINTAIN COMPRESSOR RELIABILITY AND PERFORMANCE WITH GENUINE GARDNER DENVER COMPRESSOR PARTS AND SUPPORT SERVICES

Gardner Denver Compressor genuine parts, engineered to original tolerances, are designed for optimum dependability — specifically for Gardner Denver compressor systems. Design and material innovations are the result of years of experience with hundreds of different compressor applications. Reliability in materials and quality assurance are incorporated in our genuine replacement parts.

Your authorized Gardner Denver Compressor distributor offers all the backup you'll need. A worldwide network of authorized distributors provides the finest product support in the air compressor industry. Your local authorized distributor maintains a large inventory of genuine parts and he is backed up for emergency parts by direct access to the Gardner Denver Machinery Inc. Master Distribution Center (MDC) in Memphis, Tennessee.

Your authorized distributor can support your Gardner

Denver air compressor with these services:

1. Trained parts specialists to assist you in selecting the correct replacement parts.
2. Factory warranted new and remanufactured rotary screw air ends. Most popular model remanufactured air ends are maintained in stock at MDC for purchase on an exchange basis with liberal core credit available for the replacement unit.
3. A full line of factory tested AEON™ compressor lubricants specifically formulated for use in Gardner Denver compressors.
4. Repair and maintenance kits designed with the necessary parts to simplify servicing your compressor.

Authorized distributor service technicians are factory-trained and skilled in compressor maintenance and repair. They are ready to respond and assist you by providing fast, expert maintenance and repair services.

For the location of your local authorized Gardner Denver Air Compressor distributor refer to the yellow pages of your phone directory or contact:

Distribution Center:
Gardner Denver Machinery Inc.
Master Distribution Center
5585 East Shelby Drive
Memphis, TN 38141
Phone: (901) 542-6100
(800) 245-4946
Fax: (901) 542-6159

Factory:
Gardner Denver Machinery Inc.
1800 Gardner Expressway
Quincy, IL 62301
Phone: (217) 222-5400
Fax: (217) 224-7814

REMANUFACTURED AIR ENDS

Whenever an air end requires replacement or repair, Gardner Denver offers an industry unique, factory remanufactured air end exchange program. From its modern Remanufacturing Center in Indianapolis, IN, Gardner Denver is committed to supplying you with the highest quality, factory remanufactured air ends that are guaranteed to save you time, aggravation and money.

Immediately Available

Repair downtime costs you money, which is why there are over 200 remanufactured units in inventory at all times, ready for immediate delivery.

Skilled Craftsmen

Our Remanufacturing assembly technicians average over 20 years experience with air compression products.

Precision Remanufacturing

All potentially usable parts are thoroughly cleaned, inspected and analyzed. Only those parts that can be brought back to original factory specifications are remanufactured. Every remanufactured air end receives

a new overhaul kit: bearings, gears, seals, sleeves and gaskets.

Extensive Testing

Gardner Denver performs testing that repair houses just don't do. Magnaflux and ultrasonic inspection spot cracked or stressed castings, monochromatic light analysis exposes oil leaks, and coordinate measurement machine inspects to $\pm .0001$ ", insuring that all remanufactured air ends meet factory performance specifications.

Warranty

Gardner Denver backs up every remanufactured air end with a new warranty . . . 18 months from purchase, 12 months from service.

Gardner Denver remanufactured air ends deliver *quality without question . . . year in and year out.*

Call Gardner Denver for information on the air end exchange program and the name of your authorized distributor.

Phone Number: 800-245-4946 or
FAX: 901-542-6159

FOREWORD

Gardner Denver Rotary Screw compressors are the result of advanced engineering and skilled manufacturing. To be assured of receiving maximum service from this machine the owner must exercise care in its operation and maintenance. This book is written to give the operator and maintenance department essential information for day-to-day operation, maintenance and adjustment. Careful adherence to these instructions will result in economical operation and minimum downtime.



DANGER

Danger is used to indicate the presence of a hazard which will cause severe personal injury, death, or substantial property damage if the warning is ignored.



WARNING

Warning is used to indicate the presence of a hazard which can cause severe personal injury, death, or substantial property damage if the warning is ignored.



CAUTION

Caution is used to indicate the presence of a hazard which will or can cause minor personal injury or property damage if the warning is ignored.

NOTICE

Notice is used to notify people of installation, operation or maintenance information which is important but not hazard-related.

This book covers the following models:

HP	PSIG	Air Cooled	Water Cooled	Parts List	Controller Manual
350	100, 125, 150 International	EAYQSE EAYQSE	EAYSSE EAYSSE	13-10-510 13-10-514X	13-9/10-647 13-9/10-647
400	100, 125, 150 International	EAYQTE EAYQTE	EAYSTE EAYSTE	13-10-510 13-10-514X	13-9/10-647 13-9/10-647
500	100, 125, 150 International	EAYQVE EAYQVE	EAYSVE EAYSVE	13-10-510 13-10-514X	13-9/10-647 13-9/10-647

TABLE OF CONTENTS

Maintain Compressor Reliability and Performance With Genuine Gardner Denver Compressor Parts and Support Services	i
Remanufactured Air Ends	i
Foreword	ii
Index	iv
List of Illustrations	vii
Section 1, General Information	1
Section 2, Installation	8
Section 3, Starting & Operating Procedures	16
Section 4, Controls & Instrumentation	18
Section 5, Lubrication, Oil Cooler, Oil Filter & Separator	28
Section 6, Air Filter	39
Section 7, Coupling	41
Section 8, Maintenance Schedule	42
Section 9, Trouble Shooting	43
Warranty	Last Page

INSTRUCTIONS FOR ORDERING REPAIR PARTS

When ordering parts, specify Compressor MODEL, Method of Cooling, HORSEPOWER and SERIAL NUMBER (see nameplate on unit). The Serial Number is also stamped on top of the cylinder flange to the right of the inlet housing.

All orders for Parts should be placed with the nearest authorized distributor.

Where NOT specified, quantity of parts required per compressor or unit is one (1); where more than one is

required per unit, quantity is indicated in parenthesis. SPECIFY EXACTLY THE NUMBER OF PARTS REQUIRED.

DO NOT ORDER BY SETS OR GROUPS.

To determine the Right Hand and Left Hand side of a compressor, stand at the motor end and look toward the compressor. Right Hand and Left Hand are indicated in parenthesis following the part name, i.e. (RH) & (LH), when appropriate.

INDEX

Actuator, Turn Valve	21	Alignment	41
Addition of Oil Between Changes	30	Daily Check	17
Aftercooler	11	Decals	6, 7
AIR FILTER, SECTION 6	39	Discharge Service Line	13
Air Filter	39	Discharge Thermistor	22
Air Filter Element Life	39, 40	Drain, Oil Reservoir	9
Air Filter Vacuum Switch	22	Draining and Cleaning Oil System	31
Air Filter, Dust Cap	40	Dust Cap	40
Air Filter, Heavy-Duty – 350 & 400 HP Units ..	39		
Air Flow in the Compressor System	1	Electric Motor Grease Recommendations	15
Air Receiver, Auxiliary	11	Electric Motor Regreasing Interval	15
Air-Cooled Oil Cooler Module	9	Electrical Wiring	14
Auto Sentry Operation	18	Starter	14
		Element Life, Air Filter	39, 40
Blowdown Valve	19	Emergency Stop Push-Button	22
		Enclosure	9
Change Procedure, Lubricant	29		
Check, Daily	17	Fan Starter	23
Cleaning and Draining Oil System	31	Filling Oil Reservoir	32
Cold Ambient Operation	30	Filter, Compressor Oil	32
Cold Weather Operation	12	Filter Element	39, 40
Cold Weather Operation, Installation for	12	Filter, Air (Standard)	39
Compression Principle	1	Foreword	ii
Compressor	1	Foundation	9
Compressor Capacity Control – Turn Valve Units Only	23		
Compressor Oil Cooler	33	Gauge, Oil Level	19, 30
Compressor Oil Filter	32	GENERAL INFORMATION, SECTION 1	1
Compressor Oil Separator	36	Grease Recommendations, Electric Motor	15
Compressor Oil System	28	Grounding	15
Compressor Oil System Check	38		
Control Devices	18	High Temperature Operation	29
Control Transformer	22		
Controller	18	Inlet Line	12
CONTROLS & INSTRUMENTS, SECTION 4 ..	18	Inlet Screen and Tube	40
Controls & Instruments, General Description ..	18	Inlet Valve	20
Cooler, Compressor Oil	33	INSTALLATION, SECTION 2	8
Cooling, Sealing and Lubrication	1	Installation, General	8
COUPLING, SECTION 7	41	Installation for Cold Weather Operation	12
Coupling	41		
		Lifting Unit	8
		Line, Discharge Service	13

INDEX

Line, Inlet	12	Oil Cooler Oil Pressure Differential	38
Location	8	Oil Cooler Temperature Differential	38
Low Oil Pressure Protection	9	Oil Cooler Water Pressure Differential	38
Lubricant, Recommended	28	Oil Inlet Pressure	38
Lubricant Change Procedure	29	Operation	
Lubrication, Cooling and Sealing	1	Cold Ambient	30
Lubrication, Motor	15	High Temperature	29
LUBRICATION, OIL COOLER, OIL FILTER & SEPARATOR, SECTION 5	28	Piping, Water	13
Main Starter	23	Pressure Differential Gauging	37
MAINTENANCE SCHEDULE, SECTION 8 ...	42	Pressure Regulator	21
Minimum Discharge Pressure/Check Valve ...	19	Prestart-Up Instructions	16
Moisture in the Oil System	30	Air Filter	16
Moisture Separator/Trap	12	Compressor Oil	16
Motor Grease Recommendations	15	Coupling	16
Motor Lubrication	15	Electrical	16
Motor Regreasing Interval	15	Enclosure	17
		Grounding	16
		Operating Mode	17
		Piping	16
		Rotation	16
		System Pressure	17
Oil Change Interval	31	Purge Valve	21
Oil Cooler, Compressor	33	Recommended Lubricant	28
Oil Cooler – Installation	11	Regreasing Interval, Electric Motor	15
Oil Cooler – Location and General Piping	9	Regulator, Pressure	21
Oil Filter, Compressor	32	Relief Valve	18
Oil Level Gauge	19, 30	Repair Parts, Ordering Instructions	iii
Oil Reservoir	36	Reservoir, Oil	36
Filling	32	Reservoir Pressure Transducer	22
Oil Reservoir Drain	9		
Oil Separator		Safety Precautions	4, 5
Compressor	36	Sealing, Lubrication and Cleaning	1
Inspection	37	Separator, Compressor Oil	36
Oil Carryover	36	Separator/Trap, Moisture	12
Removal for Inspection or Replacement ...	37	Service Check List	42
Oil Specifications	28	Air Filter	42
Oil System		Every 1000 Hours Operation	42
Compressor	28	Every 125 Hours Operation	42
Draining and Cleaning	31	Every 4000 Hours Operation	42
Oil System Check	38		
Air and Oil Discharge Temperature	38		

INDEX

Every 8 Hours Operation	42	System	22
Every Year	42	Transducer	
Motor Lubrication	42	Reservoir Pressure	22
Oil Separator	42	System Pressure	22
Shuttle Valve	21	Transformer, Control	22
Solenoid Valves IVC and IVO	21	TROUBLE SHOOTING, SECTION 9	43
Solenoid Valves TVC and TVO	21	Tube, Inlet	40
Specifications, Oil	28	Turn Valve	1, 21
Starter		Turn Valve Actuator – EAQ Units Only	21
Fan	23	Valve	
Main	23	Blowdown	19
STARTING & OPERATING PROCEDURES,		Inlet	20
SECTION 3	16	Minimum Discharge Pressure/Check Valve	19
Starting the Unit	17	Purge	21
Unit Cold	17	Relief	18
Unit Hot	17	Shuttle	21
Stopping the Unit	17	Solenoid IVC and IVO	21
Strip, Terminal	23	Solenoid TVC and TVO	21
Switch		Turn	21
Air Filter Vacuum	22	Ventilation	9
Vibration	22	Vibration Switch	22
System Pressure Transducer	22	Warranty	Last Page
System Thermistor	22	Water Piping	13
Terminal Strip	23	Wiring, Electrical	14
Thermistor			
Discharge	22		

LIST OF ILLUSTRATIONS

Figure #	Description	Page
Figure 1–1	Compression Cycle	1
Figure 1–2	View of Water Cooled Unit with Aftercooler (less enclosure) – Motor Side	2
Figure 1–3	View of Water Cooled Unit with Aftercooler (less enclosure) – Motor End	2
Figure 1–4	View of Water Cooled Unit with Aftercooler (less enclosure) – Reservoir End	3
Figure 1–5	View of Water Cooled Unit with Aftercooler (less enclosure) – Reservoir Side	3
Figure 2–1	Typical Compressor Room	8
Figure 2–2	Air Flow Chart	8
Figure 2–3	Piping Schematic	9
Figure 2–4	Piping Diagram for Aftercooler and Heat Exchanger	10
Figure 2–5	Cold Weather Installation	11
Figure 2–6	Inlet Line Lengths	12
Figure 2–7	Heat Exchanger (Oil Cooler) Approximate Water Flow	13
Figure 2–8	Aftercooler Approximate Water Flow	13
Figure 4–1	Schematic Tubing Diagram	19
Figure 4–2	Blowdown Valve	19
Figure 4–3	Minimum Discharge Pressure Valve	20
Figure 4–4	Inlet Valve	20
Figure 4–5	Shuttle Valve	21
Figure 4–6	Turn Valve Control	21
Figure 4–7	Turn Valve Actuator	22
Figure 4–8	Control Schematic – Compressor at Full Load	24
Figure 4–9	Control Schematic – Compressor Fully Unloaded – Constant Speed Mode	25
Figure 4–10	Control Schematic – Compressor Fully Unloaded – Low Demand Mode or Auto Mode ..	26
Figure 4–11	Wiring Diagram – 212EAP546	27
Figure 5–1	Flow Diagram – Air/Oil Systems	28
Figure 5–2	Oil System Capacities	30
Figure 5–3	Oil Change Interval	31
Figure 5–4	Compressor Oil Filter	33
Figure 5–5	Oil Flow Diagram – Remote Overhead Mounted Oil Cooler	33
Figure 5–6	Thermostatic Mixing Valve Element	34
Figure 5–7	Water Control Valve	35
Figure 5–8	Dew Point Temperature VS. Ambient Temperature	35
Figure 5–9	Single Element Oil Separator	36
Figure 5–10	Ambient Temperatures	38
Figure 6–1	Heavy Duty Air Filter	40
Figure 7–1	Installation of Coupling Style “A”	41
Figure 7–2	Installation of Coupling Style “B”	41

SECTION 1

GENERAL INFORMATION




FIGURE 1-1 – COMPRESSION CYCLE

COMPRESSOR – The Gardner Denver Electra-Saver® compressor is a single stage, positive displacement rotary machine using meshing helical rotors to effect compression. The input drive shaft and helical drive gear are supported in the gear case by high capacity tapered roller bearings. The drive gear meshes with a driven gear mounted on the main rotor shaft to drive the rotors. Both rotors are supported between large capacity anti-friction bearings located outside the compression chamber. Single width cylindrical roller bearings are used at the inlet end of the rotors. Early models used two (2) heavy-duty, single-row, angular contact ball bearings at the discharge end to locate each rotor axially and carry all thrust loads; later models use tapered roller bearings in this location.

COMPRESSION PRINCIPLE (FIGURE 1-1) – Compression is accomplished by the main and secondary rotors synchronously meshing in a one-piece cylinder. The main rotor has four (4) helical lobes 90° apart. The secondary rotor has five (5) matching helical grooves 72° apart to allow meshing with main rotor lobes.

The air inlet port is located on top of the compressor near the center. The discharge port is near the bottom at the opposite end of the compressor cylinder. *Figure 1-1 is an inverted view to show inlet and discharge ports.* The compression cycle begins as rotors unmesh at the inlet port and air is drawn into the cavity between the main rotor lobes and secondary rotor grooves (A). When the rotors pass the inlet port cutoff, air is trapped in the interlobe cavity and flows axially with the meshing rotors (B). As meshing continues, more of the main rotor lobe enters the secondary rotor groove, normal volume is reduced and pressure increases.

Oil is injected into the cylinder to remove the heat of compression and seal internal clearances. Volume reduction and pressure increase continues until the air/oil

mixture trapped in the interlobe cavity by the rotors passes the discharge port and is released to the oil reservoir (C). Each rotor cavity follows the same “fill-compress-discharge” cycle in rapid succession to produce a discharge air flow that is continuous, smooth and shock free.

AIR FLOW (FIGURE 5-1, page 28) – Air enters the air filter and passes through the inlet unloader valve to the compressor. After compression, the air/oil mixture passes into the oil reservoir where most of the entrained oil is removed by velocity change and impingement and drops back into the reservoir. The air and remaining oil then passes through the oil separator; the separated oil is returned to the system through tubing connecting the separator and compressor. The air passes through the reservoir discharge manifold, discharge check valve, minimum pressure valve and the customer furnished unit shutoff globe valve to the plant air lines.

LUBRICATION, COOLING AND SEALING – Oil is forced by air pressure from the oil reservoir through the oil cooler, thermostatic mixing valve, and oil filter and discharges into the compressor main oil gallery. A portion of the oil is directed through internal passages to the bearings, gears and shaft oil seal. The balance of the oil is injected directly into the compression chamber to remove heat of compression, seal internal clearances and lubricate the rotors.

TURN VALVE – The turn valve is a rotary helical valve located on the discharge side of the cylinder toward the inlet end. The valve opens and closes ports in the cylinder which communicates with the inlet passage. This varies the compressor rotor volume to match the demand for air, thus reducing the part-load power requirement.




FIGURE 1-2 – VIEW OF WATER COOLED UNIT WITH AFTERCOOLER (LESS ENCLOSURE) COMPRESSOR – MOTOR SIDE




FIGURE 1-3 – VIEW OF WATER COOLED UNIT WITH AFTERCOOLER (LESS ENCLOSURE) – MOTOR END




FIGURE 1-4 - VIEW OF WATER COOLED UNIT WITH AFTERCOOLER (LESS ENCLOSURE) COMPRESSOR - RESERVOIR END




FIGURE 1-5 - VIEW OF WATER COOLED UNIT WITH AFTERCOOLER (LESS ENCLOSURE) RESERVOIR SIDE

SAFETY PRECAUTIONS

Safety is everybody's business and is based on your use of good common sense. All situations or circumstances cannot always be predicted and covered by established rules. Therefore, use your past experience, watch out for safety hazards and be cautious.

Some general safety precautions are given below:



DANGER

Failure to observe these notices could result in injury to or death of personnel.


- **Keep fingers and clothing away** from revolving fan, drive coupling, etc.
- **Do not use the air discharge** from this unit for breathing – not suitable for human consumption.
- **Do not loosen or remove** the oil filler plug, drain plugs, covers, the thermostatic mixing valve or break any connections, etc., in the compressor air or oil system until the unit is shut down and the air pressure has been relieved.
- **Electrical shock** can and may be fatal.
- **Compressor unit must be grounded** in accordance with the National Electrical Code. A ground jumper equal to the size of the equipment ground conductor must be used to connect the compressor motor base to the unit base.
- **Fan motors must remain grounded** to the main base through the starter mounting panel in accordance with the National Electrical Code.
- **Open main disconnect switch**, tag and lockout before working on the control.
- **Disconnect the compressor** unit from its power source, tag and lockout before working on the unit – this machine is automatically controlled and may start at any time.

 WARNING


Failure to observe these notices could result in damage to equipment.

- Stop the unit if any repairs or adjustments on or around the compressor are required.
- Disconnect the compressor unit from its power source, tag and lockout before working on the unit – this machine is automatically controlled and may start at any time.
- An Excess Flow Valve should be on all compressed air supply hoses exceeding 1/2 inch inside diameter. (OSHA Regulation, Section 1926.302)
- Do not exceed the rated maximum pressure values shown on the nameplate.
- Do not operate unit if safety devices are not operating properly. Check periodically. Never bypass safety devices.


DECALS




206EAQ077




212EAQ077



218EAQ077




211EAQ077




207EAQ077


DECALS




216EAQ077




217EAQ077



222EAQ077



221EAQ077



208EAQ077

SECTION 2
INSTALLATION

GENERAL – On receipt of the unit, check for any damage that may have been incurred during transit. Report any damage or missing parts as soon as possible.

 CAUTION

Do not electric weld on the compressor or base; bearings can be damaged by passage of current.

LIFTING UNIT:

 CAUTION

Lift compressor unit by base only. Do not use other places such as motor, compressor or discharge manifold piping as lifting points.

 DANGER

The eyebolts or lugs provided on the motor are for lifting the motor only and should not be used to lift any additional weight. All eyebolts must be securely tightened. When lifting the motor the lifting angle must not exceed 15 degrees. Failure to observe this warning may result in damage to equipment or personal injury.

 DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

LOCATION – The compressor should be installed in a clean, well-lighted, well-ventilated area with ample space all around for maintenance. Select a location that provides a cool, clean, dry source of air. In some

cases it may be necessary to install the air filter at some distance from the compressor to obtain proper air supply.

The compressor unit require electric motor cooling air as well as air to the compressor inlet. Proper ventilation **MUST** be provided (FIGURE 2-2); hot air must be exhausted from the compressor operating area. A typical inlet-outlet air flow arrangement is shown in FIGURE 2-1.




FIGURE 2-1 – TYPICAL COMPRESSOR ROOM


If the air-cooled oil cooler module is to be installed at a location remote from the compressor unit, be sure that adequate ventilation is provided, FIGURE 2-2. Hot air must be exhausted from the oil cooler area.

Do not block the air flow to and from the unit. Allow 3-1/2 feet to the nearest obstruction on the control box side of the unit and 3 feet on all other sides.


Size	Open Compressor Unit	Aftercooler and Oil Cooler Module	Open Unit With Aftercooler & Oil Cooler Module Discharge in Same Room
350 HP	12,600	43,000	55,600
400 HP	14,400	43,000	57,400
500 HP	18,000	43,000	61,000

* 80° F Inlet Air

FIGURE 2-2 – AIR FLOW CHART



**PIPING SCHEMATIC OF COOLER
WITH SCREWED CONNECTIONS.**



**PIPING SCHEMATIC OF COOLER
WITH FLANGED CONNECTIONS.**

FIGURE 2-3 – PIPING SCHEMATIC

VENTILATION – The unit, whether air- or water-cooled, requires sufficient air flow, FIGURE 2-2, for electric motor cooling. Air is drawn into the back and front of the motor and is discharged out the sides. Do not block air flow to and from the unit.

FOUNDATION – The Electra-Saver® compressor requires no special foundation but should be mounted on a smooth, solid surface of sufficient strength to support the weight of the unit. Whenever possible install the unit near level. Temporary installation may be made at a maximum 10° angle lengthwise or 30° sidewise.

Mounting bolts are not normally required. However, installation conditions such as piping rigidity, angle of tilt, or danger of shifting from outside vibrations or moving vehicles may require the use of mounting bolts to the foundation.

OIL RESERVOIR DRAIN – (FIGURE 1-5, page 3) The oil reservoir drain valve is located near the center of the oil reservoir just below the separator tower. The drain valve is approximately 5 inches from the floor level. If this height is not sufficient to conveniently drain the oil, some other methods of providing oil drain are:

1. Elevate the compressor unit on a suitable structure to obtain the desired drain height.
2. Construct an oil sump or trough below the floor level and pump or bail the drained oil.
3. Pump oil from the reservoir filler opening or drain to a container.

ACOUSTIC ENCLOSURE – The Electra-Saver® unit is furnished with an acoustic enclosure over the compressor only, as standard equipment. The enclosure reduces the normal operating sound of the unit to 90 DBA or below in free field conditions.

AIR-COOLED OIL COOLER MODULE – The air-cooled oil cooler is a separate module and may be mounted remote to the compressor unit.

Ventilation – The oil cooler requires adequate cooling air flow. Proper ventilation **MUST** be provided, with hot air exhausted away from the cooler; take care that hot air is not recirculated from the exhaust to the inlet side of the cooler. Cooling air flow direction is from the motor side through the grille side of the oil cooler. Do not obstruct the air flow to or from the cooler. Allow two (2) feet clearance on all sides of the cooler module. See FIGURE 2-2, page 8, for cooling air flow requirements.

Low Oil Pressure Protection – The standard factory-installed low oil pressure shutdown switch in the control box will prevent start-up or shut the unit down if oil pressure is not established or maintained due to malfunction in the oil cooler system.

Oil Cooler – Location and General Piping – The oil cooler module can be mounted in any of several remote locations; close coupled but not joined to the compressor unit; horizontal remote, located on the same level as the compressor unit, but some distance away; or overhead remote, located above level of the compressor unit, as on a roof.




FIGURE 2-4 - PIPING DIAGRAM FOR AFTERCOOLER AND HEAT EXCHANGER

⚠ WARNING

The machine cannot be run blown down with remote overhead oil cooler. These units require special wiring diagram – check with factory. Running the machine blown down with an overhead cooler could result in damage to compressor.

All piping and wiring between the compressor unit and the remote oil cooler is to be supplied by the user. **THE DESIGN OF THE REMOTE OIL COOLER MODULE SYSTEM MUST BE APPROVED BY THE FACTORY BEFORE INSTALLATION.** The design information to be submitted for approval includes:

1. Location of oil cooler module – inside or outdoors.
2. Range of operating ambient temperatures at the oil cooler location.
3. Elevation of the oil cooler above the compressor unit.
4. Pipe type and size(s) to be used to connect the oil cooler and the compressor unit. Minimum pipe size is 2-1/2" NPT.
5. Horizontal and vertical lengths of the pipe run. If more than one pipe size is used, list length of each size and total length.
6. Number and size of elbows, tees, unions, reduc-

ers, and valves to be used in the pipe run.

7. A dimensional sketch of the proposed piping system showing location of the compressor unit, oil cooler, pipe, and fittings illustrating design information included in numbers 3 through 6 above.

All remote piping should be of adequate size to insure a minimum pressure loss. Number 4 above lists the minimum pipe size to be used. Long runs of pipe and the use of valves and fittings require larger than the minimum pipe sizes in the system to keep the pressure loss low. All pipe and fittings used in a remote oil cooler system should be galvanized or treated internally to prevent rust, and all valves are to be of a nonferrous construction to prevent corrosion and fouling.

The remote cooler should be placed so that the fan air flow through the cooler (air flow is from the motor side through core) and the prevailing winds are in the same direction. A baffle should be provided on the exhaust side of the cooler for protection against occasional wind shifts.

When the oil cooler is mounted above the compressor unit, a check valve is to be mounted on the compressor unit in the line to the oil cooler; see FIGURE 5-4, page 33. A pneumatic pilot-operated normally-closed valve is to be mounted at the oil filter inlet on the compressor unit line from the oil cooler. The check valve permits oil flow to the oil cooler during operation, but prevents return oil flow from the cooler when the unit is shut down. The pilot valve is held open by air pressure from the unit oil reservoir during operation and closes under spring load when the unit is shut down to prevent return oil flow from the oil cooler.




FIGURE 2-5 – COLD WEATHER INSTALLATION

An oil filler stand pipe and plug must be located in the piping on the oil cooler module for ease of filling of a remote oil cooler, see FIGURE 5-4, page 33.

Oil Cooler – Installation – Inspect unit upon arrival. In case of damage, report immediately to transportation company. Before installation, check rating plate on motor to verify that power input and motor specification requirements match available electric power at point of installation.

1. Set the unit level on a firm, solid foundation. The larger oil cooler models have lifting holes to facilitate unit hoisting.
2. Allow for linear expansion and contraction of piping in the direction away from the oil cooler. Use flexible connectors or suitable expansion joints on all oil cooler inlet and outlet piping. See FIGURE 2-3, page 9, for typical schematics.
3. Select properly tensioned and aligned piping support clamps or hangers and position them to relieve any piping stress at the oil cooler inlet and outlet ports. Do not support from flexible connectors.
4. Service – For continuous efficiency, oil cooler cores must be periodically cleaned with either vacuum or compressed air. If wet cleaning is required, shield motor and spray on a mild soap solution and flush with clear water.

AUXILIARY AIR RECEIVER – The unit requires an auxiliary air receiver unless the piping system is large and provides sufficient storage capacity to prevent rapid cycling. When used, an air receiver should be of adequate size, provided with a relief valve of proper setting, a pressure gauge, and a means of draining condensate.

AFTERCOOLER (FIGURE 1-2 and FIGURE 1-5, pages 2 and 3) – An aftercooler will provide control of moisture entering the shop air lines while reducing the normal low discharge temperature of about 180° F at 100 PSIG discharge pressure to near inlet air temperature, or cooling water temperature.

Air-Cooled Machines – When an aftercooler is furnished on an air-cooled machine, the aftercooler is installed on the oil cooler module between the fan and the oil cooler. The moisture separator is furnished by Gardner Denver but must be mounted by the customer between the aftercooler and the auxiliary air receiver with a condensate drain provided at the bottom. All air piping from the compressor discharge to aftercooler to auxiliary air receiver is to be furnished and mounted by customer. **The design of the aftercooler piping must be approved by the factory before installation.** Design information to be submitted for approval includes:

1. Location of aftercooler module – inside or outdoors.
2. Range of operating ambient temperatures at the aftercooler location.
3. Pipe type and size(s) to be used to connect the aftercooler, separator, and compressor unit – minimum pipe size is 5" NPT.
4. Lengths of the pipe run. If more than one pipe size is used, list length of each size and total length.
5. Number and size of elbows, tees, unions, reducers, and valves to be used in the pipe run.
6. A dimensional sketch of the proposed piping system showing location of the compressor unit, aftercooler, separator and auxiliary air receiver, pipe and fittings illustrating design information included in numbers 3 through 5 above.

Water-Cooled Machines (FIGURE 2-4, page 10) – On water-cooled machines with aftercooler, the moisture separator and condensate drain are shipped loose and must be installed by customer. Customer must furnish and install all water piping required.

INSTALLATION FOR COLD WEATHER OPERATION – It is recommended that the unit be installed inside a shelter that will be heated to temperatures above freezing (32°F, 0°C). This will eliminate many of the problems associated with operating units in cold climates where freezing rain, drifting snow, freezing condensate and bitter cold temperatures are encountered.

Refer to Engineering Data Sheet 13-9-411 for the advantages of using the heat recovered from rotary compressors. This heat recovery could easily pay for an adequate shelter for the unit.

When an outside installation must be made, the precautions required will depend on the severity of the environment. The following are general guidelines for outside installations:

Cold Weather (Down To +10°F)

1. Be sure all drains, traps, and control lines, including pressure transducer lines are heated to avoid freezing of condensate. Heat tape with thermostat control is generally satisfactory for this purpose and can be obtained at various local plumbing or hardware outlets at nominal cost.
2. If an air-cooled aftercooler is to be used, provisions to bypass the aftercooler must be made. Since cold air contains very little moisture, successful operation can be achieved without the aftercooler. Successful operation down to +15° F can be accomplished by reversing fan flow, but cooler bypass should still be provided should it be required.
3. Provide at least some simple shelter such as a plywood windbreak to protect against drifting snow.
4. Use only Gardner Denver® AEON™ 9000 SP lubricant.
5. Monitor the unit carefully during start-up and operation to be sure it is functioning normally.

6. Specify NEMA 4 enclosure for electrical devices.

Extreme Cold Weather Operation (Down To -40°F, -40°C) – In addition to the above, the following should be provided:

1. A temperature switch to control the fan should be provided for better starting and quicker warm-up. This switch can be provided from the factory and will delay fan start-up until discharge temperature reaches approximately 150-160° F.
2. It will probably be necessary to provide shutters or to block off part of the cooler in some manner since the cooler is greatly oversized for operation in these low temperatures. Shutters are not a factory option.
3. Auto operation should not be used in extreme environments.
4. Coolers should be located as close to the unit as possible. Long lines to and from the cooler only further complicate the circulation of oil flow on cold starts. Heat tape and insulation may be required on oil lines.
5. Some means of providing heat to the oil reservoir and cooler during shutdown should be provided. There are various methods to accomplish this, but since openings are not provided for sump heaters, the use of radiant heaters is recommended. The heaters should be sized to provide at least a +10°F environment for coolers, motor and sump. FIGURE 2-5, page 11, shows how these might be located in a typical installation and sizes required.

Remember unsheltered (outside) installations should be avoided where possible. Installation next to a heated building where enough heat can be used to keep the compressor room above freezing will save many complications in the operation and installation of the unit.

MOISTURE SEPARATOR/TRAP – Since the unit is equipped with a built-in aftercooler, a combination moisture separator and trap is furnished with the unit. A means of draining condensate will need to be provided for.

INLET LINE – Where an inlet line is used between the air filter and the compressor, it must be thoroughly

Length of Inlet Line	Diameter of Pipe Size
0 to 10 Feet	Same as Compressor Inlet Opening
10 to 17 Feet	One Size Larger Than Inlet Opening
17 to 38 Feet	Two Sizes Larger Than Inlet Opening

FIGURE 2-6 – INLET LINE LENGTHS

HEAT EXCHANGER							
Size	Rated Pressure PSIG	Water Temperature to Heat Exchanger Gallons/minute				Maximum Water Flow GPM	Approximate Water Pressure Drop @ Maximum Flow (PSI)
		60° F.	70° F.	80° F.	90° F.		
350 HP	ALL	33	42	56	83	120	21.0
400 HP	ALL	38	48	64	95	120	21.0
500 HP	ALL	48	60	80	119	130	17.0

The maximum water flow shown is allowable through the heat exchanger.

FIGURE 2-7 – HEAT EXCHANGER (OIL COOLER) APPROXIMATE WATER FLOW

AFTERCOOLER							
Size	Rated Pressure PSIG	Water Temperature to Aftercooler Gallons/minute				Maximum Water Flow GPM	Approximate Water Pressure Drop @ Maximum Flow (PSI)
		60° F.	70° F.	80° F.	90° F.		
350 HP	ALL	8.4	10.5	14.0	21.6	100.0	10.0
400 HP	ALL	9.4	11.7	15.6	23.5	100.0	10.0
500 HP	ALL	11.3	14.1	18.8	29.0	100.0	10.0

Water flow rates (gpm) are based on 100° F water temperature out of cooler. Maximum water flow shown is the maximum allowable flow through aftercooler.

FIGURE 2-8 – AFTERCOOLER APPROXIMATE WATER FLOW

cleaned on the inside to prevent dirt or scale from entering the compressor. **If welded construction is used, the line must be shot blasted and cleaned to remove welding scale.** In either case, the inlet line must be coated internally by galvanizing or painting with a moisture and oil-proof sealing lacquer. The inlet line should be the full size of the inlet opening on the compressor. If an extra-long line is necessary, the pipe size should be increased according to Inlet Line Length Chart, FIGURE 2-6, page 12.

Accessibility for inlet air filter servicing must be considered when relocating the filters from the unit to a remote location.

DISCHARGE SERVICE LINE – The discharge service line connection on water-cooled units with aftercooler is made at the moisture separator. On air-cooled units and water-cooled without aftercooler, the connection is made at the pipe nipple located behind the instrument panel. When manifolding two or more Electra-Saver® units on the same line, each unit is isolated by the check valve in the unit discharge line.

If an Electra-Saver® unit is manifolded to another compressor, be sure the other compressor has a check valve in the line between the machine and the manifold.

If an Electra-Saver® and a reciprocating compressor are manifolded together, an air receiver must be located between the two units.



DANGER

Discharge air used for breathing will cause severe injury or death.

Consult filtration specialists for additional filtration and treatment equipment to meet health and safety standards.

WATER PIPING (Water-Cooled Heat Exchanger Models Only) – On machines equipped with water-cooled heat exchangers, the water inlet and outlet con-

nections are located in the unit base flange on the left side of the unit.

WARNING

It is mandatory that any water cooled unit be installed in a shelter heated to temperatures above freezing (32° F., 0° C).

The water source should be capable of supplying up to the maximum flow shown in FIGURE 2–6, page 12, and FIGURE 2–7, page 13, at a minimum pressure of 40 PSIG; maximum allowable water pressure is 150 PSIG. The water flow rates shown in FIGURE 2–6, page 12, are approximate and a guide to sizing piping, cooling tower and other water system equipment.

The heat exchanger system is designed to operate with water inlet temperatures from 60° to 90° F and a water outlet temperature not to exceed 110° F. If water cooler than 60° F is used, high water outlet temperatures (over 110° F) will be experienced along with shortened heat exchanger life caused by tube fouling and corrosion. If water warmer than 90° F is used, higher compressor oil inlet temperatures and high water usage will result.

Most water systems will require control of impurities: filtration, softening or other treatment. See “Compressor Oil Cooler – Water–Cooled Heat Exchanger” for more information on the water system.

Aftercooler – Heat Exchanger Water Piping (FIGURE 2–4, page 10, and FIGURE 2–6, page 12, and FIGURE 2–7, page 13) – If an aftercooler is used and piped in series with the heat exchanger, install the water flow control valve and magnetic water shutoff valve, if used, downstream of the exchanger. Pipe the aftercooler water outlet to the heat exchanger water inlet on the compressor unit.

If the aftercooler is piped in parallel with the heat exchanger, provide a manual valve between aftercooler outlet and heat exchanger outlet after the water control valve to adjust aftercooler water flow for discharge temperature required and most economical water use; separate water inlet lines are piped to the aftercooler and heat exchanger.

If the standard factory built-in aftercooler is used, the maximum allowable water flow through the aftercooler is 100 gallons per minute on all 350 – 500 HP units and the maximum water inlet pressure is 150 PSIG. If another aftercooler is used, consult the manufacturer for operating limits.

CAUTION

When an aftercooler is piped in series with the oil cooler, the maximum allowable flow rate through the oil/aftercooler system is the maximum allowed by the aftercooler. If the oil cooler requires more water flow than the maximum allowed by the aftercooler, a parallel water piping system must be used.

The water control valve **MUST** be used to maintain discharge temperatures approximately 10° F. over the dew point for expected ambient (FIGURE 5–7, page 35). See Section 5 for adjustment instructions and maximum allowable oil temperature.

ELECTRICAL WIRING – The Electra-Saver® unit is furnished with the compressor motor enclosure as specified by the user. If unit has an air-cooled oil cooler, this fan motor is a totally enclosed “air-over” or “fan-cooled type” and is complete with starter and enclosure as specified by the user. Allow 42” deep and 30” wide clear space to the nearest obstruction in accordance with Article 110–16(a), National Electric Code.

It is necessary to connect the compressor unit (and oil cooler, if used) to a main starter of the correct size, power characteristics, and enclosure for the application. See Section 4 for typical wiring diagrams; however, use only the wiring diagrams supplied with the unit for final connections.

Starter – The main starter is to be mounted at a location selected by the user at the time of installation. The first three feet of line from the motor conduit box to the starter must be of flexible conduit to maintain effective vibration isolation. Electrical connections to other parts of the unit (instrument panel, fan motor, etc.) from the starter do not require flexible conduit since the compressor and motor are already isolated from these parts. See Article 110–16(a) National Electric Code for working clearance.

WARNING

Electrical shock can cause injury or death. Open main disconnect switch, tag and lockout before working on starter/control box.

GROUNDING – Equipment must be grounded in accordance with Section 250–95 of the National Electrical Code.

 WARNING

Failure to properly ground the compressor package could result in controller malfunction.

MOTOR LUBRICATION – Long time satisfactory operation of an electric motor depends in large measure on proper lubrication of the bearings. The following charts show recommended grease qualities and regreasing intervals for motors supplied with ball bearings. For additional information refer to the motor manufacturer's instructions. The following procedure should be used in regreasing:

1. Stop the unit.
2. Disconnect, tag and lockout the unit from the power supply.

3. Remove the relief plug and free hole of hardened grease.
4. Wipe lubrication fitting clean and add grease with a hand-operated grease gun.

The amount and type of grease added is very important. Only enough grease should be added to replace the grease used by the bearing. Too much grease can be as harmful as insufficient grease. The grease cavity should be filled 1/3 to 1/2 full.

5. Leave the relief plug temporarily off. Reconnect the unit and run for about 20 minutes to expel the excess grease.
6. Stop the unit. Replace the relief plug.
7. Restart the unit.

 WARNING

Rotating machinery can cause injury or death. Open main disconnect, tag and lockout power supply to the starter before working on the electric motor.

ELECTRIC MOTOR GREASE RECOMMENDATIONS (–30° to 50° C)

MANUFACTURER	TRADE NAME
CHEVRON	SRI #2
SHELL	DOLIUM R
EXXON	UNIREX #2
EXXON	POLYREX

ELECTRIC MOTOR REGREASING INTERVAL

Type of Service	Typical Examples	Rating	Relubrication Interval
Standard	One– or Two–Shift Operation	Above 150 HP	12 Months
Severe	Continuous Operation	Above 150 HP	6 Months
Very Severe	Dirty Locations, High Ambient Temperature	Above 150 HP	2 Months

SECTION 3

STARTING & OPERATING PROCEDURES

PRESTART-UP INSTRUCTIONS – A new unit as received from the factory has been tested and then prepared for shipping only. Do not attempt to operate the unit until checked and serviced as follows:

1. **Compressor Oil** – Check the oil level in the reservoir. Add oil only if the oil level gauge reads in the red “ADD OIL” range. Do not mix different type oils. The unit is shipped filled with Gardner Denver AEON™ 4000 SP Lubricating Coolant which is suitable for the first 6000 hours under normal operating conditions.

REPLACE OIL FILTER EVERY 1000 HOURS.

Initial fill, or filling after a complete draining of the system, may show the oil level in the yellow “EXCESS OIL” range. After start-up, the oil will fall into the green operating range as system components are filled. If necessary, add oil to bring the level to the top of the green range as read when the unit is operating at full load and normal pressure. See FIGURE 5-2, page 30.

NOTICE

Regular maintenance and replacement at required intervals of the oil filter, air filter and air-oil separator is necessary to achieve maximum service and extended drain intervals of AEON™ 9000 SP synthetic lubricant. Use only genuine Gardner Denver filters designed and specified for this compressor.



DANGER

Always stop the unit and release air pressure before removing the oil filler plug. Failure to release pressure may result in personal injury or death.

During unloaded operation and after shutdown, the system will partially drain back into the oil res-

ervoir and the oil level may read higher than when operating on load. DO NOT DRAIN OIL TO CORRECT; on the next loaded cycle or start, oil will again fill the system and the gauge will indicate the operating level.

2. **Air Filter** – Inspect the air filter to be sure it is clean and tightly assembled. Refer to Section 6, “Air Filter,” page 39, for complete servicing instructions. Be sure the inlet line, if used, is tight and clean.
3. **Coupling** – Check all bolts and cap screws for tightness. See Section 7, page 41.
4. **Piping** – Refer to Section 2, “Installation,” page 10, and make sure piping meets all recommendations.
5. **Electrical** – Check the wiring diagrams furnished with the unit to be sure it is properly wired. See Section 4, “Controls and Instruments,” for general wiring diagrams and Section 2, page 8 for installation instructions.
6. **Grounding** – Equipment must be properly grounded according to Section 250-95 of the National Electrical Code.



WARNING

Failure to properly ground the compressor package could result in controller malfunction.

7. **Rotation** – Check for correct motor rotation using “JOG MODE.” Compressor drive shaft rotation must be clockwise standing facing the compressor coupling.



WARNING

Operation with incorrect motor rotation can damage equipment and cause oil eruption from the compressor inlet. When checking motor rotation, induce minimum rotation (less than one revolution if possible). Never allow motor to reach full speed.

8. **System Pressure** – Set the controls to the desired load pressure. DO NOT EXCEED THE MAXIMUM OPERATING PRESSURE ON THE COMPRESSOR NAMEPLATE. See Section 4, “Controls and Instrumentation” for procedure.



WARNING

Operation at excessive discharge air pressure can cause personal injury or damage to equipment. Do not adjust the full discharge air pressure above the maximum stamped on the unit nameplate.

9. **Operating Mode** – Refer to Section 4 for detailed information on the control system.
10. **Enclosure** – Check for damaged panels or doors.

Check all screws and latches for tightness. Be sure doors are closed and latched.

STARTING THE UNIT – OBSERVE UNIT COLD OR HOT STARTING PROCEDURES.

Unit Cold – If the unit is a water-cooled heat exchanger model, open any manual water inlet valves wide open. Start the unit by pushing either the “CONSTANT RUN” button or one of the “AUTO” buttons. Since the unit is equipped with a minimum (65 psig) pressure discharge valve, no special procedure to maintain unit reservoir pressure is required.

Unit Hot – No warm-up period is required. If the unit is a water-cooled heat exchanger model, open any manual water inlet valves wide open. Start the unit by pushing either the “CONSTANT RUN” button or one of the “AUTO” buttons.

DAILY CHECK – Refer to Section 8, “Maintenance Schedule,” page 42.

STOPPING THE UNIT – Press “STOP–RESET” button. The oil reservoir will automatically blow down as the motor stops. If the unit is a water-cooled heat exchanger type, close any manual water inlet valves.

SECTION 4

CONTROLS & INSTRUMENTATION

GENERAL DESCRIPTION – The Gardner Denver rotary screw compressor is prewired with all controls for the voltage and horsepower at the time of ordering. It is necessary only to connect the motor to the customer-supplied starters, the compressor unit to the correct power supply and to the shop air line (and to the appropriate water supply if water cooled). A standard compressor unit consists of the compressor, oil reservoir, oil cooling system and filter, motor type as specified, NEMA 12 control box, and control components as described below.

AUTO SENTRY® OPERATION

Operation of the “AUTO SENTRY®” controller is dependent on selection of an operating mode from the controller keypad. Prior to starting, the [STOP/RESET] key must be pressed to place the controller into its “READY” state (as indicated on the display). Compressor operation may then be started by pressing an operating mode key.

AUTOMATIC is the most commonly selected mode of operation, as it will operate the compressor unit automatically in the most efficient manner for the demand of the air system.

Once operating, the mode may be changed at any time by pressing a key, and the selected mode will be displayed in the lower right corner of the message window. Press the [STOP/RESET] key at any time to stop the compressor under normal conditions.

Detailed instructions for the controller are found in the manual 13–9/10–647.

WARNING

Automatic restarting or electrical shock can cause injury or death. Open, tag and lockout main disconnect and any other circuits before servicing the unit.

CONTROL DEVICES

Controller – This compressor unit features the “AUTO SENTRY®” controller, which integrates all the control functions under microprocessor control. Its functions include safety and shutdown, compressor regulation, operator control, and advisory/maintenance indicators. The keypad and display provide the operator with a log-

ical and easily operated control of the compressor and indication of its condition. The controller is factory adjusted for the compressor package, but allows tuning for specific applications.

Relief Valve – A pressure relief valve(s) is (are) installed in the final discharge line and set to approximately 120–125% of the unit’s full load operating pressure for protection against over pressure. Periodic checks should be made to ensure its (their) operation.

The relief valve should be tested for proper operation at least once every year. To test the relief valve, raise the system operating pressure to 75% of the relief valve set pressure and manually open the valve with the hand lever. Hold the valve open for a few seconds and allow it to snap shut.

WARNING

When the relief valve opens, a stream of high velocity air is released, resulting in a high noise level and possible discharge of accumulated dirt or other debris. Always wear eye and ear protection and stand clear of the discharge port when testing the relief valve to prevent injury.


CAUTION

Never paint, lubricate or alter a relief valve. Do not plug vent or restrict discharge.

WARNING

Operation of unit with improper relief valve setting can result in severe personal injury or machine damage.

Insure properly set valves are installed and maintained.



B76087

FIGURE 4-3 – MINIMUM DISCHARGE PRESSURE / CHECK VALVE

from the shop air line when the unit stops, unloads, or is shut down.

The valve incorporates a spring-loaded piston which maintains approximately 65 psig in the oil reservoir.

When the air pressure on the upstream (reservoir) side of the valve rises above 65 psig, the spring is overridden and the valve opens to full porting.


The valve does not require maintenance or adjustment. If the valve fails to function, check the valve stem O-ring for sealing, valve orifices for restriction, or valve and valve seat for burrs and dirt.

The valve is adjustable within a small range. It is adjusted by a screw on the side of the valve. By turning the screw, the minimum pressure to open the valve increases. Conversely, backing it out decreases the minimum pressure required to open the valve.

To service the valve, unscrew the valve cap from the body. The internal parts will come out after the cap has been removed. Repair kits are available from your local authorized Gardner Denver Machinery distributor.

Inlet Valve (FIGURE 1-4, page 3, and FIGURE 4-4, page 20) – The Inlet valve restricts the inlet to control delivery and closes to unload the compressor. At shut-down, the inlet valve closes to prevent the back flow of air.

The inlet valve position is controlled by air pressure in its piston cylinder, which is controlled by the “AUTO SENTRY®” controller through solenoid valves IVC and IVO. As Pressure to the piston is increased, the valve closes to restrict air flow and compressor delivery.



203EAY797-B
(Ref Drawing)

FIGURE 4-4 – INLET VALVE




FIGURE 4-5 – SHUTTLE VALVE

Solenoid Valves IVC and IVO – These valves control position of the inlet valve in response to signals from the “AUTO SENTRY®” controller. With both valves de-energized, the normally open IVC valve allows control pressure to the inlet piston to close the valve. If IVC only is energized, the inlet valve is held in its current position. If both valves are energized, control pressure is relieved from the inlet piston to allow the valve to open.

Pressure Regulator – The pressure regulator is used to supply a constant and low control pressure to prevent damage to the inlet valve from “slamming.” The regulator should be set for 25–30 psig.

Shuttle Valve (FIGURE 4-5) – Also known as a double check valve, the shuttle valve is a device which will take two (2) supply signals and allow the one with the highest pressure to pass through. The shuttle valve is used to provide control air pressure from either the reservoir or plant air system, as required during different operating conditions.

Purge Air Valve – The purge valve is a normally closed two-way air actuated valve that admits purge air from the final discharge manifold to the compressor to counteract the oil knock that occurs in oil-flooded rotary screw compressors when they are completely unloaded with pressure in the oil reservoir. This valve is controlled by the same control pressure which controls the inlet valve.

Turn Valve (Electra-Saver only) (FIGURE 4-6)– The turn valve is a helical valve which, when rotated, opens and closes a series of ports cast into the compressor cylinder. When these ports are open, they direct some of the air which would otherwise be compressed back

to the inlet, reducing both capacity and power consumption.

Turn Valve Actuator (Electra-Saver only) (FIGURE 4-7) – The turn valve actuator is a rotary rack and pinion device which positions the turn valve according to system demand. Filtered oil from the compressor sump is directed to the outboard end of the two actuating cylinders to move the rack and rotate the valve. Located on the ends of the cylinders are adjusting screws which limit the travel of the actuator. The adjusting screw on the top adjusts the open position of the turn valve; the bottom adjusting screw adjusts the full closed (full load) position of the valve. The full load position of the actuator may be checked by removing the adjusting screw at the unloaded end of the actuator (top of the compressor) and using a rod to push the pistons to the full load position. The rod must be clean and free of burrs and scale. Take care not to scrape the cylinder walls when moving the pistons.

Solenoid Valves TVC and TVO (Electra-Saver only) – These valves control the position of the turn valve in response to signals from the “AUTO SENTRY®” controller. With both valves de-energized, equal pressure is applied to both ends of the actuator to hold it in its




FIGURE 4-6 – TURN VALVE CONTROL

present position. If TVC only is energized, the right side of the turn valve actuator is exhausted to the compressor inlet cavity, causing the turn valve to move towards the full load position. If TVO only is energized, the left end of the turn valve actuator is exhausted to the compressor inlet cavity, causing the turn valve to move towards the unload position. See "AUTO SENTRY® OPERATION," in this section for a description of how the turn valve position is controlled during normal operation.

System Pressure Transducer – This transducer is connected after the minimum pressure valve. It converts the pressure in the plant air system into an electrical signal for use by the "AUTO SENTRY®" controller for modulation and control.

Reservoir Pressure Transducer – This transducer is connected to the coolant system. Its signal is used to prevent loaded starts, monitor reservoir pressure, and monitor the condition of the air/oil separator.

Air Filter Vacuum Switch – This switch is used to monitor air filter condition and alert the user if the filter requires service or replacement.

Discharge Thermistor – This sensor is located directly in the compressor discharge. Its signal is used to monitor compressor temperature and shut down the compressor if a coolant problem is detected.

Reservoir Thermistor – This sensor is located near the separator and is used to monitor temperature and shut down the compressor if high temperatures are detected.

Emergency Stop Push-Button – This is a maintained push-button, and removes power from the controller outputs regardless of controller status. It is located on the upper section of the panel, next to the keypad. This should be used for emergency purposes

only – use the keypad [STOP/RESET] for normal controlled stopping.

⚠ **WARNING**

Automatic restarting or electrical shock can cause injury or death. Open, tag and lockout main disconnect and any other circuits before servicing the unit.

Vibration Switch – The "AUTO SENTRY®" controller has one additional input available for dealer or user installed optional shutdown switches. The switch is simply wired in place of the jumper between terminals 7 and 9 of the terminal strip. If the contact is opened, the compressor will be shut down, and will display "SHUTDOWN – HIGH VIBRATION".

The vibration shutdown switch is to be mounted on the compressor coupling cover, and detects an increase in vibration that could be an indication of impending damage to the unit. The switch actuates when the selected level of vibration is exceeded.

The switch must be adjusted when the unit is first installed. Refer to the switch manufacturer's instruction manual for complete details.

Control Transformer – This control device changes the incoming power voltage to 110–120 volts for use by all unit control devices. The transformers employed are usually connectable for several input voltages, refer to the transformer label for connection prior to energizing. Two primary and one secondary fuse are provided. Refer to adjacent labeling for replacement information.




FIGURE 4-7 – TURN VALVE ACTUATOR

Terminal Strip – This provides connections for all 110–120 volt devices not contained within the enclosure.

Fan Starter – The starter is used to provide control and overload protection for the optional ventilation fan. Overload heaters should be selected and adjusted based on the motor nameplate amps and the instructions located inside the cover of the electrical enclosure. Three fuses are provided. Refer to adjacent labeling for replacement information.

Aircooled units are provided with a combination disconnect/starter for the cooling module. Refer to manual 13–9/10–647 for connection information.

Main Starter – This starter is used to provide control and overload protection for the main drive motor. Refer to the manufacturer's instructions for proper overload protection and to manual 13–9/10–647 for connection information.

COMPRESSOR CAPACITY CONTROL – TURN VALVE UNITS ONLY

The capacity of the compressor is controlled by the ac-

tion of the Turn Valve and the Compressor Inlet Valve.

The turn valve controls compressor delivery to match demands of 40% to 100% of the compressor's maximum capacity. The inlet valve throttles to control compressor delivery to match demands of 0% to 40% of the compressors maximum capacity.

Example with normal setting of 100 PSIG:

Compressor Delivery	Inlet Valve	Turn Valve	Discharge Manifold Pressure
Full Capacity	Open	Closed	100
70% Capacity	Open	50% Open	100
40% Capacity	Open	Full Open	100
30% Capacity	Closing	Full Open	103
20% Capacity	Closing	Full Open	103
0% Capacity	Closed	Full Open	103




FIGURE 4-8 - CONTROL SCHEMATIC - COMPRESSOR AT FULL LOAD

205EAY797-B
(Ref. Drawing)




FIGURE 4-9 – CONTROL SCHEMATIC – COMPRESSOR FULLY UNLOADED – CONSTANT SPEED MODE

206EAY797-B
(Ref. Drawing)





FIGURE 4-10 – CONTROL SCHEMATIC – COMPRESSOR FULLY UNLOADED – LOW DEMAND MODE



NOTE 1: FORM C CONTACT FOR USE BY OTHERS. CONTACT OPERATES FOLLOWING COMPRESSOR SHUTDOWN. RATING: 120VAC, 2 AMP.

NOTE 2: FOR USE WITH OPTIONAL SHUTDOWN SWITCH, REMOVE JUMPER BETWEEN TERMINALS 7 & 9. CONNECT N.C. VIBRATION SWITCH CONTACT TO TERMINALS 7 & 9.

NOTE 3: FOR CONTROL BY REMOTE CONTACT, REMOVE JUMPER BETWEEN TERMINALS 6 & 9. CONNECT CONTACT TO TERMINALS 6 & 9.


NOTE 4: J3A & J3B ARE FOR USE OF OPTIONAL COMMUNICATIONS CABLE.

NOTE 5: MOUNT THE COOLING MODULE COMBINATION STARTER AND REMOVE ALL CONTROL WIRES INSIDE THE STARTER. INSTALL CONTROL CONDUIT WITH 5 WIRES. CONNECT WIRES 18 & 10 TO COIL, WIRES 9 & 23 TO AUXILIARY CONTACT, WIRES 9 & 22 TO OVERLOAD CONTACT. CONNECT 5 WIRES TO TERMINALS IN CONTROL BOX. ADJUST CONTROLLER FOR "WATERCOOLED" FAN MODE.

NOTE 6: NO CONNECTION TO 1T1, 1T2 & 1T3.

NOTE 7: TERMINALS 40 & 41 ARE TO BE USED FOR TWO WIRE CONTROL OF REMOTE-MOUNTED STARTER. AN ISOLATED N.O. AUXILIARY CONTACT (DRY CONTACT) MUST BE PROVIDED ON THIS STARTER, WIRING TO TERMINALS 4 & 9.

NOTE 8: INSTALL CT ON ONE PHASE LEAD TO MAIN MOTOR, AND WIRE TO TERMINALS 53 & 54. ADJUST CONTROLLER SFA TO THE MOTOR SERVICE FACTOR AMPS.




MAIN MOTOR	LESS STARTER
FAN MOTOR	REMOTE AIR COOLED
CONTROLLER	ES+
ACCESSORY	CURRENT MONITOR

FIGURE 4-11 - WIRING DIAGRAM

SECTION 5

LUBRICATION

OIL COOLER, OIL FILTER & SEPARATOR



207EAY797-B
(Ref. Drawing)

FIGURE 5-1 - FLOW DIAGRAM - AIR/OIL SYSTEMS

COMPRESSOR OIL SYSTEM (FIGURE 5-1) cools the compressor, lubricates moving parts and seals internal clearances in the compression chamber.

The oil inlet line is connected at the bottom of the oil reservoir. Air pressure in the oil reservoir forces oil through the oil cooler, thermostatic mixing valve, oil filter and into the compressor main oil gallery.

The oil passes through internal passages for lubrication, cooling and sealing. The air-oil mixture is then discharged to the oil reservoir where a large part of the entrained oil drops out of the air stream; the air then passes through the final oil separator where most of the remaining oil is removed. The separated oil is returned to the compressor and the air passes to the final discharge line.

RECOMMENDED LUBRICANT – Gardner Denver compressors are factory filled with AEON lubricants. These lubricants are formulated to the highest quality standards and are factory authorized, tested and approved for use in rotary screw compressors. AEON lubricants are available through your authorized Gardner Denver compressor distributor.

OIL SPECIFICATIONS – The recommended compressor lubricant is Gardner Denver AEON™ 4000 Lubricating Coolant which can be used for year-round operation except as noted in the "High Temperature Operation" paragraph below, or low temperature, see "Installation for Cold Weather", Section 2, page 12. AEON™ 4000 Lubricating Coolant is a superior petroleum base lubricant formulated and containing additives for use in Gardner Denver compressors.

 CAUTION

Use of improper lubricants will cause damage to equipment. Do not mix different types of lubricants or use inferior lubricants.

HIGH TEMPERATURE OPERATION – If the discharge temperature is sustained between 200–210° F for a period of more than four (4) hours due to continuing high ambient air temperature, use Gardner Denver® AEON 9000 SP Lubricating Coolant which is a superior synthetic lubricant. Short periods of up to four (4) hours of sustained discharge temperatures up to 210° F do not require a change from the recommended year-round lubricant AEON™ 4000.

 DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

LUBRICANT CHANGE PROCEDURE – Upgrading to a longer life lubricant is essentially a very worthwhile practice. Following are the primary steps to be completed when upgrading or changing the type of lubricant.

1. Thoroughly drain system:
 - Drain oil from air end and cooler while hot.
 - Break low point connections and drain oil from pipe runs.
 - Dump oil from the filter and reinstall used filter.
2. Fill the system with a 50 percent charge of the new lubricant:
 - Start the machine and stay there to observe.
 - Allow the machine to run about five minutes at temperature, or until temperature stabilizes, then shut down.
3. Thoroughly drain the machine.
4. Change to a new filter and separator.
5. Fill the system with a full charge of the new lubricant.

6. Replace the drain plug before restoring power.
7. Machine should then be run normally, however, total run time after the initial changeout should be 50 percent of normal anticipated service life of the new lubricant.
 - Drain all lubricant from the system, change the filter and separator, and replace with a full charge of the new lubricant.
8. Subsequent lubricant changeouts should be at normal intervals. (See (FIGURE 5–3, page 31.)

 CAUTION

Improper equipment maintenance with use of synthetic lubricants will damage equipment. Oil filter and oil separator change intervals remain the same as for AEON™ 4000 — See Maintenance Schedule, page 42.

 WARNING

High temperature operation can cause damage to equipment or personal injury. Do not repeatedly restart after high temperature stops operation. Find and correct the malfunction before resuming operation.

 WARNING

All materials used in Gardner Denver® compressor units are compatible with AEON™ 9000 SP Lubricating Coolant. Use caution when selecting downstream components such as air line lubricating bowls, gaskets and valve trim.

AEON™ 9000 SP Synthetic Lubricant is not compatible with low nitrile Buna N or acrylic paints. AEON™ 9000 SP is compatible with most air system downstream components.

Material Safety Data Sheets (MSDS) are available for all AEON lubricants from your authorized Gardner Denver distributor or by calling 217-222-5400.

COLD AMBIENT OPERATION – See “Installation for Cold Weather Operation,” page 12.

ADDITION OF OIL BETWEEN CHANGES must be made when the oil level is in the red range on the gauge as read while the unit is on. To add oil, follow these steps:

1. Be sure the unit is completely off and that no air pressure is in the oil reservoir.
2. Disconnect, tag and lockout the power supply to the starter.
3. Wipe away all dirt around the oil filler plug.
4. Remove the oil filler plug and add oil as required to return the oil level to the center of the green range on the gauge.
5. Replace the oil filter plug **BEFORE** restoring power to the unit.

DO NOT OVERFILL. The quantity required to raise the oil level from the red range center of the green range is shown in FIGURE 5-2. Repeated addition of oil between oil changes may indicate excessive oil carry-over and should be investigated.


DANGER

Air/oil under pressure will cause severe personal injury or death. Shut down compressor, relieve system of all pressure, disconnect, tag and lockout power supply to the starter before removing valves, caps, plugs, fittings, bolts, and filters.


DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

Size	Approximate System Capacity (Initial Fill)	Oil Reservoir Capacity** (Refill)	Qty. – Top of ADD to Centerline of RUN
350 HP	Air Cld* – 61 Water Cld – 59	55 55	11 11
400 HP	Air Cld* – 61 Water Cld – 59	55 55	11 11
500 HP	Air Cld* – 61 Water Cld – 59	55 55	11 11

* System capacity shown is for the initial fill of the compressor unit oil cooler module ONLY – remotely mounted oil coolers will require additional oil to fill the piping between the compressor unit and the cooler.

** The oil reservoir refill quantity shown is measured at the centerline of the oil level gauge RUN range or approximately 3.5 inches below the centerline of the oil reservoir.

FIGURE 5-2 – OIL SYSTEM CAPACITIES (APPROXIMATE) – U. S. GALLONS


CAUTION

Excessive oil carry-over can damage equipment. Never fill oil reservoir above the “FULL” marker.

OIL LEVEL GAUGE (FIGURE 1-5, page 3) indicates the amount of oil in the oil reservoir. When the unit is stopped, the oil level will be higher in the RUN range than when operating on load. When the unit is operating, the oil level should be near the center of the RUN range. In normal operation, the oil level will fluctuate slightly as the compressor loads and unloads. Add oil only when the oil level gauge indicated in the ADD OIL range when the compressor is loaded. Drain oil only when the oil level gauge indicates EXCESS OIL when the compressor is loaded.

MOISTURE IN THE OIL SYSTEM – In normal humidity and with normal operating temperatures and pressures, the thermal mixing valve controls the oil temperature and prevents moisture contamination of the oil. Unusual cooling of the oil reservoir, short loaded cycle in high humidity or malfunctions of the thermal valve may result in moisture in the oil system which is detrimental to compressor lubrication and could cause oil carryover. If moisture is observed in the oil reservoir,

drain the moisture and correct the condition causing the accumulation. See “Compressor Oil System Check,” page 38 and “Thermal Control (Thermostatic Mixing) Valve,” page 34.

OIL CHANGE INTERVAL – Recommended oil change intervals are based on oil temperature (see FIGURE 5–3).

When operating conditions are severe (very dusty, high humidity, etc.), it will be necessary to change the oil more frequently. Operating conditions and the appearance of the drained oil must be surveyed and the oil change intervals planned accordingly by the user. A good lubricant analysis program is helpful in planning the change interval.

 **CAUTION**

Change the oil filter every 1000 hours.

DRAINING AND CLEANING OIL SYSTEM

 **DANGER**

Air/oil under pressure will cause severe personal injury or death. Shut down compressor, relieve system of all pressure, disconnect, tag and lockout power supply to the starter before removing valves, caps, plugs, fittings, bolts, and filters.

 **DANGER**

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

Always drain the complete system. Draining when the oil is hot will help to prevent varnish deposits and carry away impurities.

To drain the system, use one of the following methods:

1. If the unit is not elevated high enough to use the oil reservoir drain line to drain oil, a small hand, electric or air operated pump should be used to drain reservoir through the oil filler opening or from the drain valve.
2. If the unit is elevated so that the oil reservoir drain can be used, empty the oil reservoir through the drain valve to a suitable container or sump.
3. If the drained oil and/or the oil filter element are contaminated with dirt, flush the entire system: reservoir, oil cooler, mixing valve and lines.
4. Inspect the oil separator elements for dirt accumulation; replace if necessary. If a varnish deposit exists, contact the factory for recommendations for removal of the deposit and prevention of varnish.

Discharge Temperature	AEON 4000 Change Interval	AEON 9000 SP Change Interval
Up to 180°F (82°C)	4000 hrs.	8000 hrs.
180° to 190°F (82° to 88°C)	3000 hrs.	6000 hrs.
190° to 200°F (88° to 93°C)	2000 hrs.	4000 hrs.
200°F+ (93°C)	1000 hrs.	2000 hrs.

FIGURE 5–3 – OIL CHANGE INTERVAL

FILLING OIL RESERVOIR

DANGER

Air/oil under pressure will cause severe personal injury or death. Shut down compressor, relieve system of all pressure, disconnect, tag and lockout power supply to the starter before removing valves, caps, plugs, fittings, bolts, and filters.

DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

1. Be sure the unit is completely off and that no air pressure is in the oil reservoir.
2. Disconnect, tag and lockout the power supply to the starter.
3. Wipe away all dirt around the oil filler plug.
4. Remove the oil filler plug and add oil as required to return the oil level to the center of the green range on the gauge.
5. Install the oil filler plug and operate the unit for about a minute allowing oil to fill all areas of the system. Check for leaks.
6. Shut down unit, allowing the oil to settle, and be certain all pressure is relieved.
7. Add oil, if necessary, to bring level to the center of the green range on the gauge.

On unloaded operation and after shutdown some oil will drain back into the oil reservoir and the oil level gauge may read in EXCESS OIL range. DO NOT DRAIN OIL TO CORRECT. On the next start, oil will again fill the system and the gauge will indicate the operating level.

COMPRESSOR OIL FILTER (FIGURE 5–4, page 33)
– This replaceable element oil filter is a vital part in maintaining a trouble-free compressor, since it removes dirt and abrasives from the circulated oil. The oil filter relief valve is located in the oil filter head. The relief valve opens in the event the element becomes dirty enough to block the flow of oil.

CAUTION

Element must be replaced every 1000 hours or sooner, or when top of the indicator on the filter is in the red CHANGE FILTER half of the window. Unit must be running and warmed up for indicator to read accurately. Check with light to be certain of indicator position – some lubricants will obscure the indicator.

Use only the replacement element shown on the filter tag or refer to the parts list for the part number. Use the following procedure to replace the filter element. Do not disturb the piping.

DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

DANGER

Air/oil under pressure will cause severe personal injury or death. Shut down compressor, relieve system of all pressure, disconnect, tag and lockout power supply to the starter before removing valves, caps, plugs, fittings, bolts, and filters.

Compressor Main Oil Filter Instructions (Refer to FIGURE 5–4, page 33)

1. Stop the unit and be sure no air pressure is in the oil reservoir. Disconnect, tag and lockout power supply to the starter.
2. To remove head assembly, rotate tee handle (9) counterclockwise until head assembly (1) is free of housing (3).
3. Holding baffle (12) down, push down on indicator assembly (5) to insure that it moves up and down freely within the baffle. Remove baffle (12) and




FIGURE 5-4 – COMPRESSOR OIL FILTER

check its inside bore for burrs or deep scratches and carefully smooth out if required. Check seal (13) for cuts and excess wear.

4. Remove element (6) from housing assembly (3). Remove indicator assembly (5) from element (6) by inserting screwdriver between indicator assembly and element cap and carefully prying downward. Inspect indicator O-ring (4) for cuts or excessive wear and discard element (6).
5. Remove O-ring from head assembly (1) and inspect for cuts or excessive wear. Wipe O-ring area of head (1) with clean cloth and after covering O-ring (2) with oil, reinstall in head assembly.
6. Reinstall indicator assembly (5) into new element (6). Place element into cannister (3), making sure that large diameter of spring (8) contacts the new element, and install baffle (12).
7. Place head assembly (1) onto housing assembly

(3) and rotate tee handle (9) clockwise until hand tight; do not exceed 20 foot-pound torque if tools are used.

8. Reconnect starter to power source.
9. If leakage appears around tee handle (9) remove snap ring (11) and remove tee handle (9) from head assembly (1). Remove O-ring (10) and inspect for nicks or cuts and replace if necessary. Wipe tee handle (9) and O-ring groove. Then oil and replace O-ring (10), insert tee handle (9) into head assembly (1) and replace snap ring (11).

BEARING OIL FILTER – An oil filter of the spin-on type is used. This filter is a vital part in maintaining a trouble-free compressor, since it removes dirt and abrasives from the circulated oil before it reaches the bearings. The filter is the disposable type and is equipped with a relief valve that opens in the event the element becomes dirty enough to block the flow of oil. **The filter must be replaced each time the main oil filter element is replaced.** When changing this filter between oil changes, add one (1) quart of lubricant to the system to replace that retained in the old filter. Use only the replacement filter shown in the parts list, as others may not have sufficient burst pressure strength.

To replace filter, stop the unit and be sure no air pressure is in the oil reservoir. Disconnect, tag and lockout power supply to the starter. Spin off the old filter and discard, then spin on the new filter by hand, tightening firmly enough to prevent leaks.

COMPRESSOR OIL COOLER – RADIATOR TYPE (FIGURE 5-5) – The air-cooled oil cooler module is remote mounted. The oil cooler requires pipe and electri-




FIGURE 5-5 – OIL FLOW DIAGRAM – REMOTE OVERHEAD MOUNTED OIL COOLER

cal connection to the main compressor unit. Connecting piping and wiring are furnished by the user. See "Installation", Section 2, page 8.

Do not obstruct the air flow to and from the oil cooler. Allow two (2) feet clearance on all sides of the oil cooler. See FIGURE 2-2, Section 2, page 8, for cooling air flow requirements. Keep both faces of the oil cooler core clean for efficient cooling of the compressor oil. Oil cooler malfunctions may be traced by checking oil pressure drop through the cooler; check by installing pressure gauges at fittings in the inlet and outlet oil piping near the end of the cooler. At normal operating air service pressures (65 to 150 psig), with the unit warm, a pressure drop of 2 to 25 psig can be expected between the inlet and outlet side of the cooler. The controller will show the reservoir temperature which is the air temperature in the reservoir and the approximate oil temperature into the thermal mixing valve.

An oil filler stand pipe and plug must be located in the piping on the oil cooler module for ease of filling the oil cooler when it is mounted at a distance from the compressor unit. When filling a remotely mounted oil cooler, be sure all lines to and from the compressor unit are also filled to prevent excessive drawdown of the oil supply in the oil reservoir. A vent line should be installed between the oil cooler and compressor oil reservoir as an aid in filling and to prevent siphoning.

HEAT EXCHANGER (OIL) PIPING – All remote elevated cooler applications must be sent through Engineering for approval and for recommending the pipe size. A special control group will be mounted on the package at the factory. This group controls the oil stop valve as well as not allowing the machine to run unloaded. Kit number EAU68133 includes the oil stop valve, check valve and flanges and must be installed on all remote elevated coolers per FIGURE 5-5, page 33, and the following instructions.

NOTICE

Remote mounted elevated coolers have a maximum pipe length of 30 feet (each way) and a maximum height of 20 feet with a minimum of fittings. Engineering will review all remote elevated cooler applications and recommend pipe size on an individual basis. Customer Service should include the engineering recommendation in the special order sent to Engineering.




FIGURE 5-6 – THERMOSTATIC MIXING VALVE ELEMENT

1. Mount the check valve (90J113).
2. Mount the drain valves in the lowest section of the pipe on each side of the cooler connections.
3. Mount the oil stop valve (90AR243) in the line after the thermal mixing valve as shown.

Modifications to the control lines will be made at the factory to control the oil stop valve. Air to the oil stop valve must come from the dry side of the reservoir cover, then through the 3-way pneumatic valve. Control air to the valve must come from the line between the tee and the orifice in the blowdown muffler line. When the machine blows down, it will activate the pneumatic valve which will shut off the air and vent the line between the pneumatic control valve and the oil stop valve to the atmosphere. This will shut the oil stop valve and prevent excessive oil from running into the reservoir. Failure to install these parts could result in high oil carryover and cause the machine to shutdown on high discharge temperature.

THERMAL CONTROL (THERMOSTATIC MIXING) VALVE (FIGURE 5-6) on current units is installed in the system as shown in FIGURE 5-1, page 28. This valve is used to control temperature of the oil in both air-cooled radiator and water-cooled heat exchanger type oil cooler systems. The element is so designed that a portion of the oil can flow through the oil cooler at all times. On start-up with unit cold, element is open to bypass, allowing oil to pass directly from the reservoir to compressor during warm-up. As oil warms, element gradually closes to the bypass allowing more of




FIGURE 5-7 – WATER CONTROL VALVE

the oil from the cooler to mix with oil from the bypass. After the unit is warmed up, the mixing valve maintains oil injection temperature into the compressor at a minimum of 150° F (66° C). This system provides proper compressor warm-up and helps prevent moisture contamination of oil.

To check element, heat in oil – it should be fully extended at 150° F (66° C). If unit shuts down due to high air discharge temperature, the cause may be that the element is stuck open to the bypass, in which case lines 1 and 2 (FIGURE 5-1, page 28) will be hot to touch and lines 3 and 4 much cooler. When flushing the oil system, remove mixing valve and clean all parts thoroughly.

COMPRESSOR OIL COOLER – WATER-COOLED HEAT EXCHANGER (FIGURE 1-2, page 2) – The heat exchanger oil cooler is a multiple pass type, with water in the tubes and oil in the shell. The oil temperature is controlled by the thermal (thermostatic mixing) valve. The optional water control valve may be used to conserve water.

WARNING

It is mandatory that any water cooled unit be installed in a shelter heated to temperatures above freezing (32° F, 0° C).




FIGURE 5-8 – DEW POINT TEMPERATURE VS. AMBIENT TEMPERATURE (100% RELATIVE HUMIDITY)

Oil cooler malfunction may be traced by checking pressure at oil inlet and outlet. At normal operating air service pressure (65 to 150 psig) with the unit warm, a pressure drop of 3 to 15 psi can be expected between the oil inlet and the oil outlet.

Water pressure drop from water inlet to outlet will vary with the inlet pressure and amount of water flowing. A normal pressure drop may range from 5 to 10 psi. Any change in the pressure drop from that normally held may indicate tube leakage or fouling and should be investigated.

In many instances, the cooling water supply for the heat exchanger will contain impurities in solution and/or suspension. These substances can cause scale formation, corrosion and plugging of any water-cooled heat exchanger equipment. Disregarding the possibility that one or more of these conditions exist may result in increased maintenance and operation expense, reduced equipment life and emergency shutdown. It is strongly recommended that a reputable, local water treatment concern be engaged to establish the corrosion, scale forming and fouling tendency of the cooling water and take steps necessary to remedy the situation if a problem does exist. The need for water treatment may involve only filtration (screening) to remove debris, sand and/or salt in the cooling water supply. However, chemical treatment methods may be necessary in certain instances to inhibit corrosion and/or remove dissolved solids, to alter the water's tendency to form scale deposits, or prevent the growth of microorganisms. The normal maintenance program for the unit should also include periodic cleaning of the tubes (wa-

ter side) of the heat exchanger to remove deposits which enhance fouling and corrosion.

Hex head zinc anodes are used in the return bonnet (opposite end to the water pipe connections) of heat exchangers to provide internal water system corrosion protection. These anodes should be inspected periodically and replaced when the zinc has been reduced to about 1/2 inch in length.

WATER FLOW CONTROL VALVE FOR HEAT EXCHANGER (Optional Equipment) (FIGURE 5-7, page 35) – The water flow control valve is adjustable to compensate for varying water inlet temperatures and pressures (thermal control valve prevents settings below approximate 180° F.) Use the discharge air temperature gauge on the instrument panel in setting flow control valve for minimum water usage to maintain discharge temperature at a minimum of 10° F above dew point at the maximum anticipated ambient; refer to FIGURE 5-8, page 35, for the dew point temperature at the operating pressure and ambient temperatures.

To decrease water flow (increase compressor discharge air temperature) turn the adjusting screw from left to right, increasing spring tension. **To increase water flow** (decrease compressor discharge air temperature) turn the adjusting screw in the opposite direction. The groove at the lower edge of the adjusting screw is an index line for use with the index scale 0 to 8 in obtaining a desired setting.

These valves must be handled with care and proper tools and techniques must be used when working on the valve.

Care must be used when handling the capillary tube; a kink or break in the tubing or connections will make the valve inoperative. Never attempt to change capillary length. Excess capillary tube should be carefully coiled and placed so that damage will not occur in normal maintenance or traffic past the unit.

If a leak develops through the packing, tighten the packing gland nut firmly with a wrench to reseal the packing around the valve stem, then back off the nut until loose, and finally retighten the nut finger tight. Tightening the packing nut too tight may cause erratic operation. An occasional drop of oil on the valve stem at the packing nut will prolong packing life.

If valve malfunctions, check for bent or binding, paint or corrosion on valve stem, foreign material in valve, erosion, or thermal system (capillary) failure. If foreign material or scale is likely, the use of a strainer in the inlet water line is recommended.

WATER SHUTOFF VALVE – WATER-COOLED HEAT EXCHANGER (Optional Equipment) (FIGURE 5-1, page 28) – A magnetic solenoid-oper-




FIGURE 5-9 – SINGLE ELEMENT OIL SEPARATOR

ated water shutoff valve rated at 150 psig water pressure should be mounted in the water outlet line after the oil cooler. The valve should be wired into the compressor control circuit in such a manner that the valve opens to allow water to flow any time the ON-OFF push button is ON and the compressor is running. When the compressor stops under automatic control, or is shut off manually, the valve should close, stopping water flow through the system.

OIL RESERVOIR – The oil reservoir-separator combines multiple functions into one vessel. The lower half is the oil reservoir, providing oil storage capacity for the system and the top portion, a primary oil separation means. The reservoir also provides limited air storage for control and gauge actuation.

COMPRESSOR OIL SEPARATOR located in a separate housing, consists of a renewable cartridge-type separator element and provides the final removal of oil from the air stream. Oil from inside the separator elements is returned through tubing to the compressor cylinder. (FIGURE 5-9).

Oil carryover through the service lines may be caused by a faulty oil separator, faulty minimum pressure valve, over-filling of the oil reservoir, oil that foams, oil return line malfunction or water condensate in the oil. If oil carryover occurs, inspect the separator only after it is determined that the oil level is not too high, the oil

is not foaming excessively, the oil return line from the separator housing to the compressor cylinder is not clogged or pinched off, the check valve in the oil return line is functioning properly, and there is not water or an oil/water emulsion in the oil.

Oil carryover malfunctions of the oil separator are usually due to using elements too long, heavy dirt or varnish deposits caused by inadequate air filter service, use of improper oil or using oil too long for existing conditions. A ruptured or collapsed separator element is usually due to heavy dirt or varnish buildup in the filtering material. Excessive tilt angle of the unit will also hamper separation and cause oil carryover.

Oil separator element life cannot be predicted; it will vary greatly depending on the conditions of operation, the quality of the oil used and the maintenance of the oil and air filters. The condition of the separator can be determined by pressure differential gauging or by inspection.

Pressure Differential Gauging – The “CHANGE SEPARATOR” advisory will flash when the pressure differential across the oil separator reaches approximately 8 PSI. Replace the oil separator element at this time. If ignored, the unit will shut down and the advisory will illuminate steadily when the pressure differential reaches 15 PSI.



CAUTION

Using an oil separator element at excessive pressure differential can cause damage to equipment. Replace the separator when the “Change Separator” advisory appears.

NOTICE

A sudden drop of zero pressure differential or sudden heavy oil carryover may indicate a ruptured element.

Inspection – After removal of separator element, shine a light inside the element to reveal areas of heavy dirt or varnish deposits or breaks (ruptures) in the element media.

Removal Of Oil Separator For Inspection Or Replacement:



DANGER

Air/oil under pressure will cause severe personal injury or death. Shut down compressor, relieve system of all pressure, disconnect, tag and lockout power supply to the starter before removing valves, caps, plugs, fittings, bolts, and filters.



DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

1. Be certain unit is completely off and that no air pressure is in the oil reservoir.
2. Disconnect, tag and lockout power supply to the starter.
3. Disconnect oil return to compressor tubing at tube elbow near the discharge manifold flange on the top plate.
4. Loosen the nut on fitting at manifold flange and completely withdraw the tubing through the fitting.
5. Disconnect all other tubing from discharge manifold.
6. Disconnect discharge manifold pipe union.
7. Remove screws holding the top plate to the oil reservoir. Lift the top plate from the oil reservoir.
8. Lift the separator from the separator housing.
9. Inspect and/or replace the separator as necessary. Before installing (or reinstalling) any separator be sure gaskets bonded to the separator flanges are not damaged. Remove the gasket material adhering to the top plate or reservoir flange from the old separator.
10. Lower the separator into the oil reservoir.
11. Seat the top plate to the oil reservoir flange; install and tighten all cap screws.
12. Reconnect the discharge manifold pipe union and all tubing.

13. Install original oil return by slipping tube through the fitting at the discharge manifold flange until ferrule bottoms in the fitting. If a new fitting and return tube are used, slip the tube through the fitting until it touches the bottom of the separator, then raise the tube about 1/4 inch off the bottom and tighten the fitting nut securely. Connect the other end of the tube to the compressor oil return tube elbow. Do not bend tube or raise tube further than 1/4"–1/2" from the bottom of the separator.
14. Reconnect compressor oil return tube to tube elbow.

COMPRESSOR OIL SYSTEM CHECK – The compressor should be at operating temperature at the time of the checks. On–half hour of loaded operation is usually sufficient to reach level–out operating temperatures. The data shown below is for an oil–system in good condition.

If the unit will operate at discharge temperatures over 200° F for more than 4 consecutive hours, refer to the "High Temperature Operation" paragraph and select a lubricant for this service. Regardless of level of sustained discharge temperature, the high discharge air temperature switch must never be set higher than 225° F shutdown temperature.

Air and Oil Discharge Temperature – Check with a thermometer in the tapped opening on top of the compressor discharge pipe to the oil reservoir.

For **Air Cooled Oil Systems**, FIGURE 5–10 shows the normal upper limit of discharge temperatures for varying ambient temperatures beginning at the system design point of 80° F. At ambient temperatures below 80° F, the mixing valve will hold the discharge temperature at the 80° F ambient temperature point. Above 80° F, the oil cooler is fully used and the discharge temperature varies degree for degree with the ambient temperature.

For **Water Cooled Oil Systems**, the water flows at various temperatures outlined in Section 2 will hold the discharge temperature below the 80° F ambient tempera-

ture level of FIGURE 5–10. Small variations in specific water flows or temperatures will not be noted in the discharge temperature since the water control valve will tend to hold a constant oil temperature. A significant change in the discharge temperature is cause to check for a change in water flow or temperature.

Oil Inlet Pressure – Check at the fitting in the line near the compressor oil inlet. With air receiver pressure at 100 psi, oil inlet pressure should be 75–85 psig.

Oil Cooler Oil Pressure Differential (Air–Cooled Radiator) – 2 to 25 psi (65 to 150 PSIG Receiver Pressure) – Check at the fitting in the inlet and outlet lines of the oil cooler.

Oil Cooler Oil Pressure Differential (Water–Cooled Heat Exchanger) – 2 to 25 PSI (65 to 150 PSIG Receiver Pressure) – Check at the heat exchanger oil inlet and outlet fittings.

Oil Cooler Temperature Differential (Air–Cooled Radiator) – The oil temperature differential depends on the temperature of the air at the oil cooler fan and cleanliness of core faces. As ambient temperatures and core restrictions increase, the oil cooler outlet temperature will increase. The inlet oil temperature may be checked at the fittings in the oil inlet line on the oil cooler module. The outlet oil temperature may be checked at the fitting in the oil outlet line.

Oil Cooler Temperature Differential (Water–Cooled Heat Exchanger) – The oil temperature differential depends on the inlet water temperature and the water flow rate permitted by the water flow control valve setting. The oil inlet temperature is approximately the same as the air discharge temperature – see the gauge on the instrument panel. The oil outlet temperature may be checked at the compressor oil inlet line fitting.

Oil Cooler Water Pressure Differential (Water–Cooled Heat Exchanger) – The water pressure differential through the heat exchanger will depend on the supply pressure, flow rate, cooler tube cleanliness and outlet pressure. The inlet and outlet water pressure may be checked at the pipe fittings supplied by the customer.

Ambient Temperature (°F.)		80	90	100
350 HP	Discharge Temperature ° F	171	181	191
400 HP		175	185	195
500 HP		184	194	204*

* For temperatures above 200 F see "High Temperature Operation".

FIGURE 5–10 – AMBIENT TEMPERATURES

SECTION 6

AIR FILTERS

AIR FILTER – The air filter furnished as standard equipment is a panel type washable filter. The air filter must receive proper maintenance if maximum service is to be obtained from the unit. Establishing adequate and timely filter service is MOST IMPORTANT. With wide variation of dust conditions encountered, only experience can determine the proper time element for servicing filters. Although a paper filter element is normally considered expendable, proper and careful cleaning can extend its original life several times.

Filter Element – Service the air filter element when the “CHANGE AIR FILTER” LED is illuminated. Clean every 50 to 150 operating hours depending on dust conditions.

To service:

Remove louvered filter cover and filter element by removing the six (6) cover to enclosure screws.

Two methods of cleaning are recommended. Use of compressed air is effective when the major contaminant is dust. Washing is effective on carbon, soot, and oil laden elements.

DO NOT ATTEMPT TO CLEAN ELEMENTS BY BEATING OR RAPPING.

When air is used, direct a jet of air (100 PSI maximum) against the clean air side of the element in the opposite direction of normal air flow. Move the air jet up and down the pleat, slowly moving across the face of the element. The nozzle must be kept at least one inch away from the element. Take care that the paper is not ruptured by the nozzle or air jet.

When cleaning by washing, use a good non-sudsing detergent and water. Soak the element in a solution of two (2) ounces of detergent per gallon of water (140°F maximum) for at least 15 minutes. Swish the element around in the solution (2 minutes) to help remove dirt. Warm solution gives best results. Rinse the element with a stream of water (40 PSI maximum) opposite to normal air flow until rinse water is clear. **DRY THE ELEMENT THOROUGHLY BEFORE USING. DO NOT USE LIGHT BULBS FOR DRYING.** Warm air (160° F or less) must be circulated as high surface temperatures can burn or scorch the filter paper.

After cleaning, thoroughly inspect the element for dirt on the clean air side, holes or damage, by looking through the element toward a bright light. Do not reuse damaged elements.

Filter Element Life – The element should be replaced after six (6) cleanings or if:

1. Visual inspection indicates a rupture, crack or pin hole in the pleated media. Inspection should be done by placing a bright light inside the element.
2. Pressure drop through a filter with a freshly cleaned element is below three (3) inches of water with the compressor running at full load – this would indicate a rupture or crack.

NOTICE

Use only genuine Gardner Denver air filter elements on Gardner Denver compressor units. Genuine parts are available through your authorized Gardner Denver distributor.


WARNING

Do not oil this element. Do not wash in inflammable cleaning fluids. Do not use solvents other than water. Improper cleaning may damage the element.

NOTICE

Never operate the unit without the element. Never use elements that are damaged, ruptured or wet. Never use gaskets that won't seal. Keep spare elements and gaskets on hand to reduce downtime. Store elements in a protected area free from damage, dirt and moisture. Handle all parts with care.

HEAVY-DUTY AIR FILTER – 350 & 400 HP UNITS (FIGURE 6–1, page 40) – When heavy-duty air filters are specified for the 350 & 400 HP units, they will be a



C74831

FIGURE 6-1 – HEAVY DUTY AIR FILTER

two-stage dry type. When the unit has been so equipped, service the filters as follows:

Dust Cup – Service every 4 to 120 hours depending on dust conditions. To service, loosen the retaining band clamp and remove the dust cup. Do not wash the dust cup – wipe clean with a clean dry cloth. Do not bend the edge of the cup by striking on a hard surface. When installing the dust cup, make sure the clamp is securely tightened to prevent leakage.

Filter Element – Service the air filter element when the “CHANGE AIR FILTER” LED is illuminated. Clean every 50 to 150 operating hours depending on dust conditions.

To service:

1. Loosen the retaining band clamp and remove the dust cup from the body of the filter.
2. Visually inspect the element in place. If cleaning is not necessary, reinstall the dust cup on the filter. If the element requires cleaning, unscrew the wing bolt and withdraw the element from the body.
3. Wash the element by soaking about 15 minutes in warm water with a mild detergent. Rinse the element thoroughly with clean water; a hose may be used if the water pressure does not exceed 40 psig.
4. Inspect the element for ruptures or cracks in the pleated media; replace the element if any are found. Inspect the gasket on the bottom (outlet end) of the element; replace the entire element if the gasket is damaged.
5. Allow the element to air dry **COMPLETELY**. Do not expose the element to heat over 150° F. Install the element in the filter body and fasten securely with the wing bolt. Reinstall the dust cup and retaining band clamp. Make sure the clamp is tightened securely to prevent leakage.

Filter Element Life – The element should be replaced after six (6) cleanings or if:

1. Visual inspection indicates a rupture, crack or pin hole in the pleated media. Inspection should be done by placing a bright light inside the element.
2. Pressure drop through a filter with a freshly cleaned element is below three (3) inches of water with the compressor running at full load – this would indicate a rupture or crack.

Inlet Tube – Inspect the inlet screen and tube for dirt accumulation each time the filter is serviced. Clean the tube when required by ramming a clean dry cloth through the tube. Wipe the inside of the filter body to remove any dirt falling from the inlet tube before reinstalling the element.

Causes of short element life include: severe dust conditions, infrequent servicing, improper cleaning, or contamination by oil or chemical fumes.

NOTICE

Use only genuine Gardner Denver air filter elements on Gardner Denver compressor units. Genuine parts are available through your authorized Gardner Denver distributor.

⚠ WARNING

Do not oil this element. Do not wash in inflammable cleaning fluids. Do not use solvents other than water. Improper cleaning may damage the element.

NOTICE

Never operate the unit without the element. Never use elements that are damaged, ruptured or wet. Never use gaskets that won't seal. Keep spare elements and gaskets on hand to reduce downtime. Store elements in a protected area free from damage, dirt and moisture. Handle all parts with care.

SECTION 7 COUPLING




FIGURE 7-1 – INSTALLATION OF COUPLING – STYLE “A”




FIGURE 7-2 – INSTALLATION OF COUPLING – STYLE “B”

COUPLING – The motor and compressor are direct connected by a flexible coupling. Style “A” coupling has several individual cushions, (FIGURE 7-1). Style “B” has a two piece split sleeve, (FIGURE 7-2).

cushions and secure with cap screws. Reinstall the cover plate.

FOR STYLE “B” COUPLING:

DANGER

Rotating machinery can cause personal injury or death. Turn the unit completely off, open the main disconnect, tag and lockout before servicing the coupling.

DANGER

Rotating machinery can cause personal injury or death. Do not operate unit with either the coupling guard or the collar removed. All bolts and screws must be properly tightened.

If maintenance on mating parts is required, reassemble coupling as follows:

1. Slide coupling halves over shaft extensions. Be sure the collar is installed on the shaft behind one coupling body.
2. Assemble the motor to the compressor.

FOR STYLE “A” COUPLING:

- a. Working through the cover plate opening, center coupling halves over the gap between the shafts, maintaining the gap as shown in FIGURE 7-1 between the ends of the jaws on one coupling body and the flange on the opposite coupling body. Tighten set screws in each coupling body.
- b. Insert individual cushions as shown in FIGURE 7-1 and slide the collar over the

- a. Working through coverplate, center coupling halves over the gap in the shafts. Secure short hub half of the coupling to the shaft by tightening the set screws over the shaft key and 90° to the key.
- b. Assemble halves of split sleeve into the teeth of the short hub half of the coupling.
- c. Slide the long hub over the split sleeve teeth until the sleeve is bottomed in both hubs; back long hub off 1/16 inch.
- d. Secure the long hub in position by tightening the socket head cap screw through the split section of the hub; tighten the set screw over the shaft key.

Alignment – The coupling is permanently aligned by the flanges on the compressor and motor.

SECTION 8 MAINTENANCE SCHEDULE

SERVICE CHECK LIST –

Air Filter – Operating conditions determine frequency of service. If the “CHANGE AIR FILTER” message is displayed, air filter requires servicing or changing. See “Air Filter,” Section 6, page 39.

Oil Separator – Operating conditions determine frequency of service. If the “CHANGE SEPARATOR” message is displayed, the oil separator element requires changing. See “Compressor Oil Separator” in Section 5, page 36, for further details.

Motor Lubrication – Refer to Section 2, page 15, and Maintenance Schedule Chart below.

Every 8 Hours Operation

1. Check the reservoir oil level – add oil if required. See Section 5, page 30. If oil consumption is high, refer to “Excessive Oil consumption, page 44. DO NOT MIX LUBRICANTS.
2. Observe if the unit loads and unloads properly.
3. Check discharge pressure and temperature.
4. Drain the moisture trap in the control system.
5. Check Panel LED’s for advisories.

Every 125 Hours Operation

1. Check for dirt accumulation on oil/aftercooler core faces and the cooling fan. If cleaning is required, clean the exterior fin surfaces of the cores by blowing compressed air carrying a nonflammable safety solvent in a direction opposite that of the cooling fan air flow. This cleaning operation will keep the exterior cooling surfaces clean and ensure effective heat dissipation.

Every 1000 Hours Operation

1. Change the oil filter element.

Every 4000 Hours Operation

1. Change the compressor lubricant. UNDER ADVERSE CONDITIONS, CHANGE MORE FREQUENTLY (refer to “Oil Change Interval”, page 31). Flush system if required.

Every Year

1. Check the relief valve for proper operation. See Section 4, page 18.

MAINTENANCE SCHEDULE (See detail notes above)

Maintenance Action

	As Indicated By Auto-Sentry® Controller	Every 8 Hours	Every 125 Hours	Every 1000 Hours	Every 4000* Hours	Every Year
Change Air Filter	•					
Change Oil Separator	•					
Check Reservoir Oil Level		•				
Check For Proper Load/Unload		•				
Check Discharge Pressure/Temp		•				
Check Dirt Accumulation on Cooler			•			
Change Oil Filter Element	•			•		
Change Compressor Lubricant (AEON 4000)	•				•	
Check Relief Valve						•

* See Oil Change Interval Chart, FIGURE 5–3, Page 31, for specific lubricant life.

SECTION 9

TROUBLE SHOOTING

SYMPTOM	POSSIBLE CAUSE	REMEDY
Compressor fails to start.	1. Wrong lead connections. 2. Blown fuses in control box. 3. Motor starter overload heaters tripped. 4. Pressure in reservoir. 5. Read error message on control panel. 6. Remote Contact is open (terminals 6 & 9).	1. Change leads. 2. Replace fuse. 3. Reset and investigate cause of overload. 4. Inspect blowdown valve and muffler. 5. Take appropriate action. See Section 4. 6. Replace switch or jumper.
Compressor starts but stops after a short time.	1. High discharge temperature. 2. High discharge temperature switch malfunction. 3. Blown fuse in starter/control box. 4. Motor starter overload heaters trip.	1. See "High Discharge Air Temperature," this section, page 44. 2. Replace switch. 3. Replace fuse (investigate if fuses continue to blow). 4. Reset and investigate cause of overload.
Compressor does not unload (or load).	1. Improperly adjusted control. 2. Air leak in control lines. 3. Restricted control line. 4. Blowdown valve malfunction.	1. Refer to manual 13-9/10-641 and adjust control. 2. Determine source of leak and correct. 3. Clean control lines. 4. Repair, clean or replace valve.
Compressor cycles from load to unload excessively.	1. Insufficient receiver capacity. 2. Restriction in control tubing.	1. Increase receiver size. 2. Inspect and clean control tubing.

SYMPTOM	POSSIBLE CAUSE	REMEDY
Compressor is low on delivery and pressure.	1. Restricted air filter. 2. Sticking inlet valve. 3. Unload pressure adjusted too low. 4. Minimum pressure valve stuck closed. 5. Turn valve adjustment or malfunction.	1. Clean or replace filter. 2. Inspect and clean inlet valve. 3. Adjust the unload pressure. See Section 4, page 21. 4. Disassemble and clean valve. 5. Adjust turn valve per Section 4, page 21.
High discharge air temperature.	1. Thermostatic mixing valve stuck open. 2. Dirty or clogged cooler face. 3. Insufficient cooling air flow. 4. Clogged oil filter or cooler (interior). 5. Low compressor oil.	1. Repair or replace valve. 2. Clean cooler. 3. Provide unrestricted supply of cooling air. 4. Replace filter or clean cooler. 5. Add oil to proper level.
Excessive Oil Consumption	1. Oil carryover through lines. 2. Oil leaks at all fittings and gaskets.	1. See "Oil Carryover", below. 2. Tighten or replace fittings or gasket.
Oil Carry-Over	1. Overfilling the reservoir.	1. Drain excess oil from system.

 DANGER

Air/oil under pressure will cause severe personal injury or death. Shut down compressor, relieve system of all pressure, disconnect, tag and lockout power supply to the starter before removing valves, caps, plugs, fittings, bolts, and filters.

 DANGER

Compressor, air/oil reservoir, separation chamber and all piping and tubing may be at high temperature during and after operation.

SYMPTOM	POSSIBLE CAUSE	REMEDY
Oil Carry-Over (Continued)	2. Clogged, broken or loose oil return lines 3. Ruptured oil separator element. 4. Loose assembly. 5. Foam caused by use of incorrect oil. 6. Inoperative minimum pressure valve, causing low operating pressure. 7. Operation at elevated discharge temperatures. 8. Scavenge line check valve failure. 9. Water condensate in oil.	2. Tighten or replace faulty lines. 3. Replace element. 4. Tighten all fittings and gaskets. 5. Use Gardner Denver® AEON™ 4000 or AEON™ 9000 SP Lubricating Coolant. 6. Clean out or replace valve. 7. Reduce temperature. See High Discharge Air Temperature, page 44, this section. 8. Replace check valve. 9. Check oil reservoir temperature and if low, change thermal mixing valve element to higher temperature.

NOTICE

Gardner Denver factory remanufactured replacement compressor air end units are available from your authorized distributor, on an exchange basis, for all rotary screw compressor units.

GENERAL PROVISIONS AND LIMITATIONS

Gardner Denver Machinery Inc. (the "Company") warrants to each original retail purchaser ("Purchaser") of its new products from the Company or its authorized distributor that such products are, at the time of delivery to the Purchaser, made with good material and workmanship. No warranty is made with respect to:

1. Any product which has been repaired or altered in such a way, in the Company's judgment, as to affect the product adversely.
2. Any product which has, in the Company's judgment been subject to negligence, accident, improper storage, or improper installation or application.
3. Any product which has not been operated or maintained in accordance with the recommendations of the Company.
4. Components or accessories manufactured, warranted and serviced by others.
5. Any reconditioned or prior owned product.

Claims for items described in (4) above should be submitted directly to the manufacturer.

WARRANTY PERIOD

The Company's obligation under this warranty is limited to repairing or, at its option, replacing, during normal business hours at an authorized service facility of the Company, any part which in its judgment proved not to be as warranted within the applicable Warranty Period as follows.

COMPRESSOR AIR ENDS

Compressor air ends, consisting of all parts within and including the compressor cylinder and gear housing, are warranted for 24 months from date of initial use or 27 months from date of shipment to the first purchaser, whichever occurs first.

Any disassembly or partial disassembly of the air end, or failure to return the "unopened" air end per Company instructions, will be cause for denial of warranty.

OTHER COMPONENTS

All other components are warranted for 12 months from date of initial use or 15 months from date of shipment to first purchaser, whichever occurs first.

LABOR TRANSPORTATION AND INSPECTION

The Company will provide labor, by Company representative or authorized service personnel, for repair or

replacement of any product or part thereof which in the Company's judgment is proved not to be as warranted. Labor shall be limited to the amount specified in the Company's labor rate schedule.

Labor costs in excess of the Company rate schedule amounts or labor provided by unauthorized service personnel is not provided for by this warranty.

All costs of transportation of product, labor or parts claimed not to be as warranted and, of repaired or replacement parts to or from such service facilities shall be borne by the Purchaser. The Company may require the return of any part claimed not to be as warranted to one of its facilities as designated by Company, transportation prepaid by Purchaser, to establish a claim under this warranty.

Replacement parts provided under the terms of the warranty are warranted for the remainder of the Warranty Period of the product upon which installed to the same extent as if such parts were original components.

DISCLAIMER

THE FOREGOING WARRANTY IS EXCLUSIVE AND IT IS EXPRESSLY AGREED THAT, EXCEPT AS TO TITLE, THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY.

THE REMEDY PROVIDED UNDER THIS WARRANTY SHALL BE THE SOLE, EXCLUSIVE AND ONLY REMEDY AVAILABLE TO PURCHASER AND IN NO CASE SHALL THE COMPANY BE SUBJECT TO ANY OTHER OBLIGATIONS OR LIABILITIES. UNDER NO CIRCUMSTANCES SHALL THE COMPANY BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOSSES OR DELAYS HOWSOEVER CAUSED.

No statement, representation, agreement, or understanding, oral or written, made by any agent, distributor, representative, or employee of the Company which is not contained in this Warranty will be binding upon the Company unless made in writing and executed by an officer of the Company.

This warranty shall not be effective as to any claim which is not presented within 30 days after the date upon which the product is claimed not to have been as warranted. Any action for breach of this warranty must be commenced within one year after the date upon which the cause of action occurred.

Any adjustment made pursuant to this warranty shall not be construed as an admission by the Company that any product was not as warranted.



For additional information contact your local representative or
Gardner Denver Machinery Inc., Customer Service Department,
1800 Gardner Expressway, Quincy, Illinois 62301
Telephone: (800) 682-9868 FAX: (217) 224-7814



Sales and Service in all major cities.

For parts information, contact Gardner Denver,
Master Distribution Center, Memphis, TN
Telephone: (800) 245-4946 FAX: (901) 542-6159

Specifications subject to change without notice.
Copyright 1996 Gardner Denver Machinery Inc.

Litho in U.S.A.