



GARDNER-DENVER®

13-9-634
1st Edition

**ELECTRA-SAVER II®
STATIONARY
BASE-MOUNTED
COMPRESSOR**

Models

40 HP

ECHQHE, ECHSHE

50 HP

ECHQJE, ECHSJE

Service Manual

13-9-634



INDUSTRIAL MACHINERY



GARDNER-DENVER®

WARRANTY

ROTARY SCREW COMPRESSORS EC ELECTRA-SAVER II® EA ELECTRA-SAVER® EB, ET ELECTRA-SCREW® SE, ST PACKAGES

A warranty registration card is provided with each machine. The card must be completed by the purchaser and mailed (card is preaddressed and postage paid) within ten days after machine start up in order to validate this warranty.

Gardner-Denver/Industrial Machinery Division (the "Company") warrants to each original retail purchaser ("Purchaser") of its products from the Company or its authorized distributors that such products will be free from defects in material and workmanship caused by Company and shall be warranted as follows:

BASIC COMPRESSOR AIR ENDS

Basic compressor air ends, consisting of all parts within and including the compressor cylinder and gear housing, are warranted for 24 months from date of initial use or 27 months from date of shipment to the first purchaser, whichever occurs first.

The Company will furnish, at its option, air end repairs, a remanufactured replacement air end, or a new replacement air end, FOB factory for any air end which in its judgment proved not to be as warranted within the applicable period.

Purchaser must return, transportation charges prepaid, any air end claimed to be not as warranted to a Gardner-Denver factory. Any disassembly or partial disassembly of the air end, or failure to return the "unopened" air end per Company instructions, will be cause for denial of warranty.

ELECTRIC MOTORS

Electric motors, when specified and furnished by the Company, are warranted for 12 months from date of initial use or 15 months from date of shipment to the first purchaser, whichever occurs first.

The motor manufacturer or authorized service shop will provide at its option, motor repairs or replacement motor FOB manufacturer's location for any motor which in the manufacturer's judgment proves not to be as warranted within the applicable period.

ENGINES

Engines are warranted to the extent of the original manufacturer's warranty to the Company.

OTHER COMPONENTS

All other components are warranted for 12 months from date of initial use or 15 months from date of shipment to first purchaser, whichever occurs first.

The Company will furnish at its option FOB Company location repairs or replacement parts for any component which in the Company's judgment proved not to be as warranted within the applicable period.

GENERAL PROVISIONS AND LIMITATIONS

No warranty is made with respect to:

1. Any product which has been repaired or altered in such a way, in the Company's judgment, as to affect the product adversely.
2. Any product which has, in the Company's judgment been subject to negligence, accident, improper storage, or improper installation or application.

3. Any product which has not been operated or maintained in accordance with normal practice and with the recommendations of the Company.

4. Components or accessories manufactured, warranted and serviced by others, except as separately rated.

5. Any reconditioned or prior owned product.

Claims for items described in (4) above should be submitted directly to the manufacturer.

The Company's obligation under this warranty is limited to repair or replacement, at its option during normal business hours at an authorized service facility of the Company, of any part which in its judgment proved not to be as warranted within the applicable Warranty Period. The Company may require the return of any part claimed not to be as warranted to one of its facilities as designated by Company, transportation prepaid by Purchaser, to establish a claim under this warranty.

The Company will provide labor for repair or replacement of any product or part thereof which in the Company's judgment is proved not to be as warranted, by Company representative up to the amount specified in the Company's labor rate schedules, or up to the amount the Company determines is reasonable. Labor costs in excess of the Company rate schedule amounts or labor provided by unauthorized service personnel is not provided for by this warranty.

Replacement parts provided under the terms of the warranty are warranted for the remainder of the Warranty Period of the product upon which installed to the same extent as if such parts were original components thereof.

DISCLAIMER

THE FOREGOING WARRANTY IS EXCLUSIVE AND IT IS EXPRESSLY AGREED THAT, EXCEPT AS TO TITLE, THE COMPANY MAKES NO OTHER WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY.

THE REMEDY PROVIDED UNDER THIS WARRANTY SHALL BE THE SOLE, EXCLUSIVE AND ONLY REMEDY AVAILABLE TO PURCHASER AND IN NO CASE SHALL THE COMPANY BE SUBJECT TO ANY OTHER OBLIGATIONS OR LIABILITIES. UNDER NO CIRCUMSTANCES SHALL THE COMPANY BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, EXPENSES, LOSSES OR DELAYS HOWSOEVER CAUSED.

No statement, representation, agreement, or understanding, oral or written, made by any agent, distributor, representative, or employee of the Company which is not contained in this Warranty will be binding upon the Company unless made in writing and executed by an officer of the Company.

This warranty shall not be effective as to any claim which is not presented within 30 days after the date upon which product is claimed not to have been as warranted. Any action for breach of this warranty must be commenced within one year after the date upon which the cause of action occurred.

Any adjustment made pursuant to this warranty shall not be construed as an admission by the Company that any product was not as warranted.

FOREWORD

Gardner-Denver® Electra-Saver II® compressors are the result of advanced engineering and skilled manufacturing. To be assured of receiving maximum service from this machine, the owner must exercise care in its operation and maintenance. This book is written to give the operator and the maintenance department essential information for day-to-day operation, maintenance and adjustment. Careful adherence to these instructions will result in economical operation and minimum downtime.



DANGER

— Failure to observe a *DANGER* notice could result in injury to, or death of personnel.



WARNING

— Failure to observe a *WARNING* notice could result in damage to equipment.



CAUTION

— *CAUTION* notices set forth general reminders of good safety practice, or direct attention to unsafe practices.

NOTE — Information furnished in a *NOTE* will include general information or the highlights of a procedure.

TABLE OF CONTENTS

GENERAL INFORMATION	SECTION 1
INSTALLATION	SECTION 2
STARTING AND OPERATING PROCEDURES	SECTION 3
CONTROLS AND INSTRUCTIONS	SECTION 4
LUBRICATION, OIL COOLER, OIL FILTER AND SEPARATOR	SECTION 5
AIR FILTERS	SECTION 6
COUPLING	SECTION 7
MAINTENANCE SCHEDULE	SECTION 8
TROUBLE SHOOTING	SECTION 9
REBUILDING DATA	SECTION 10

INDEX

NOTE: Numbers preceeding dash are Section Numbers — numbers following dash are Page Numbers.

Addition of Oil Between Changes	5-2	Electrical	3-1
Aftercooler	2-3	Electrical Wiring (Standard Units)	2-6
Air Control Valves	4-4	Enclosure	2-2, 3-1
Air-Cooled Unit — Location	2-1	Externally Mounted Aftercooler	2-4
Air Filter	3-1, 6-1, 8-1		
Air Filter Indicator	4-4		
AIR FILTERS (SECTION 6)	6-1		
Air Flow	1-1	Filling Oil Reservoir	5-3
Air and Oil Discharge Temperature	5-6	Filter Element (Heavy Duty)	6-1
Air-Oil Systems Flow Diagram	5-1	Filter Element Life (Heavy Duty)	6-2
Air Pressure Adjustment, Operating	4-8	Fits	10-2
Air Pressure Gauge	4-4	Flow Diagram — Air-Oil Systems	5-1
Air Temperature Gauge, Discharge	4-4	Foundation	2-1
Alignment, Coupling	3-1, 7-1		
Automatic Blowdown Valve	4-2		
Auxiliary Accessories	2-3	Gauges and Instruments	4-3
Auxiliary Air Receiver	2-3, 4-7	General (Controls)	4-1
		GENERAL INFORMATION (SECTION 1)	1-1
Blowdown Valve	4-2, 4-5	General (Installation)	2-1
Blowdown Valve Piping	2-5	Grease Recommendations	2-6
Built-In Air-Cooled Aftercooler	2-4	Grounding	2-6
Check Valve (Oil Reservoir)	4-7	Heavy-Duty Air Filter	6-1
Cleaning and Draining Oil System	5-3	High Discharge Temperature Switch	4-2
Cold Ambient Operation	5-2	High Temperature Operation	5-2
Cold Weather Operation, Installation for	2-2	Hourmeter	4-4
Compression Principle	1-1		
Compressor	1-1	Inlet Line	2-4
Compressor Lubricants	5-2	Inlet Screen and Tube (Heavy-Duty Air Filter)	6-2
Compressor Oil	3-1	Inlet Temperature, Compressor Oil	5-6
Compressor Oil Cooler — Radiator Type	5-4	Inlet Valve	4-5
Compressor Oil Cooler — Water-Cooled		Installation for Cold Weather Operation	2-2
Heat Exchanger	5-4	INSTALLATION (SECTION 2)	2-1
Compressor Oil Filter	5-3	Instruments and Gauges	4-3
Compressor Oil Inlet Temperature	5-6		
Compressor Oil Separator	5-5		
Compressor Oil System	5-1		
Compressor Oil System Check	5-6		
Control Piping	2-4		
CONTROLS & INSTRUMENTS (SECTION 4)	4-1	Lifting Unit	2-1
Control Schematics	4-9 thru 4-12	Location (Installation)	2-1
Control System, Modulating	4-7	Low Demand 4-Way Solenoid Valve	4-2
Control Voltage	4-1	Low Demand Pressure Switch	4-2
COUPLING (SECTION 7)	7-1	Low Demand Pressure Switch Setting	4-8
Coupling	7-1	Low Demand Switch	4-1
		Low Demand Switch Off	4-7, 4-8
Daily Check	3-1	Low Demand Switch On	4-7, 4-8
Differential, Oil Cooler Oil Pressure		Low Oil Pressure Shutdown Switch	4-2
(Air-Cooled Radiator)	5-6	Low Oil Pressure Time Delay Switch	4-3
Differential, Oil Cooler Oil Pressure		Lubricants, Compressor	5-2
(Water-Cooled Heat Exchanger)	5-6	Lubricants, Synthetic	5-1
Differential, Oil Cooler Temperature		Lubrication, Cooling and Sealing	1-1
(Air-Cooled Radiator)	5-6	LUBRICATION, OIL COOLER, OIL FILTER &	
Differential, Oil Cooler Temperature		SEPARATOR (SECTION 5)	5-1
(Water-Cooled Heat Exchanger)	5-7		
Differential, Oil Cooler Water Pressure			
(Water-Cooled Heat Exchanger)	5-6	MAINTENANCE SCHEDULE (SECTION 8)	8-1
Dimensions	10-1	Minimum Discharge Pressure Valve	4-6
Discharge Air Temperature Gauge	4-4	Modulating Control System	4-7
Discharge Temperature, Air and Oil	5-6	Moisture in the Oil System	5-3
Discharge Service Line	2-5	Moisture Separator Trap	2-4
Draining and Cleaning Oil System	5-3	Motor Lubrication	2-6, 8-1
Dust Cup (Heavy-Duty Air Filter)	6-1	Motor Protection Devices	4-1

Oil and Air Discharge Temperature	5-6
Oil-Air Systems Flow Diagram	5-1
Oil Capacities	5-2
Oil Change Interval	5-3
Oil Cooler, Compressor — Radiator Type	5-4
Oil Cooler, Compressor — Water-Cooled Heat Exchanger	5-4
OIL COOLER, OIL FILTER & SEPARATOR — LUBRICATION (SECTION 5)	5-1
Oil Cooler Oil Pressure Differential (Air-Cooled Radiator)	5-6
Oil Cooler Oil Pressure Differential (Water-Cooled Heat Exchanger)	5-6
Oil Cooler Temperature Differential (Air-Cooled Radiator)	5-6
Oil Cooler Temperature Differential (Water-Cooled Heat Exchanger)	5-7
Oil Cooler Water Pressure Differential (Water-Cooled Heat Exchanger)	5-6
Oil Filter, Compressor	5-3
Oil Filter Indicator	4-4
Oil Inlet Pressure	5-6
Oil Inlet Temperature, Compressor	5-6
Oil Level Gauge	5-2
Oil Reservoir	5-5
Oil Reservoir Drain	2-2
Oil Separator, Compressor	5-5, 8-1
Oil Specifications	5-1
Oil System Capacities	5-2
Oil System Check, Compressor	5-6
Oil System, Compressor	5-1
Oil System, Draining and Cleaning	5-3
On-Off-Reset Switch	4-1
Operating Air Pressure Adjustment	4-8
Operating Light Test	3-1
Operating Mode	3-1
Parallel Piping	2-5
Pilot Light	4-1
Piping	3-1
Piping, Blowdown Valve	2-5
Piping, Control	2-4
Piping, Water	2-5
Pressure Differential Gauging	5-5
Pressure, Oil Inlet	5-6
Pressure Regulator	4-6
Pressure, System	3-1
Prestart-Up Instructions	3-1
Purge Air Valve	4-5
REBUILDING DATA (SECTION 10)	10-1
Receiver, Auxiliary Air	2-3, 4-7
Regreasing Interval	2-6
Reservoir Pressure Switch	4-3
Reset	4-1
Rotation	3-1
Running Clearances	10-2

Safety Devices	4-1
Safety Precautions	1-4
Safety Valve	4-2
Separator, Compressor Oil	5-5
Series Piping	2-5
Service Check List	8-1
Shuttle Valve	4-5
STARTING & OPERATING PROCEDURES (SECTION 3)	3-1
Starting Unit	3-1
Stopping Unit	3-1
Subtractive Pilot	4-4
Subtractive Pilot Unload Setting	4-8
Switch, High Discharge Temperature	4-2
Switch, Low Demand	4-1
Switch, Low Demand Pressure	4-2
Switch, Low Oil Pressure Shutdown	4-2
Switch, Low Oil Pressure Time Delay	4-3
Switch, On-Off-Reset	4-1
Switch, Start-Stop/Reset	4-1
Switch, Reservoir Pressure	4-3
Synthetic Lubricants	5-1
System Pressure	3-1
Temperature, Air and Oil Discharge	5-6
Temperature, Compressor Oil Inlet	5-6
Thermal Control (Thermostatic Mixing) Valve	5-4
Timer	4-1
TROUBLE SHOOTING (SECTION 9)	9-1
Valve, Air Control	4-4
Valve, Blowdown	4-2, 4-5
Valve, Check (Oil Reservoir)	4-7
Valve, Low Demand 4-Way Solenoid	4-2
Valve, Inlet	4-5
Valve, Minimum Discharge Pressure	4-6
Valve, Safety	4-2
Valve, Shuttle	4-5
Valve, Thermal Control (Thermostatic Mixing)	5-4
Valve, Water Flow Control (For Heat Exchanger)	5-4
Valve, Water Shutoff — Water-Cooled Heat Exchanger)	5-5
Water-Cooled Unit — Location	2-1
Water Flow Control Valve for Heat Exchanger	5-4
Water Flow Rates	2-4
Water Piping	2-5
Water Shutoff Valve — Water-Cooled Heat Exchanger)	5-5
Wiring Diagrams	4-13 thru 4-17

SECTION 1

GENERAL INFORMATION




FIGURE 1-1. — COMPRESSION CYCLE



COMPRESSOR — The Gardner-Denver® “ECH” Electra-Saver II® compressor is a single stage, positive displacement rotary machine using meshing helical rotors to effect compression. Both rotors are supported between high capacity roller bearings located outside the compression chamber. Single width cylindrical roller bearings are used at the inlet end of the rotors to carry part of the radial loads. Tapered roller bearings at the discharge end locate each rotor axially and carry all thrust loads and the remainder of the radial loads.



COMPRESSION PRINCIPLE (Figure 1-1) — Compression is accomplished by the main and secondary rotors synchronously meshing in a one-piece cylinder. The main rotor has four (4) helical lobes 90° apart. The secondary rotor has six (6) matching helical grooves 60° apart to allow meshing with main rotor lobes.

The air inlet port is located on top of the compressor cylinder near the drive shaft end. The discharge port is near the bottom at the opposite end of the compressor cylinder. *Figure 1-1 is an inverted view to show inlet and discharge ports.* The **compression cycle** begins as rotors unmesh at the inlet port and air is drawn into the cavity between the main rotor lobes and secondary rotor grooves (A). When the rotors pass the inlet port cutoff, air is trapped in the interlobe cavity and flows axially with the meshing rotors (B). As meshing continues, more of the main rotor lobe enters the secondary rotor groove, normal volume is reduced and pressure increases. Oil is injected into the cylinder by proprietary means to remove the heat of compression and seal internal clearances. The Electra-Saver II utilizes Gardner-Denver’s exclusive Intensive Injection System to feed coolant into the compression chamber through dozens of small injection ports. This greatly improves the rate of heat exchange between the air/oil mixture with most of the injection and heat transfer occurring where the air has reached its highest pressure and greatest temperature. Hot spots in the compression cycle are eliminated. Volume reduction and pressure increase continues until the air/oil mixture trapped in the interlobe cavity by the rotors passes the discharge port and is released to the oil reservoir (C). Each rotor cavity follows the same “fill-compress-discharge” cycle in rapid succession to produce a discharge air flow that is continuous, smooth and shock-free.

AIR FLOW IN THE COMPRESSOR SYSTEM (Figure 1-5) — Air enters the air filter and passes through the inlet unloader valve to the compressor. After compression, the air/oil mixture passes into the oil reservoir where most of the entrained oil is removed by velocity change and impingement and drops back into the reservoir. The air and remaining oil then passes through the oil separator, the separated oil is returned to the system through tubing connecting the separator and compressor. The air passes through the reservoir discharge manifold, minimum pressure valve and discharge check valve to the plant air lines.

LUBRICATION, COOLING AND SEALING — Oil is forced by air pressure from the oil reservoir through the oil cooler, thermostatic mixing valve, and oil filter and discharges into the compressor main oil gallery. A portion of the oil is directed through internal passages to the bearings, gears and shaft oil seal. The balance of the oil is injected directly into the compression chamber to remove heat of compression, seal internal clearances and lubricate the rotors.





SAFETY PRECAUTIONS

Safety is everybody's business and is based on your use of good common sense. All situations or circumstances cannot always be predicted and covered by established rules. Therefore, use your past experience, watch out for safety hazards and be cautious.

Some general safety precautions are given below.

WARNING

- STOP THE UNIT IF ANY REPAIRS OR ADJUSTMENTS ON OR AROUND THE COMPRESSOR ARE REQUIRED.
- ALL COMPRESSED AIR SUPPLY HOSES EXCEEDING 1/2 INCH INSIDE DIAMETER SHOULD HAVE AN EXCESS FLOW VALVE (OSHA REGULATION, SECTION 1518.302.)
- DO NOT EXCEED THE RATED MAXIMUM PRESSURE VALUES SHOWN ON THE NAMEPLATE
- DO NOT OPERATE UNIT IF SAFETY DEVICES ARE NOT OPERATING PROPERLY. CHECK PERIODICALLY. NEVER BYPASS SAFETY DEVICES.

DANGER

- KEEP FINGERS AND CLOTHING AWAY FROM REVOLVING FAN, DRIVE COUPLING, ETC.
- DO NOT USE THE AIR DISCHARGED FROM THIS UNIT FOR BREATHING — NOT SUITABLE FOR HUMAN CONSUMPTION.
- DO NOT LOOSEN OR REMOVE THE OIL FILLER PLUG, DRAIN PLUGS, COVERS, THE THERMOSTATIC MIXING VALVE OR BREAK ANY CONNECTIONS IN THE COMPRESSOR AIR OR OIL SYSTEM UNTIL THE UNIT IS SHUT DOWN AND THE AIR PRESSURE HAS BEEN RELIEVED.
- ELECTRICAL SHOCK CAN AND MAY BE FATAL
- COMPRESSOR UNIT MUST BE GROUNDED IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE A GROUND JUMPER EQUAL IN SIZE TO THE EQUIPMENT GROUND CONDUCTOR MUST BE USED TO CONNECT THE COMPRESSOR MOTOR BASE TO THE UNIT BASE
- OPEN MAIN DISCONNECT SWITCH BEFORE WORKING ON THE CONTROL
- DISCONNECT THE COMPRESSOR UNIT FROM ITS POWER SOURCE BEFORE WORKING ON THE UNIT — THIS MACHINE IS AUTOMATICALLY CONTROLLED AND MAY START AT ANY TIME

SECTION 2

INSTALLATION

GENERAL — On receipt of the unit, check for any damage that may have been incurred during transit. Report any damage or missing parts as soon as possible.



CAUTION

DO NOT electric weld on the compressor or base; bearings can be damaged by passage of current.

LIFTING UNIT — Proper lifting and/or transporting methods must be used to prevent damage.



WARNING

Lift compressor unit by base only. Do not use other places such as enclosure, motor, compressor oil discharge manifold and piping as lifting points.



WARNING

The eyebolts or lugs provided on the motor are for lifting the motor only and should not be used to lift any additional weight. All eyebolts must be securely tightened. When lifting the motor the lifting angle must not exceed 15 degrees. Failure to observe this warning may result in damage or personal injury.

Lifting slots are provided in the base for towmotor use. Unit may also be moved into location by rolling on bars. The optional sound attenuating enclosure air inlet and discharge baffles may be removed for handling purposes.



WARNING

DO NOT operate unit with access doors removed. Doors must be in place and closed to direct cooling air over the motor, oil cooler and aftercooler.

LOCATION — The compressor should be installed, whenever possible, in a clean, well-lighted, well-ventilated area with ample space all around for maintenance. Select a location that provides a cool, clean, dry source of air. In some cases it may be necessary to install air filter at some distance from compressor to obtain proper air supply. See "Inlet Line" paragraph below. Both the air-cooled and water-cooled units require cooling air as well as air to the compressor inlet. Proper ventilation **MUST** be provided; hot air must be exhausted from the compressor operating area. A typical inlet-outlet air flow arrangement is shown in Figure 1-2.

AIR-COOLED UNIT — The air-cooled unit with the standard enclosure requires sufficient air flow, Figure 2-2, for the compressor oil/after cooling system and for electric motor cooling. Air is drawn into the unit at the motor end of the enclosure. Air is exhausted at the compressor end. Do not block the air flow to and from the unit. Allow three and one-half (3-1/2) feet to the nearest obstruction on the starter end and control box side of the unit. Allow two (2) feet to the nearest obstruction above and on other sides of the unit.



CAUTION

If the compressor unit base is raised above floor level, the space between the floor and the base bottom must be closed with solid material all around to prevent recirculation of hot air from the oil cooler end and over temperature operation.

WATER-COOLED UNIT — The water cooled unit with the standard enclosure requires sufficient air flow, Figure 2-2, for electric motor cooling. Air is drawn into the unit at the motor end of the enclosure and is exhausted at compressor end. Do not block air flow to and from unit. Allow three and one-half (3-1/2) feet to the nearest obstruction on starter end and control box side of unit. Allow two (2) feet to the nearest obstruction above and on other sides of the unit.

FOUNDATION — The Electra-Saver II® compressor requires no special foundation, but should be mounted on a smooth, solid surface. Whenever possible install the unit near level. Temporary installation may be made at a maximum 20° angle lengthwise or 20° sidewise. Mounting bolts are not normally required. However, installation conditions such as piping rigidity, angle of tilt, or danger of shifting from outside vibration or moving vehicles may require the use of mounting bolt to the foundation. Coupling alignment **MUST** be checked after installation.




FIGURE 1-2. — TYPICAL COMPRESSOR ROOM

Minimum Air Flow* For Compression And Cooling (Cubic Feet/Minute)		
	Air Cooled	Water Cooled
All Models	6000 cfm	6000 cfm

* 80° F Inlet Air

FIGURE 2-2.

OIL RESERVOIR DRAIN — The oil drain is piped from the bottom of the reservoir to the side of the compressor unit base. This drain is approximately eight (8) inches above the floor level. If this height is not sufficient to conveniently drain the oil, some other methods of providing oil drain are:

1. Elevate the compressor unit on raising blocks to obtain the desired drain height. See "Air Cooled Unit" paragraph above for caution on preventing recirculation of hot air through unit.
2. Construct an oil sump or trough below the floor level and pump or bail the drained oil.
3. Pump oil from the reservoir filler opening or drain to a container.

ENCLOSURE — The compressor, electric motor, oil cooler and aftercooler are mounted inside the enclosure. The enclosure directs the cooling air flow across the motor, compressor and through the coolers. The enclosure reduces the normal operating sound level of the unit to 88 DbA. Optional sound attenuating air inlet and discharge baffles are available which reduce the normal operating sound level to 84 DbA in free field conditions.

Service doors are provided for access to the motor and compressor. Be sure to allow enough space around the unit for the doors to open completely. Both of the two (2) doors may be removed by opening the door and lifting it up slightly to disengage the lower hinge pin from its bracket. The top pin can then be disengaged by lowering the door.



WARNING

Do not operate unit with access doors removed. Doors must be in place and closed to direct cooling air over motor and coolers.



DANGER

Do not open service doors while compressor is operating. Open doors will expose rotating fan and coupling.

INSTALLATION FOR COLD WEATHER OPERATION — It is recommended that whenever possible the unit be installed inside a shelter that will be heated to temperatures above freezing (32° F, 0° C). This will eliminate many of the problems associated with operating the units outside in cold climates where freezing rain, drifting snow, freezing condensate and bitter cold temperatures are encountered. When an outside installation must be made, the precautions required will depend on how severe the environment will get. The following are general guidelines for outside installations:

Cold Weather (Down To -10° F)

1. Be sure all control lines, drains and traps are heated to avoid freezing of condensate. Heat tape with thermostat control is generally satisfactory for this purpose and can be obtained at various local plumbing or hardware outlets at nominal cost.
2. If an air-cooled aftercooler is to be used, provisions to bypass the aftercooler should be made. Since cold air contains very little moisture, successful operation can be achieved without the aftercooler.
3. Provide at least some simple shelter such as a plywood windbreak to protect against drifting snow.
4. Use only Gardner-Denver® GD800 lubricant.




FIGURE 3-2.




FIGURE 4-2. — AUXILIARY ACCESSORIES

D76412

5. Monitor unit carefully during start-up and operation to be sure it is functioning normally.
6. Specify NEMA 4 enclosure for electrical devices.

Extreme Cold Weather Operation (Down To -40° F)

In addition to the above, the following should be provided:

1. It will probably be necessary to provide shutters or to block off part of the cooler in some manner since the cooler is greatly oversized for operation in these low temperatures. Since shutters are not provided as a factory option, blocking off a portion of the cooler with plywood should be satisfactory.
2. Low Demand operation should not be used in extreme environments.
3. Some means of providing heat to oil reservoir and cooler during shutdown should be provided. There are various methods to accomplish this, but since openings are not provided for sump heaters, the use of radiant heaters is recommended. The heaters should be sized to provide at least a -10° F environment for the coolers, motor and sump. Figure 3-2 shows how these might be located in a typical installation and sizes required.

Remember unsheltered (outside) installations should be avoided where possible. Installation next to a heated building where enough heat can be used to keep the compressor room above freezing will save many complications in the operation and installation of the unit.

Refer to Engineering Data Sheet 13-9-411 for the advantages of using the heat recovered from rotary compressors. This heat recovery could easily pay for an adequate shelter for the unit.

AUXILIARY AIR RECEIVER — An auxiliary air receiver is not required if the piping system is large and provides sufficient storage capacity to prevent rapid cycling. When used, an air receiver should be adequate size, provided with a relief valve of proper setting, a pressure gauge and a means of draining condensate. Figure 4-2 shows a typical air receiver and auxiliary accessories.

AFTERCOOLER — An aftercooler will provide control of moisture entering the shop air lines while reducing the normal low discharge temperature of about 180° F at 100 PSIG discharge pressure to near inlet air temperature.

Aftercoolers are available in these classifications:

OIL COOLER							
HP	Model	Water Temperature To Heat Exchanger				Maximum Water Flow	Approximate Water Pressure Drop @ 90° F Water Flow (PSI)
		60° F	70° F	80° F	90° F		
40	ECHQHE ECHSHE	3.4	4.3	5.7	8.6	30.0	1.0
50	ECHQJE	4.1	5.1	6.8	10.2	30.0	1.0
AFTERCOOLER							
HP	Model	Water Temperature To Heat Exchanger				Maximum Allowable Flow (GPM)	Approximate Water Pressure Drop
		60° F	70° F	80° F	90° F		
40	ECHQHE ECHSHE	0.5	0.7	0.9	1.3	26.0	Less than 1 PSI for any flow rate shown in table.
50	ECHQJE ECHSJE	0.7	0.9	1.2	1.8	26.0	

Flow rates are based on 110° F maximum allowable outlet water temperature. Higher water outlet temperatures can lead to heat exchanger malfunction by causing fouling in the last water pass.

FIGURE 5-2. — HEAT EXCHANGER (OIL COOLER-AFTERCOOLER) APPROXIMATE WATER FLOW
U.S. Gallons/Minute

1. Factory-installed built-in air-cooled radiator type.
2. Factory-installed built-in water-cooled shell and tube type.
3. Externally-mounted aftercoolers supplied by the user.

BUILT-IN AIR-COOLED AFTERCOOLER — The radiator type aftercooler is an integral part of the factory installed unit oil/aftercooler system. The unit cooling fan forces air through the aftercooler and oil cooler. The compressed air is taken from the oil reservoir manifold and passes through the aftercooler and then through the moisture separator and trap to the shop air line.

MOISTURE SEPARATOR/TRAP — A combination moisture separator and trap is supplied for mounting by the user. Local codes and conditions will dictate the location of the separator/trap. However, the separator/trap must be placed between the aftercooler air outlet and any auxiliary air receiver and shop lines. The separator/trap should be placed in a vertical piping run, as near the outlet of the aftercooler as convenient, with the trap drain opening down. Provision should be made to pipe the drained moisture away from the unit.

EXTERNALLY-MOUNTED AFTERCOOLER — If an aftercooler is mounted outside the compressor unit, it is to be installed between the final discharge outlet and any auxiliary air receiver. Figure 4-2 shows a water-cooled aftercooler, but the piping arrangement shown also applies to an air-cooled type. A moisture separator trap is to be mounted directly downstream from the aftercooler and before any auxiliary air receiver.

CONTROL PIPING — Control piping is not necessary since the Electra-Saver II® unit is factory wired and piped for the control system specified.

INLET LINE — Where an inlet line is used between the air filter and the compressor, it must be thoroughly cleaned on the inside to prevent dirt or scale from entering the compressor. **If welded construction is used, the line must be shot blasted and cleaned to remove welding scale.** In either case, the inlet line must be coated internally by galvanizing or painting with a moisture and oil-proof sealing lacquer. Up to ten (10) feet in length, the inlet line should be the full size of the inlet opening on the compressor. If an extra-long line is necessary, the pipe size should be increased accordingly:

Length of Inlet Line	Diameter of Pipe Size
0 to 10 Ft.	Same As Compressor Inlet Opening
10 to 17 Ft.	One Size Larger Than Inlet Opening
17 to 38 Ft.	Two Sizes Larger Than Inlet Opening

Accessibility for inlet air filter servicing must be considered when relocating the filters from the unit to a remote location.

DISCHARGE SERVICE LINE — The discharge service line connection on both water-cooled and air-cooled units with after-cooler is made at the upper right hand corner of the unit, viewed from the service door side. On water-cooled units without aftercoolers, the discharge connection is made just after the factory installed check valve on the oil reservoir manifold. When manifolding two or more Electra-Saver II® units on the same line, each unit is isolated by the check valve in the unit discharge line. If an Electra-Saver II unit is manifolded to another compressor, be sure the other compressor has a check valve in the line between the machine and the manifold. If an Electra-Saver II and a reciprocating compressor are manifolded together, an air receiver must be located between the two units.



DANGER

DO NOT USE THE AIR DISCHARGED FROM THIS UNIT FOR BREATHING — IT IS NOT SUITABLE FOR HUMAN CONSUMPTION.

BLOWDOWN VALVE PIPING — The blowdown valve is fitted with a muffler for operation indoors. If the installation requires, the muffler may be removed and the blowdown valve piped to the outside with a pipe size the same as the blowdown valve outlet connection.


WATER PIPING (Water-Cooled Heat Exchanger Models Only) — On machines equipped with a water-cooled heat exchanger, pipe the water to the unit water inlet connection located at the lower left hand corner of the unit viewed from the control panel side and the water outlet connection located in the upper left hand corner. The water source should be capable of supplying up to the maximum flow shown in Figure 5-2 at a minimum pressure of 40 PSIG; maximum allowable water pressure is 150 PSIG. The water flow rates shown in Figure 5-2 are approximate and a guide to sizing piping, cooling tower and other water system equipment.

The heat exchanger system is designed to operate with water inlet temperatures from 60° F to 90° F and a water outlet temperature not to exceed 110° F. If water cooler than 60° F is used, high water outlet temperatures (over 110° F) will be experienced along with shortened heat exchanger life caused by tube fouling and corrosion. If water warmer than 90° is used, higher compressor oil inlet temperatures and high water usage will result.

Most water systems will require control of impurities: filtration, softening or other treatment. See "Compressor Oil Cooler — Water-Cooled Heat Exchanger" for more information on the water system.


SERIES PIPING (Figure 6-2) — The factory installed water cooled aftercooler will be piped upstream of and in series with the water cooled oil cooler. If the installation uses an externally mounted aftercooler, which is piped in series with the water cooled oil cooler the water flow must be through aftercooler first for effective cooling of discharge air.

PARALLEL PIPING (Figure 7-2) — A separate water control valve is required to control the discharge air temperature. If an externally mounted water-cooled aftercooler is piped in parallel with the heat exchanger, provide a separate water control valve for the aftercooler and pipe separate inlet water lines to both the aftercooler and heat exchanger.



* (OPTIONAL) WATER CONTROL VALVE AND WATER SHUTOFF VALVE MUST BE ORDERED SEPARATELY.

FIGURE 6-2. — SERIES PIPING



* (OPTIONAL) WATER CONTROL VALVE AND WATER SHUTOFF VALVE MUST BE ORDERED SEPARATELY.

FIGURE 7-2. — PARALLEL PIPING

The water control valve is to be adjusted to maintain oil out of the heat exchanger within the 140°-150° F range regardless of inlet water flow or temperature. See Section 5 for adjustment instructions and maximum allowable lubricant temperature.

ELECTRICAL WIRING – Standard Units – The “ECH” Electra-Saver II® compressor is factory wired for all starter to motor and control connections for the voltage specified on the order. It is necessary only to connect the unit starter to the correct power supply. See Section 4 for wiring diagrams of the control system. The standard unit is supplied with an open drip-proof motor, a NEMA 1 starter enclosure and a dust resistant control enclosure. See “Location” paragraph above for distance to nearest obstruction on starter and control box sides of the unit.

GROUNDING – Equipment must be grounded in accordance with Table 250-95 of the National Electrical Code.

MOTOR LUBRICATION – Long time satisfactory operation of an electric motor depends in large measure on proper lubrication of the bearings. The following charts show recommended grease qualities and regreasing intervals for ball bearing motors. For additional information refer to the motor manufacturer’s instructions.

The following procedure should be used in regreasing:

1. Stop the unit.
2. Disconnect the unit from the power supply.
3. Remove the relief plug and free the hole of hardened grease.
4. Wipe the lubrication fitting clean and add grease with a hand-operated grease gun.
5. Leave the relief plug temporarily off. Reconnect the unit and run for about 20 minutes to expell the excess grease.
6. Stop the unit. Replace the relief plug.
7. Restart the unit.

GREASE RECOMMENDATIONS

	<u>Standard Service</u>	<u>High Temperature</u>
Worked Penetration	265-296	220-240
Oil Viscosity, SSU At 100° F	400-550	475-525
Soap Type	Lithium	Lithium
N-H Bomb, Minimum Hours For 20 PSI Drop At 210° F	750	1000
Bleeding, Maximum Weight % In 500 Hours 212° F	10	3
Rust Inhibiting	Yes	Yes

REGREASING INTERVAL

Type of Service	Typical Example	Rating	Relubrication Interval
Standard	One- Or Two-Shift Operation	150 HP and Below	18 Months
Severe	Continuous Operation	150 HP and Below	9 Months
Very Severe	Dirty Location, High Ambient Temperature	150 HP and Below	4 Months

SECTION 3

STARTING & OPERATING PROCEDURES

PRESTART-UP INSTRUCTIONS — A new unit as received from the factory has been prepared for shipping only. Do not attempt to operate the unit until checked and serviced as follows:

1. **Compressor Oil** — Check oil level in the reservoir. Add oil only if the oil level gauge reads in the red ADD OIL range. Do not mix different type oils. Unit is shipped filled with Gardner-Denver® GD800 Lubricating Coolant which is suitable for the first 2000 hours under normal operating conditions.

REPLACE OIL FILTER ELEMENT EVERY 1000 HOURS.

Initial fill, or filling after a complete draining of the system, may show the oil level in the red EXCESS OIL range. After start-up, the oil will fall into the operating range as system components are filled. If necessary, add oil to bring the level into the center of the RUN range when the unit is operating at full load and normal operating pressure; see Figure 3-5.



DANGER

ALWAYS STOP THE UNIT AND RELEASE AIR PRESSURE BEFORE REMOVING OIL FILLER PLUG.

During unloaded operation and after shutdown, the system will partially drain back into the oil reservoir and the oil level may read higher than when operating on load. DO NOT DRAIN OIL TO CORRECT; on the next loaded cycle or start, oil will again fill the system and the gauge will indicate the operating level.

2. **Air Filter** — Inspect the air filter to be sure it is clean and tightly assembled. Refer to Section 6 "Air Filter" for complete servicing instructions. Be sure the inlet line, if used, is tight and clean.
3. **Alignment** — Check all bolts and cap screws for tightness. Check coupling alignment; refer to Section 7 "Coupling" for procedure.
4. **Piping** — Refer to Section 2 "Installation" and make sure the piping meets all recommendations.
5. **Electrical** — Check the wiring diagrams furnished with the unit to be sure it is properly wired. See Section 4 "Controls and Instruments" for general wiring diagrams and Section 2 for installation instructions.
6. **Rotation** — Check the motor rotation by momentarily jogging the motor. Compressor drive shaft rotation is clockwise standing at the motor end.



WARNING

DO NOT REPEATEDLY JOG THE MOTOR UNLESS ROTATION IS CORRECT. SEVERE COMPRESSOR DAMAGE CAN RESULT.

7. **Operating Light Test** — Observe the operating pilot lights when jogging motor in Step 6. Be sure all lamps are operative.
8. **System Pressure** — Set the constant speed pilot and/or operating air pressure switch to the desired unload pressure and differential. DO NOT EXCEED MAXIMUM OPERATING PRESSURE ON COMPRESSOR NAMEPLATE. See Section 4 "Controls and Instruments" for procedure.
9. **Operating Mode** — Refer to Section 4 for detailed information on the control system.
10. **Enclosure** — Check for damaged panels or doors. Check all screws and latches for tightness. Be sure doors are closed and latched.

STARTING THE UNIT — OBSERVE UNIT COLD OR HOT STARTING PROCEDURES.

Unit Cold — Close the air service valve (furnished by customer) between the main air system and unit check valve. If unit is a water-cooled heat exchanger model, open any manual water inlet wide open. Start unit by pressing the OFF (STOP/RESET) button, then the ON (START) button and run for one (1) minute. Open the air service valve. Since unit is equipped with a minimum (65 PSIG) pressure discharge valve, no special procedure to maintain unit reservoir is required.

Unit Hot — No warm-up period is required. Close the air service valve (furnished by customer). If the unit is a water-cooled heat exchanger model, open any manual water inlet valves wide open. Start unit by pressing the OFF (STOP/RESET) button, then the ON (START) button. Open the air service valve.

DAILY CHECK — Refer to Section 8 "Maintenance Schedule".

STOPPING THE UNIT — Close the air service valve (furnished by customer), allow the unit to build up to full unloaded

pressure and operate there for 3-5 minutes. Press the OFF (STOP/RESET) button. Stopping the unit at a pressure below full receiver may cause oil carry-over. The oil reservoir will automatically blow down as the motor stops. If the unit is a water-cooled heat exchanger type, close any manual water inlet valves. Open the air service valve.

SECTION 4

CONTROLS & INSTRUMENTS

GENERAL — The "ECH" Electra-Saver II® compressors are available with either of two (2) control systems.

1. Constant Speed Modulating Control.
2. Constant Speed Modulating Control With Automatic Start/Timed Stop.

Each of the above systems have a Low Demand Mode Switch to further reduce power consumption by blowing down the reservoir during unloaded operation. The "ECH" Electra-Saver II compressor unit is prewired with the starter mounted and all starter to motor and control connections for the voltage specified on the order. It is necessary only to connect the unit to the correct power supply, to the shop air line and to the shop water line, if the unit is water cooled. The standard unit consists of the compressor, oil reservoir, oil cooling system, air and oil filters, the control system specified, an open drip-proof motor, NEMA 1 starter enclosure and a dust resistant control enclosure/instrument panel all mounted on a steel base.

CONTROL VOLTAGE — The control voltage for the start-stop push button, hourmeter, pressure switch, high discharge temperature shutdown switches, blowdown valve, and other electrical control devices is 115 volts regardless of power supply voltage. A transformer in the control enclosure is connected to change the power supply voltage to 115 volt control voltage.

START-STOP/RESET SWITCH — Units with the Constant Speed Modulating Control with Low Demand Mode Switch have a two (2) button Start-Stop/Reset switch mounted in the control box door.

ON-OFF-RESET SWITCH — Units with the Constant Speed Modulating, Automatic Start/Timed Stop control with Low Demand Mode Switch have a three (3) button ON-OFF-RESET switch mounted in the control box door.

RESET — Whenever there is a power interruption or the unit is turned off, the Reset button must be pressed before the unit can be restarted.



CAUTION

DO NOT continue to reset the circuit if the same malfunction occurs within a short period of time. Find and correct the trouble before resuming operation.

PILOT LIGHT — A separate Dual Indicating pilot light is mounted in the control box door with an amber lighted section to indicate "ON" (compressor running) and a blue lighted section to indicate "LOAD" (compressor loaded).

To replace the bulbs in the pilot light: Replacement Bulb Number 24CA40 (Sylvania 120 PSB or equal)

1. Turn power off at main breaker panel.
2. Open control panel.
3. Turn slotted locking screw on upper side of pilot light body counterclockwise one-fourth (1/4) turn and remove the body from the lens holder.
4. Remove old bulb located in the body and insert new bulb.
5. Reassemble body to lens holder and secure by turning locking screw one-fourth (1/4) turn clockwise.

LOW DEMAND SWITCH (Figure 2-1) — The low demand switch, when turned to the ON position, will blow the reservoir down when compressor unloads. When switch is turned to OFF, unit will retain pressure in reservoir when unloaded.

TIMER — The Automatic Start/Timed Stop control uses an adjustable timing relay to stop the unit after a selected period of unloaded operation. The timer is located on the control box door; the calibrated dial allows selection of an unloaded operation interval between 3 and 30 minutes.



CAUTION

Never set the timer for a time interval less than three (3) minutes.

SAFETY DEVICES — All units incorporate these safety devices.

Motor Protection Devices — Overload heaters are furnished for the starter in the voltage range specified. There are three (3) overloads in the starter of proper size for the starter and its enclosure. When replacing or changing overloads, be sure to select them from a 3-overload heater table, since the use of a third overload derates each overload for a given enclosure due to the extra heat. An overload from a 2-overload heater table would be undersize.

The overload heaters have a high-low adjustment of $\pm 6\%$ determined by the position of the heater in the overload relay. The high or low position is shown on the overload heater table inside the starter enclosure. Motor nameplate amperage is used to determine high-low position.

High Discharge Temperature Switch

— The compressor unit is protected from high discharge temperature by a two-probe adjustable switch. One probe is located in the discharge pipe between the compressor and the oil reservoir to sense compressor discharge air/oil mixture temperature. The second probe is located in the final discharge manifold and senses the temperature of the air at the oil separator. The switch is located inside the control box (Figure 3-1); the shutdown temperature is set on the adjustable dial. If the temperature of the air at either of the probes exceeds the temperature set on the dial, the switch will stop the unit. Press reset button of the Start/Stop (On-Off) switch, then the Start (On) button to restart the unit.


HIGH DISCHARGE TEMPERATURE SWITCH CONDITION CHART				
"A" indicates Temperature Condition at Compressor Discharge. "B" indicates Temperature Condition at Oil Separator. "C" indicates Probe Condition.				
				
CONDITION	POWER ON	"A"	"B"	"C"
POWER OFF	OFF	OFF	OFF	OFF
NORMAL TEMPERATURE	RED	RED	RED	OFF
COMPRESSOR HIGH TEMPERATURE	RED	OFF	RED	OFF
SEPARATOR HIGH TEMPERATURE	RED	RED	OFF	OFF
COMPRESSOR PROBE OPEN	RED	OFF	RED	GREEN
SEPARATOR PROBE OPEN	RED	RED	OFF	GREEN
COMPRESSOR PROBE SHORTED	RED	OFF	RED	RED
SEPARATOR PROBE SHORTED	RED	RED	OFF	RED
COMPRESSOR PROBE SHORTED/ SEPARATOR PROBE OPEN	RED	OFF	OFF	ORANGE
COMPRESSOR PROBE OPEN/ SEPARATOR PROBE SHORTED	RED	OFF	OFF	ORANGE

FIGURE 1-4.



CAUTION

This adjustable switch dial must not be set higher than 225° F.

Do not continue to reset the circuit if the same malfunction occurs within a short period of time. Find and correct the trouble before resuming operation.

In addition to protecting the unit from damage or failure resulting from high air temperature, the switch also incorporates four (4) indicator lights which show the point of high temperature and/or the condition of the temperature probes. This information is shown in Figure 1-4 and on the decal inside the control box door.

The High Air Temperature Switch may be checked periodically to assure proper operation. To check with the unit running, turn the dial on the switch to the temperature indicated by the discharge temperature gauge. Unit should shutdown. If it does not, check the temperature gauge accuracy and indicator lights — refer to the condition decal on the control box door for the malfunction. After operational check, always reset switch dial to the proper setting (225° F).

Safety Valve — A pressure relief valve is installed in the final discharge manifold and set at the factory to approximately 120% of the specified operating pressure for protection against overpressure. Periodic checks should be made to insure its proper operation.



CAUTION

Never operate the unit without a proper safety valve setting.

Automatic Blowdown Valve (Figure 2-1) — A pilot operated valve piped into the oil reservoir final discharge manifold ahead of the check valve and connected to the unloader solenoid valve which is wired into the motor control circuit, will release pressure from the oil reservoir each time the unit is unloaded with low demand mode switch ON or when unit is shut down. The blowdown line is equipped with a muffler to reduce air discharge noise.

Low Demand Pressure Switch (Figure 2-1) — The low demand mode switch when turned ON will cause the low demand pressure switch to de-energize the low demand unloader solenoid 4-way valve when the discharge pressure reaches the set point. This switch should be set approximately 2 PSI below the subtractive pilot full load pressure setting.

Low Demand 4-Way Solenoid Valve (Figure 3-1) — The low demand solenoid valve when energized passes a low pressure air signal to close the blowdown valve. When de-energized, it passes a low pressure air signal to close the compressor inlet valve and exhaust air to open the blowdown valve.

Low Oil Pressure Shutdown Switch (Figure 3-1) — Units are provided with a pressure switch piped to the compressor oil sump

and wired into the motor control circuit to protect the unit against operation at too low an oil pressure and against complete lubrication failure due to an oil line restriction or sudden loss of oil pressure. The pressure switch is set 10-15 PSIG and will stop the unit if the oil pressure falls below this pressure any time during operation, and will prevent the unit being started if the oil pressure does not rise to 10-15 PSIG within 10 seconds of starting. The pressure switch is set at 10-15 PSIG at the factory. If resetting is necessary:

1. Adjust the upper limit pressure to 15 PSIG by turning the slotted screw near the top of the switch. Clockwise movement of the screw raises the pressure; counterclockwise lowers the pressure. Note approximate pressure setting is indicated on the range scale on left face of switch.
2. Adjust the lower limit pressure to 10 PSIG by turning the slotted screw (differential) near the bottom of the switch until the cam-shaped calibrated dial under the pressure setting screw indicates about one-fourth (1/4) of full scale reading from lowest setting. Clockwise movement of the screw reduces the differential; counterclockwise increases differential. Note differential range (3-18 PSI) is indicated by marks on the cam-shaped dial.

If a unit with Constant Speed control shuts down from low oil pressure, press the Stop/Reset button, then the ON button to restart the unit.

Since the Automatic Start/Timed Stop control is an automatic starting type, a reset relay is used as a positive means to interrupt the circuit on a low oil pressure shutdown; to restart the unit, press the bar marked RESET and then press the ON button.



CAUTION

Do not continue to restart the unit if the same malfunction occurs within a short period of time. Find and correct the trouble before resuming operation.

This control may be checked periodically to assure proper operation. To check, disconnect the timed-opening instantaneous-closing contact of the time delay relay from the system at point 10; see wiring diagram, Figure 15-4. Try to start unit — unit should not run — if it does, timer is inoperative and should be replaced. Be sure to reconnect the time delay relay at point 10 after checking.

Low Oil Pressure Time Delay Relay (Figures 3-1 & 2-4) located in the control panel enclosure, is wired into the control circuit to provide the 10-second delay required for the compressor oil pressure to rise to 10-15 PSIG and energize the low oil pressure switch circuit. To check the time delay switch setting:

1. Pull main breaker switch.
2. Move black Manual Operator timer tab located on the left half of relay block to the ON position and hold. Timer will begin to run for set time.
3. Observe the action of the right hand set of NC timing contacts on the right half of the relay block; the contacts will open when the preset time runs out.
4. Adjustment of time delay setting is made by turning the time setting adjusting screw on the lower right face of relay block to a faster (F) or slower (S) setting. Recheck setting of relay as in No. 2 and 3 above each time screw is turned.

Timer is factory set at 10 seconds. NEVER ATTEMPT TO ADJUST THE TIMING RELAY FOR MORE THAN 15 SECONDS DELAY — serious compressor damage may result from operation without lubrication for even a short period.



CAUTION

NEVER DISCONNECT ANY SAFETY DEVICES THAT PROTECT THE UNIT.


Reservoir Pressure Switch (Figure 2-1) — A pressure switch is connected to the discharge manifold and wired to the motor control circuit to prevent attempted starting of the unit when there is more than 5 PSIG pressure in the oil reservoir. This protects the unit from starting against load when the oil reservoir has not had enough time to blow down. Blowdown time is usually about forty-five (45) seconds.



WARNING

Do not set the switch higher than 5 PSIG or render the switch inoperative; severe damage to the motor can occur if started with pressure in oil reservoir.

INSTRUMENTS AND GAUGES (Figure 3-1) — All units incorporate the following instruments and gauges; optional instruments are noted. See Figure 3-4 for schematic tubing diagram showing connection of pneumatic controls and gauges.



A75852

FIGURE 2-4. — LOW OIL PRESSURE TIME DELAY RELAY




FIGURE 3-4. — SCHEMATIC TUBING DIAGRAM

Hourmeter — A continuous reading (nonreset) type hourmeter displays the accumulated operating time of the unit and provides a convenient means for scheduling changes of oil and servicing of filters, separators and other devices.

Air Pressure Gauge — A direct reading air pressure gauge indicates final discharge air pressure at the discharge manifold. When the test pushbutton at the right of the gauge is pressed, the gauge reads the air pressure in the oil reservoir upstream of the oil separator. See "Compressor Oil Separator — Pressure Differential Gauging" in Section 5.

Discharge Air Temperature Gauge — A direct reading temperature gauge indicates compressor discharge air temperature.

Oil Filter Indicator — An oil filter indicator is located on the head of the oil filter and indicates when the oil filter requires changing.



CAUTION

Always change oil filter element each 1000 hours of operation regardless of indicator reading. Indicator may show need for earlier change.

Air Filter Indicator (Optional) — An air filter indicator is located on the instrument panel and indicates when the air filter requires servicing.

AIR CONTROL VALVES — All units incorporate the following air control valves. See Figure 3-4 for schematic tubing diagram showing connection of pneumatic valves.

Subtractive Pilot — The subtractive pilot is an adjustable, spring-loaded diaphragm valve that controls downstream control pressure in relation to the upstream discharge pressure; see Figure 4-4

The downstream pressure is maintained equal to the upstream pressure minus a constant. As shown in Figure 4-4, the

downstream pressure equals the upstream pressure minus 95. When the upstream (discharge) pressure rises to 100 PSIG, downstream (control) pressure rises to 5 PSIG. This 1 to 1 PSI rise is constant over the pilot differential range of 15 PSI on either rising or falling upstream pressure. Below 15 PSI under the pilot unload pressure the downstream (control) pressure is vented to atmosphere; in the example of Figure 4-4 the control pressure is vented below 95 PSIG.

Figure 5-4 shows a schematic cross-section of the subtractive pilot with the valve seat closed and the downstream line vented. Figure 6-4 shows the pilot with the valve seat open, holding a pressure downstream which is adjustable with the screw. In this position it is normal for the valve to continually bleed air through the small vent hole in the bowl.

The pilot admits air to the inlet valve piston when a discharge manifold pressure equal to the pilot low setting is reached. The air begins to pass through the pilot to the piston, and the inlet valve begins to close. As the discharge manifold pressure increases the pilot pressure also increases on the inlet valve piston further closing the inlet valve. At full manifold pressure (pilot unload setting) the pilot is exerting full differential pressure on the inlet valve piston and the inlet valve is fully closed. As the discharge manifold pressure falls, the pilot exerts proportionally less pressure on the inlet piston allowing the inlet piston spring to return the piston and the inlet valve to open. The pilot can be adjusted from 65 to 150 PSIG. The differential range of approximately 15 PSI cannot be changed. In order to obtain full capacity at the maximum operating pressure, the pilot should be set to unload with the inlet valve fully closed at approximately 10 PSIG above the maximum operating pressure. An example of pilot control air/compressor operation at 95-110 PSIG:

Discharge Manifold Pressure	Pressure In Control System	Inlet Valve	Compressor
90	0	Open	At Full Capacity
95	0	Open	At Full Capacity
100	5	Closing	Reduced Capacity
105	10	Closing	Reduced Capacity
110	15	Closed	Not Compressing

Oil, moisture and dirt in the control lines can cause the set point of the pilot to shift or be erratic. The pilot can be disassembled and the diaphragm and ports cleaned, but this should be done only under the supervision of a trained factory representative.

INLET VALVE (Figure 7-4) — The inlet valve is a piston actuated device controlled by air pressure from the subtractive pilot. As the pressure of the control air increases, the inlet valve closes. With approximately 15 PSIG control pressure on the piston, the valve will close fully and stop the flow of air through the compressor. When the inlet valve closes, a small amount of purge air is directed from a purge air valve into the compressor to minimize a hydraulic knock that can occur in oil-flooded screw type compressors when operating unloaded.

The inlet valve contains piston spring “F” which returns the unloader piston and allows the inlet valve to open as pressure decreases, and valve spring “G” which returns the inlet valve to closed position on shutdown of the compressor and prevents oil backflow from the compressor to the air filter.

Purge Air Valve — The purge air valve is a normally closed two-way air-actuated valve that admits purge air from the final discharge manifold to the compressor to counteract the oil knock that occurs in oil-flooded rotary screw type compressors when they are completely unloaded with pressure in the oil reservoir. See Figure 8-4 for a schematic diagram of the Purge Air Valve in both its modes of operation.

Shuttle Valve (Figure 9-4) — Also known as a double check valve, the shuttle valve is a device which will take two (2) supply signals and allow the one with the highest pressure to pass through. The shuttle valve is used in the Low Demand control system with reservoir blowdown to allow the control to work from both the oil reservoir and the plant air system side of check valve.

Blowdown Valve (Figure 10-4) — The blowdown valve is a diaphragm-operated two-way normally-open valve. When there is




FIGURE 4-4.




FIGURE 5-4. – SUBTRACTIVE PILOT (Closed)




FIGURE 6-4. – SUBTRACTIVE PILOT (Opened)




FIGURE 7-4. — INLET VALVE




FIGURE 8-4. — PURGE AIR VALVE

no control pressure on the diaphragm the valve opens so that the oil reservoir is blown down. When the diaphragm is pressurized (3-30 PSIG), the valve closes and allows pressure to build in the oil reservoir.

Pressure Regulator — The pressure regulator senses and maintains a constant downstream pressure. The pressure regulator is used to supply a low control pressure to prevent damage to the inlet valve from “slamming”. The regulator must be set at 25-30 PSIG; the gauge on the regulator reads this control pressure from the valve.

Minimum Discharge Pressure Valve (Figures 2-1 and 11-4) — An internal spring-loaded minimum pressure valve is used in the final discharge line to provide a positive pressure on the oil system of compressor even when the air service valve is fully open.

The valve incorporates an orifice which, when air is flowing through it, maintains approximately 65 PSIG in the oil reservoir. A spring-loaded piston valve senses air pressure on the upstream (oil reservoir side) of the valve. When the system pressure rises above 65 PSIG, the spring is overridden and the valve opens to full porting.

The valve does not require maintenance or adjustment. If the valve fails to function, check the valve stem O-ring for sealing, valve orifices for restriction, or valve and valve seat for burrs and dirt.

The valve is adjustable within a small range. It is adjusted by a screw on the side of the valve body. The minimum pressure can be adjusted as follows:

1. Start the compressor.




FIGURE 9-4. — SHUTTLE VALVE




FIGURE 10-4. — BLOWDOWN VALVE

B77095

2. Reduce pressure downstream of minimum pressure valve to below desired minimum pressure. **DO NOT REDUCE UPSTREAM PRESSURE OR ADJUST VALVE BELOW 65 PSIG.**
3. Loosen locknut on adjusting screw.
4. Turn set screws in to increase, or out to decrease minimum pressure to be held.
5. Hold set screw at desired point and tighten locknut.

Check Valve (Oil Reservoir) (Figure 2-1) — A renewable seat swing type check valve in the final discharge manifold prevents backflow of air from the shop air line when the unit stops, unloads or is shut down.

AUXILIARY AIR RECEIVER — An auxiliary air receiver with adequate volume must be used to prevent rapid cycling of the unit. Occasionally shop air lines are such a length as to provide adequate volume, but this should be carefully checked before using the unit without an auxiliary air receiver.

MODULATING CONTROL SYSTEM is the standard control system for the "ECH" Electra-Saver II® compressors and is best used in applications where there are no long periods of unloaded operation.

The control system will modulate the compressor capacity to match the air system demand. As demand decreases and air system pressure increases above the subtractive pilot low setting, the pilot passes pressure to the inlet valve piston and the inlet valve closes enough to match the air system demand. As demand increases, and air system pressure decreases toward the subtractive pilot low setting, less pressure is passed to the inlet valve piston and the inlet valve opens enough to match the air system demand; see Figure 12-4. As the demand increases and air system pressure decreases below the subtractive pilot low setting, no pressure is passed to the inlet valve piston and the inlet valve opens fully and the compressor is at full load as in Figure 13-4. Note that the Low Demand switch may be either ON or OFF during modulated operation without effect on the system; if the Low Demand pressure switch setting is not reached, the 4-way solenoid is energized and is passing pressure to hold the blowdown valve closed.


The response of the Modulating Control system to occasional or no demand is determined by the position of the Low Demand switch.

Low Demand Switch ON — The air system pressure will increase above the Low Demand pressure switch high setting and will open the switch contacts and de-energize the Low Demand 4-way solenoid valve. The 4-way valve shifts to pass pressure to the control system and release pressure from the blowdown valve which opens to vent the oil reservoir pressure to atmosphere. The decreasing oil reservoir pressure causes the subtractive pilot pressure to drop and allows shuttle valve 2 to shift to pass pressure from 4-way valve to the inlet valve piston and fully close the inlet valve. The discharge check valve blocks the higher plant air pressure from returning to the lower oil reservoir pressure and shuttle valve 1 shifts to pass plant air pressure to the control system. During the time that the shuttle valves are shifting, there is a momentary cross over between the two systems; however, since the shuttle valve requires only 0.36 PSI differential to shift, the operation is instantaneous for all practical purposes. Figure 14-4 shows the air system after the compressor is fully unloaded. During unloaded, oil reservoir blowdown operation the compressor receives proper lubrication as oil is circulated from the positive atmospheric pressure in the oil reservoir to the negative unloaded pressure (vacuum) in the compressor.

The unit will continue to run unloaded and the oil reservoir remain blown down until the plant air pressure decreases to the Low Demand pressure switch low setting. The pressure switch contacts will close, energizing the 4-way valve which shifts to release pressure from the control system and apply pressure to the blowdown valve. As pressure is released from the inlet valve piston, the inlet valve opens admitting air for compression. With the blowdown valve closed, pressure rises in the oil reservoir. The rising oil reservoir pressure opens the discharge check valve and allows air to flow to the plant air line; shuttle valve 2 shifts to allow the subtractive pilot to modulate the inlet valve. See Figure 12-4 "Compressor at Partial Load".

Low Demand Switch OFF — The air system responds the same as with the Low Demand switch ON, except that the 4-way solenoid valve will not be de-energized to open the blowdown valve. The oil reservoir will not blow down and the inlet valve will respond to the subtractive pilot control only. See Figure 15-4 "Compressor Unloaded — Low Demand Switch OFF" and Figure 12-4 "Compressor at Partial Load".

MODULATING CONTROL SYSTEM WITH AUTOMATIC START/TIMED STOP is an optional control system for "ECH" Electra-Saver II compressors and is best used in applications where the demand for air varies widely or there are long periods of no demand. The Modulating Control with Automatic Start/Timed Stop system consists of the standard Modulating Control system plus a timer. The addition of a timer to the control system minimizes power consumption by stopping unit during extended periods of unloaded operation. Operation of Modulating Control with Automatic Start/Timed Stop system is identical to operation of the standard Modulating Control system, except as described below:



B75121

FIGURE 11-4. — MINIMUM DISCHARGE PRESSURE VALVE

Low Demand Switch ON — When air system pressure increases above the Low Demand pressure switch high setting, the switch not only de-energizes the Low Demand 4-way solenoid valve and blows down reservoir, but also starts timer. If air system pressure does not drop to pressure switch low setting within the period of time set on timer, the unit will stop. The "ON" indicator light will remain on as long as the "ON" pushbutton of the On-Off switch is depressed. When air system pressure drops to the pressure switch low setting, unit will start, timer will reset, and the loaded-unloaded-stop cycle will repeat.



CAUTION

Never set the timer for a time interval less than three (3) minutes. Use of a shorter time interval will cause excess starting and reduced motor life.

When Low Demand mode switch is in the ON position and timer is positioned so the range of "MIN" in "MINUTE" is opposite the arrow on timer ring, compressor will build to full pressure, unload and blow down. At this setting the motor will not stop.

Low Demand Switch OFF — When the Low Demand switch is in the OFF position, operation of the Modulating Control System with Automatic Start/Timed stop is identical to operation of the standard Modulating Control System with the Low Demand switch OFF.

OPERATING AIR PRESSURE ADJUSTMENT — Turn Low Demand switch OFF. Start the unit. Close the air service line valve (furnished by customer), allow the unit to build to full pressure and unload, and proceed as follows:

Subtractive Pilot Unload Setting — Set 10 PSI above required operating pressure, but should not exceed 10 PSI above compressor rating.

Pressure Too High:

1. Loosen the inlet valve subtractive pilot locknut. Back the adjusting screw out about one (1) turn.
2. Open the air service line valve and bleed air from the unit so that the compressor loads again. Close the valve and allow the compressor to unload.
3. Repeat Steps 1 and 2 until the proper unload pressure is obtained.
4. Tighten the locknut.

Pressure Too Low:

1. Loosen the inlet valve subtractive pilot locknut.
2. Turn the adjusting screw in until the proper unload pressure is obtained.
3. Tighten the locknut.

Low Demand Pressure Switch Setting — Set Reservoir Blowdown and Compressor Unload Pressures:

1. Turn the upper adjusting screw on the Low Demand pressure switch until the pointer on the left edge indicates the desired pressure — about 2 PSI below subtractive pilot unloaded pressure setting.
2. Adjust service valve until service pressure is just below desired operating pressure.
3. Turn Low Demand switch "ON".
4. Close service valve. Note the air pressure when unit blows down. If it is not the pressure desired, repeat subtractive pilot and Low Demand setting steps until proper blowdown pressure is obtained.

Set Compressor Load Point:

1. With the unit running, oil reservoir at full service pressure, plant air line valve closed, and Low Demand switch in the "ON" position, set the lower (differential) adjusting screw on the Low Demand mode pressure switch near the desired service pressure. Full service pressure minus the differential is the compressor load point. The differential range is approximately 2-18 PSIG on the circular scale above the adjusting screw. It should be set approximately 10 PSIG.
2. Bleed air from the plant air line valve and note the pressure at which the compressor loads.
3. Repeat Steps 1 and 2 until desired low air line pressure point is obtained.



CAUTION

DO NOT ADJUST THE FULL UNLOADED AIR PRESSURE TO MORE THAN 10 PSIG HIGHER THAN THE MAXIMUM STAMPED ON THE UNIT NAMEPLATE. MINIMUM OPERATING PRESSURE IS 65 PSIG.




FIGURE 12-4. — CONTROL SCHEMATIC
COMPRESSOR AT PARTIAL LOAD — AIR SYSTEM DEMAND INCREASING OR DECREASING
LOW DEMAND SWITCH ON OR OFF




FIGURE 13-4. — CONTROL SCHEMATIC
COMPRESSOR AT FULL LOAD — LOW DEMAND SWITCH ON OR OFF

D76677X




FIGURE 14-4. — CONTROL SCHEMATIC
COMPRESSOR UNLOADED — LOW DEMAND SWITCH ON

D76678




FIGURE 15-4. — CONTROL SCHEMATIC
COMPRESSOR UNLOADED — LOW DEMAND SWITCH OFF

D76679




FIGURE 16-4. — WIRING DIAGRAM — AIR & WATER COOLED
CONSTANT SPEED MODULATING CONTROL — AUTOMATIC START TIMED STOP
(For Notes See Section 4, Pages 15 thru 17)

D2026460(C)





FIGURE 17-4. — WIRING DIAGRAM — AIR & WATER COOLED
CONSTANT SPEED MODULATING CONTROL WITH LOW DEMAND MODE
(For Notes See Section 4, Pages 15 thru 17)

D2026461(C)

NOTES FOR WIRING DIAGRAMS

(Figures 16-4 and 17-4)

Models ECH_HE & ECH_JE Electra-Saver II® Compressors

**ALL NOTES ARE NOT APPLICABLE TO ALL WIRING DIAGRAMS —
READ CAREFULLY AND COMPLETELY FOR WIRING INSTRUCTIONS**

All equipment must be connected and phased exactly as shown. All piping, wiring and other equipment not specified on order is to be supplied by other than Gardner-Denver.

"A" — Compressor power supply disconnecting means — Fused Switch or Circuit Breaker (not furnished as a standard item — if ordered, it must be remote mounted and wired by customer).

"B" — Equipment must be grounded in accordance with Table 250-95 of the National Electrical Code.



WARNING

An equipment ground jumper equal in size to the equipment ground conductor, must be used to connect the compressor motor base to the main base because the bases are isolated from each other by vibration mounts.

"C" — When the control circuit voltage is from a separate power (voltage) source and is not controlled by the motor power supply disconnecting means, a disconnect switch (DS) interlock (not furnished) shall be mounted immediately adjacent to the motor power supply disconnecting means and wired by the customer as shown in the Schematic Wiring Diagram and per the data shown for that starter and its disconnecting means.

This interlocking device (DS) may be an Auxiliary (Aux) or Electrical Interlock (E.I.) contact operated by the handle of the motor power supply disconnecting means.

When this disconnect switch (DS) interlock is a separate device, it shall be used to turn the control circuit "OFF" before operating the motor power supply disconnecting means. See Article 430-74 of the National Electrical Code.

"D" — The compressor motor starter coil voltage is the same as the motor voltage, i.e., 200, 230, 460 volts, etc., unless the starter is ordered with its own fused control transformer. The relay contact from the compressor control panel to the remote mounted starter control circuit is rated 600 volts.

Remote mounted magnetic compressor starter control circuits are to be connected for TWO (2) WIRE control.

The remote compressor starter control wiring shall be interlocked with the rest of the control wiring as shown in the Schematic Wiring Diagram and per the wiring data shown for the remote starter. The internal wiring shown is typical only. For exact wiring, see diagram on inside of starter or diagram

supplied with starter.

All reduced voltage (current inrush) starters, manual and magnetic, are also remote mounted and wired by the customer. See reduced voltage starter note on page 17, this section.

"D1" — Motor control circuits must be fused in accordance with article 430-72 of the National Electrical Code. Control circuits shall have short circuit protection (fuses, etc) in all instances because the control circuit wiring leaves the starter enclosure to go to the external devices.

"D2" — A G.E. CR234 air break manual starter is shown. The undervoltage (latch) coil circuit for the G.E. oil break and other manufacturers' manual starters is to be similarly reconnected and interlocked as shown with the compressor control wiring.

"E" — Oil Cooler power supply disconnecting means — Fused Switch or Circuit Breaker. Not applicable at this time.

"F" — Since most AC motors are wound for dual voltage, be certain leads are connected per the motor nameplate for the correct voltage.

"G" — Control transformers are sized for the components shown in the Schematic Wiring Diagram on 115 volts and not for any remote mounted compressor starter controls. Transformer part number is shown on the wiring diagrams.

"H" — Control circuit ground. A green ground wire is connected from the terminal shown on the wiring diagram to the control panel.

"J" — Air-cooled aftercooler with its starter and its power supply disconnecting means (Fused Switch or Circuit Breaker) with disconnect switch (DS) interlock — See Note "C" — (Not furnished as standard item — if ordered, it is remote mounted and wired by customer).

The aftercooler (when sized for an individual compressor) starter coil is 120 volts and is wired and interlocked with the rest of the control wiring as shown in the Schematic Wiring Diagram and per the wiring data shown for the aftercooler starter with its disconnecting means. When the aftercooler is sized for more than one compressor, see instructions for aftercooler starter coil on the special wiring diagram or sketch.

THE FOLLOWING COMPONENTS ARE NOT USED ON ALL UNITS — (See Wiring Diagram For Usage) —

A.P.S. — Air Pressure Switch — 2009006 — Set and/or Reset per table on wiring diagram.

The "Low Demand Switch" is furnished to provide low unloaded horsepower when the requirement for air is low. Turning the switch to "ON" switches the A.P.S. into the control circuit.

It is necessary to make sure the unload-load cycle time is greater than 45 seconds or else oil mist will be carried into the air lines. The unload-load cycle time can be increased in the same manner described below for excessive starts.

Excessive starting of motor can and will cause premature motor failure. Too frequent starting causes excessive heat which deteriorates the motor insulation. Excessive starting may be reduced by lowering the A.P.S. cut-in point (increasing differential) or by adding additional receivers to increase the system air storage capacity or both. The elimination of air leaks will also reduce the number of motor starts.

B.D.V. — 1/2" — 2-Way Normally Open — 2W.N.O. Air Operated Valve — 90AR234.

B.D.V.'s are sized to blow down oil reservoir in approximately 45 seconds.

BOOT — 24CA281 — Transparent for PB's when NEMA 4.

C.R. — Control Relay — 24CA771 — 110/120 V — 50/60 Hz Coil — 2S.P.N.O. Convertible 600 Volt Contacts.

D.S.A. — Disconnect Switch Interlock — Aftercooler.

FUSE — 2-1/4 AMP — 250 Volt Buss FRN 2-1/4 or equal.

H.D.T.S. — High Discharge Temperature Switch — Set 230° F. — 21D80. Thermistor Probe (2) — 21D81 (Compressor and Separator).

H.M. — Hourmeter — 2009369 — 120 V — 60 Hz (Alternate 2009370 — 110 V — 50 Hz).

I.C.I.O. — Instant Closing — Instant Opening.

I.C.T.O. — Instant Closing — Timed Opening.

I.O.I.C. — Instant Opening — Instant Closing.

I.O.T.C. — Instant Opening — Timed Closing.

L.O.P.S. — Low Oil Pressure Switch — 88A301 Set 10-15 PSI.

NOTE:

When starting unit for first time at final installation, loosen tube fitting on bottom of pressure switch. After compressor is started and oil appears at the fitting tighten fitting. If the compressor shuts down on low

oil pressure on the first start, wait until all the air has been bled off thru the blowdown valve before pressing reset button and restarting compressor.

M. — Motor Starter Coil, Contacts, etc.

M.U.-B.D.V. — Magnetic Unloader — Blowdown Solenoid Valve — 110/120 V — 50/60 Hz — Four Way — 91B34.

The LOW DEMAND switch should be in the "OFF" position when starting the unit to keep the compressor from cycling rapidly if service valve is closed.

M.W.V. — Magnetic Water Valve — 110/120 V — 50/60 Hz — Two-Way Normally Closed — 2W.N.C.

WATER-COOLED OIL COOLER *		
	NEMA 1	NEMA 4
ECH_HE & JE	90AC118 — 3/4"	90AC103 — 3/4"

* Valves have manual override.

M.W.V.'s are also shown on the Wiring Diagrams for Water-Cooled Aftercoolers (when used) and are to be sized for the aftercooler (if used).

O.L. — Overload — Heater  — Contacts 

R.R. 1 — Reset Relay — 24CA51 — 110/120 V — 50/60 Hz Coil — 2S.P.N.O. Convertible 300 Volt Contacts. Used with all automatic start controls which have low oil pressure shut-down. This relay gives LOW VOLTAGE PROTECTION which means a manual reset is required after every power turnoff or interruption. See the appropriate control wiring diagram for additional control switch components and resetting instructions.

T.C.I.O. — Timed Closing — Instant Opening.


T.D. — Time Delay Relay — 24CA285 — 110/120 V — 50/60 Hz Coil — is set for a maximum of 10 seconds to establish oil pressure after each start-up. If the TD timing coil fails the compressor will not load when started and will unload if running when control is constant speed. If the TD timing relay fails on an auto-start timed-stop control the compressor will not start; if running, unit will unload and continue running unloaded for the time setting of TR.

T.O.I.C. — Timed Opening — Instant Closing.

R.P.S. — Reservoir Pressure Switch — Set 5 PSI on falling pressure — 88H99 — prevents compressor from restarting loaded.



— Jumpers on Terminal Blocks (T.B.).



— Indicating Light — 24CA40 (Sylvania 120 PSB or Equal).

ADDITIONAL COMPONENTS WHEN COMPRESSOR CONTROL IS OTHER THAN CONSTANT SPEED —
(See Wiring Diagram Title For Type of Compressor Control) —

T.R. — Timing Relay (Auto-Start/Timed Stop Only) —
24A482 (Thru Door Mounting) — 110/120 V —
50/60 Hz Coil — 24A515 (Inside Panel Mounting) —
110/120 V — 50/60 Hz Coil

DO NOT SET TIMER DIAL BETWEEN THE 0 AND 3 MINUTE MARK

See remarks following A.P.S. If compressor remains unloaded for time set on timer dial head (adjustable to 30 minutes), compressor will stop and then start up when needed.

To make compressor run Constant Speed, set timer dial head so the letter "N" in "Minute" is opposite the arrow mark on the escutcheon. When timer dial is set for Constant Speed operation and compressor is not running, compressor will not start until air is required (A.P.S. closes).

 — Terminals on T.R. Timing Relay.

Special Notes, Components, Part Numbers and Description, etc. will be shown on Wiring Diagrams requiring the special notes and/or components.

REDUCED VOLTAGE STARTER NOTE —

1. Two (2) extra Normally Open Auxiliary contacts are required on most magnetic autotransformer reduced voltage starters. These contacts are required to inter-

lock the compressor starter back to the 115 volt compressor control

To determine whether or not these N.O. Auxiliary contacts are required, look at the typical wiring diagram shown in most starter manufacturers' control handbook, digest, catalog, etc. If the typical wiring diagram shows two (2) or more contacts paralleling the start push button, then these Auxiliary contacts are required.

If the typical wiring diagram shows a control (timing) relay, with or without control transformer, then the additional contacts are not required.

Generally, these Auxiliary contacts are to be ordered for the start and run contactors. If these Auxiliary contacts are not ordered with the starter, then the starter manufacturers field installation kits for Auxiliary contacts will have to be ordered and used.

These two (2) N.O. Auxiliary contacts, when required, will be supplied if Quincy orders the starters.

2. **STARTING (All Types Reduced Voltage Starters) —**
The first point acceleration time should not be longer than 4-5 seconds. This is in order that the pressure buildup in the compressor will not bog down nor stall the motor when the starter goes from the start to the run mode.

NOTE:


First point acceleration time may be limited to 2-3 seconds on some part winding motors.

On magnetic reduced voltage starters, set the starter timer for 4-5 seconds. If the starter is of the manual type, then do not hold the handle in the start position longer than 4-5 seconds.

SECTION 5

LUBRICATION

OIL COOLER, OIL FILTER & SEPARATOR



B76675

- A — Motor
- B — Compressor
- C — Air Filter
- D — Oil Reservoir
- E — Oil Separator
- F — Oil Cooler
- G — Aftercooler
- H — Thermal Control (Thermostatic Mixing) Valve
- J — Oil Filter
- K — Shuttle Valve
- L — Separator To Cylinder Oil Return Line
- M — Water Flow Control Valve

- N — Pneumatic Blowdown Valve
- P — Blowdown Muffler
- R — Low Demand Air Pressure Switch
- S — Low Demand 4-Way Valve
- T — Subtractive Pilot
- U — Pressure Regulator
- V — Minimum Discharge Pressure Valve
- W — Discharge Check Valve
- X — Reservoir Pressure Switch
- Y — Low Oil Pressure Switch
- Z — Magnetic Water Shutoff Valve
- AA — Purge Air Valve

FIGURE 1-5. — FLOW DIAGRAM — AIR-OIL SYSTEMS

COMPRESSOR OIL SYSTEM (Figure 1-5) cools the compressor, lubricates moving parts and seals internal clearances in the compression chamber. The oil inlet line is connected at the bottom of the oil reservoir. Air pressure in the oil reservoir forces oil through the oil cooler, thermostatic mixing valve, oil filter and into the compressor main oil gallery. The oil passes through internal passages for lubrication, cooling and sealing. The air-oil mixture is then discharged to the oil reservoir where a large part of the entrained oil drops out of the air stream; the air then passes through the final oil separator where most of the remaining oil is removed. The separated oil is returned to the compressor and the air passes to the final discharge line.

OIL SPECIFICATIONS — The recommended compressor lubricant is Gardner-Denver® "GD800 Lubricating Coolant" which can be used for year-round operation except as noted in the "High Temperature Operation" paragraph below. GD800 Lubricating Coolant is a superior petroleum base lubricant formulated and containing additives for use in Electra-Saver II® compressors.



CAUTION

Mixing of different types or the use of inferior lubricants will result in the formation of heavy varnish and sludge throughout the system.

SYNTHETIC LUBRICANTS — Certain synthetic lubricants, such as synthetic hydrocarbons, diesters or polyalphaolefins offer an extended drain interval when used in screw compressors. A superior diester lubricant is available in Gardner-Denver "GD8000 Lubricating Coolant" which can extend lubricant change interval from 2 to 4 times that of GD800. A good lubricant analysis program for periodic check of lubricant quality and remaining life can maximize the change interval.

See instructions on use of GD8000 in systems previously filled with other lubricants under "High Temperature Operation" below.

WARNING
 Do not mix GD800 and GD8000 Lubricating Coolants or other petroleum or syntehtic lubricants.

CAUTION
 Regardless of synthetic lubricant change interval used, oil filter and oil separator change intervals remain the same as for GD800 – See Maintenance Schedule, Section 8.

HIGH TEMPERATURE OPERATION — If the discharge temperature is sustained between 200-210° F for a period of more than four (4) hours due to continuing high ambient air or water temperatures, use Gardner-Denver “GD8000 Lubricating Coolant” which is a superior viscosity grade diester synthetic lubricant. Short periods of up to four (4) hours of sustained discharge temperatures up to 210° F do not require a change from the recommended year-round lubricant GD800

When installing GD8000, the original lubricant should be drained completely and the system flushed before filling with GD8000. Complete draining will involve removal of all plugs in compressor, oil reservoir and oil lines. In some cases, piping may require removal to insure complete draining. To insure complete removal of original lubricant, good practice indicates draining of the original lubricant, refill with GD8000, operation for 100 hours, then draining and final refill.

WARNING
 Do not mix GD800 and GD8000 Lubricating Coolants or other petroleum and synthetic lubricants.

WARNING
 Do not set the High Discharge Air Temperature switch above $\pm 225^{\circ}$ F to compensate for high temperature operation.

Use caution when selecting GD8000 lubricant as some down-stream air system components such as air line lubricator bowls, gaskets and valve trim may not be compatible. Check with the component supplier for suitability of the part with diester synthetic lubricant. All materials used in Electra-Saver II compressor units are compatible with GD8000.

COLD AMBIENT OPERATION — Gardner-Denver “GD800 Lubricating Coolant” must be used when the ambient temperature drops to +40° F in the space enclosing the compressor unit. See “Installation for Cold Weather Operation” in Section 2. If a synthetic lubricant is used, a lighter viscosity lubricant than Gardner-Denver GD8000 is necessary in the temperature range of +10° F to -40° F. The lighter viscosity lubricant must have foam depressant, oxidation and corrosion inhibiting characteristics equal to those of GD800 and meet these minimum specifications:

Viscosity at 100° F	140 SUS
Viscosity at 210° F	44 SUS
Pour Point	-60° F

ADDITION OF OIL BETWEEN CHANGES must be made when level of oil in the gauge is below the RUN range while the unit is operating.

DANGER
 Stop unit and be sure no air pressure is in the oil reservoir.

Wipe away all dirt around the oil filler plug (Figure 2-1). Remove the oil filler plug and add oil as required to return the oil level to the center of the RUN range when the unit is operating. The quantity required to raise the oil level from the bottom of the RUN range to the centerline of the RUN range is shown in Figure 3-5. Repeated addition of oil between oil changes may indicate excessive oil carryover and should be investigated.

OIL LEVEL GAUGE (Figure 2-1) indicates the amount of oil in oil reservoir. When unit is stopped the oil level will be higher in the RUN range than when operating on load. When unit is operating the oil level should be near the center of the RUN range. In operation the oil level will fluctuate slightly as the compressor loads and unloads. Add oil only when the oil level gauge indicates in the ADD OIL range when the compressor is loaded. Drain oil only when the oil level gauge indicates EXCESS OIL when the compressor is loaded. Note that top of the RUN range on oil level gauge decal is approximately centerline of filler elbow to prevent overfilling.

The oil level gauge is a tempered glass tube encased in a

Recommended Oil	Temperature Range
Gardner-Denver® GD800 Lubricating Coolant	Year-round operation at discharge temperatures to 200° F.
Gardner-Denver GD8000 Lubricating Coolant	Over four (4) hours sus- tained discharge tempera- ture between 200-210° F.

FIGURE 2-5. — COMPRESSOR LUBRICANT

Reservoir Capacity	10 U.S. Gallons
System Capacity	13 U.S. Gallons
Quantity Bottom Of Run To Centerline Of Run Range	1 U.S. Gallon

FIGURE 3-5. — OIL SYSTEM CAPACITIES

metal sleeve for maximum protection. Use caution when working near the gauge to prevent damage to the glass tube. If the glass tube should need replacement, use new gaskets in tube end caps. Lubricate the gasket faces with a thin coat of light oil, insert glass tube, install end caps finger tight, then wrench tighten 1/2-3/4 additional turn. When installing tube fittings to the gauge, hold end cap with one wrench and tighten fitting with a second wrench — use of only one wrench will overtighten end cap before fitting is tight.

MOISTURE IN THE OIL SYSTEM — In normal humidity and with normal operating temperatures and pressures, the thermal mixing valve controls the oil temperature and prevents moisture contamination of the oil. Unusual cooling of the oil reservoir, short loaded cycle in high humidity, malfunctions of the thermal valve or cooling water system may result in moisture in the oil system which would be detrimental to compressor lubrication. If moisture is observed in the oil reservoir, drain the moisture and correct the condition causing the accumulation. See "Compressor Oil System Check" and "Thermal Control (Thermostatic Mixing) Valve" in this section.

OIL CHANGE INTERVAL is determined by air filter maintenance, operating conditions and quality of oil. Good practice is to change oil often enough that the drained oil is relatively clean. Under good conditions Gardner-Denver® GD800 may be used up to 2000 hours of operation.

FILLING OIL RESERVOIR — When operating conditions are severe (very dusty, high humidity or high temperature) it will be necessary to change the oil more frequently. Operating conditions and appearance of drained oil must be surveyed and oil change intervals planned accordingly by the user. A good lubricant analysis program is helpful in planning the change interval. Change the oil filter every 1000 hours.



DANGER

Stop unit and be sure no air pressure is in the oil reservoir.

DRAINING AND CLEANING OIL SYSTEM — Always drain the complete system. Draining when the oil is hot will help to prevent varnish deposits and to carry away impurities. To drain the system, use one of the following methods:

If the unit is not elevated high enough to use the oil reservoir drain valve to drain oil, a small hand-, electric- or air-operated pump should be used to drain reservoir through the oil filler opening or from the drain valve. Remove oil cooler drain.

If the unit is elevated so that the oil reservoir drain can be used, empty the oil reservoir and then remove the oil cooler drain plug.

If the drained oil and/or the oil filter element are contaminated with dirt, flush the entire system: reservoir, oil cooler, mixing valve and lines. Inspect the oil separator elements for dirt accumulation; replace if necessary. If a varnish deposit exists, contact the factory for recommendations for removal of the deposit and prevention of varnish.




DANGER

Stop unit and be sure no air pressure is in the oil reservoir.


Wipe away all dirt before removing the oil filler plug. Refer to Figure 3-5 for the oil quantity required to fill the compressor oil system. This amount may bring the oil level into the EXCESS OIL range on the gauge. After a short time of operation, the oil level will drop into the RUN range as oil fills other parts of the system. Maintain the oil level in the RUN range. On unloaded operation and after shutdown some oil will drain back into the oil reservoir and the oil level gauge may read in EXCESS OIL range. **DO NOT DRAIN OIL TO CORRECT.** On the next start, oil will again fill the system and the gauge will indicate operating oil level. **DO NOT OVERFILL** as oil carry-over will result. Use only **CLEAN** containers and funnels so no dirt enters the reservoir. Provide for clean storage of oils. Changing oil will be of little benefit if done in a slipshod manner.

COMPRESSOR OIL FILTER (Figure 4-5) is a vital part in maintaining a trouble-free compressor, since it removes dirt and abrasives from the circulating oil. The filter is a replaceable element spin-on type and is equipped with a 15 PSI relief valve that opens in the event the element becomes dirty enough to block the flow of oil. **The element must be replaced every 1000 hours or sooner if the indicator on the filter body is in the RED range.** The unit must be running and warmed up for the indicator to read accurately.



B77096

FIGURE 4-5.
OIL FILTER



A58407

FIGURE 5-5.
THERMOSTATIC MIXING VALVE

Use only the replacement element shown on the filter tag or refer to the parts list for the part number.

COMPRESSOR OIL COOLER — RADIATOR TYPE (Figure 5-1) — The oil cooler fan is mounted to the compressor motor coupling and is guarded on both sides. Do not obstruct air flow to and from the oil cooler. Allow two (2) feet clearance at ends of the unit enclosure. Keep both faces of the oil cooler core clean for efficient cooling of the compressor oil.

THERMAL CONTROL (THERMOSTATIC MIXING) VALVE (Figure 5-5) is installed in system as shown in Figure 1-5. This valve is used to control temperature of the oil in both air-cooled radiator and water-cooled heat exchanger type oil cooler systems. On start-up with unit cold, element is open by bypass, allowing oil to pass directly from the reservoir to compressor during warm-up. As oil warms, element gradually closes to the bypass allowing more of the oil from the cooler to mix with oil from the bypass. After unit is warmed up, mixing valve maintains oil injection temperature into the compressor at a minimum of 150° F. This system provides proper compressor warm-up and prevents moisture contamination of the oil.

To check element, heat in oil — it should be fully extended at 150° F. If unit shuts down due to high air discharge temperature, the cause may be that the element is stuck open to the bypass, in which case lines 1 and 2 (Figure 1-5) will be hot to touch and lines 3 and 4 much cooler. When flushing the oil system, remove mixing valve and clean all parts thoroughly.

COMPRESSOR OIL COOLER — WATER-COOLED HEAT EXCHANGER (Figure 1-5) — The heat exchanger oil cooler is a multiple pass type with water in the tubes and oil in the shell. The oil temperature is controlled by the thermal control (thermostatic mixing) valve. The optional water control valve may be used to conserve water.

Oil cooler malfunction may be traced by checking pressure at oil inlet and outlet. Fittings at these locations are equipped with a 1/4 inch pipe tap for a gauge. At normal operating air service pressure (65 to 150 PSIG) with the unit warm, a pressure drop of 3 to 12 PSI can be expected between the oil inlet and the oil outlet.

Water pressure drop from water inlet to outlet will vary with the inlet pressure and amount of water flowing. A normal pressure drop may range from 5 to 10 PSI. Any change in the pressure drop from that normally held may indicate tube leakage or fouling and should be investigated.

In many instances, the cooling water supply for the heat exchanger will contain impurities in solution and/or suspension. These substances can cause scale formations, corrosion and plugging of any water-cooled heat exchanger equipment. Disregarding the possibility that one or more of these conditions exist may result in increased maintenance and operation expense, reduced equipment life and emergency shutdown. It is strongly recommended that a reputable, local water treatment concern be engaged to establish the corrosion, scale forming and fouling tendency of the cooling water and take steps necessary to remedy the situation if a problem does exist. The need for water treatment may involve only filtration (screening) to remove debris, sand and/or salt in the cooling water supply. However, chemical treatment methods may be necessary in certain instances to inhibit corrosion and/or remove dissolved solids to alter the water's tendency to form scale deposits, or prevent the growth of micro-organisms. The normal maintenance program for the unit should also include periodic cleaning of the tubes (water side) of the heat exchanger to remove deposits which enhance fouling and corrosion.

Hex head zinc anodes are used in the return bonnet (opposite end to the water pipe connections) of heat exchangers to provide internal water system corrosion protection. These anodes should be inspected periodically and replaced when the zinc has been reduced to about 1/2 inch in length.

WATER FLOW CONTROL VALVE FOR HEAT EXCHANGER (Optional Equipment) (Figure 6-5) — The water flow control valve is adjustable to compensate for varying water inlet temperatures and pressures. Use the compressor discharge air temperature gauge on the instrument panel in setting the flow control valve. The compressor discharge temperature must be maintained a minimum of 10° F above the dew point temperature at the maximum anticipated ambient; refer to Figure 7-5 for the dew point temperature at the operating pressure and ambient temperature of the application.

To decrease water flow (increase compressor discharge air temperature) turn the adjusting screw from left to right, increasing spring tension. **To increase water flow** (decrease compressor discharge air temperature) turn the adjusting screw in the opposite direction. The groove at the lower edge of the adjusting screw is an index line for use with the index scale 0 to 8 in obtaining a desired setting.

These valves must be handled with care and proper tools and techniques must be used when working on the valve. Care must be used when handling the capillary tube; a kink or break in the tubing or connections will make the valve inoperative. Never attempt to change capillary length. Excess capillary tube should be carefully coiled and placed so that damage will not occur in normal maintenance or traffic past the unit.

If a leak develops through the packing, tighten the packing gland nut firmly with a wrench to reseat the packing around the valve stem, then




FIGURE 6-5. —
WATER CONTROL VALVE

back off the nut until loose, and finally retighten the nut finger tight. Tightening the packing nut too tight may cause erratic operation. An occasional drop of oil on the valve stem at the packing nut will prolong packing life.

If the valve malfunctions, check for bent or binding (paint or corrosion) valve stem, foreign material in the valve, erosion, or thermal system (capillary) failure. If foreign material or scale is likely, the use of a strainer in the inlet water line is recommended.

WATER SHUTOFF VALVE — WATER-COOLED HEAT EXCHANGER (Optional Equipment) (Figure 1-5) — A magnetic solenoid-operated water shutoff valve rated at 150 PSIG water pressure should be mounted in the water inlet line ahead of the oil cooler. The valve should be wired into the compressor control circuit so that the valve opens to allow water to flow any time the ON-OFF pushbutton is ON and the compressor is running. When compressor stops under automatic control, or is shut off manually, the valve should close, stopping water flow through the system. See Wiring Diagrams in Section 4.

OIL RESERVOIR — The reservoir-separator combines two (2) functions into one vessel. The lower half is the oil reservoir, providing oil storage capacity for the system and a primary oil separation means. The upper half contains the final oil separator with the discharge manifold service line mounted on the upper flange. The reservoir also provides limited air storage for control and gauge actuation.

COMPRESSOR OIL SEPARATOR located in the upper half of the oil reservoir consists of a renewable cartridge-type separator element and provides the final removal of oil from the air stream (Figure 8-5).

Oil impinging on the outside of the separator element drains directly back into the oil reservoir by gravity. Oil collected inside the element is returned through tubing to the compressor cylinder.

Oil carry-over through the service lines may be caused by a faulty oil separator, faulty minimum pressure valve, overfilling of the oil reservoir, oil that foams, or oil return line malfunction. If oil carry-over occurs, inspect the separator only after it is determined that the oil level is not too high, the oil is not foaming excessively, the oil return line from the discharge manifold to the compressor cylinder is not clogged or pinched off, the return tube inside the separator is not loose or broken and is inserted to within 1/4"-1/2" of separator bottom.

Oil carry-over malfunctions of the oil separator are usually due to using the element too long, heavy dirt or varnish deposit caused by inadequate air filter service, use of improper oil or using oil too long for existing conditions. Ruptured or collapsed separator element is usually due to heavy dirt or varnish buildup in the filtering material. Excessive tilt angle of the unit will also hamper separation and cause oil carry-over.

Oil separator element life cannot be predicted; it will vary greatly depending on the conditions of operation, the quality of oil used and the maintenance of the oil and air filters. The condition of the separator can be determined by pressure differential gauging or by inspection.

Pressure Differential Gauging (Figure 2-1) — The discharge air pressure gauge located on the right side of the instrument panel is also used to determine the pressure differential across the oil separator during all conditions of operation. To check pressure differential across the oil separator, be sure the unit is loaded at operating pressure. Differential cannot be measured if unit is unloaded.

1. Note discharge air pressure gauge reading.
2. Press and hold "Push to Test" pushbutton at right of pressure gauge and note new reading.





FIGURE 7-5. — DEW POINT TEMPERATURE VS AMBIENT TEMPERATURE (100% RELATIVE HUMIDITY)



C77097

FIGURE 8-5. — OIL SEPARATOR

3. Subtract reading 1 from reading 2 for differential pressure.

The separator should be changed when the pressure differential reading reaches 8 PSI with the unit on load at 100 PSIG air discharge pressure.

NOTE:

Pressure differential on new elements is approximately 1-2 PSI. As the separator retains dirt, differential will rise. A sudden drop to ZERO differential or a sudden heavy oil carry-over may indicate a ruptured separator.

 **CAUTION** *Using an oil separator at differential pressure exceeding 8 PSI risks increasing oil carryover and collapse of the separator. Never use an oil separator at a pressure differential over 15 PSI.*

Inspection — After removal of the separator use a drop light inside the element to reveal areas of heavy dirt or varnish deposits or breaks (ruptures) in the element media.

Removal of Oil Separator For Inspection or Replacement:

1. Disconnect oil return to compressor tubing at tube elbow near discharge manifold flange on top plate.
2. Loosen nut on fitting at manifold flange and completely withdraw the tubing through the fitting.
3. Disconnect all other tubing from discharge manifold.
4. Disconnect discharge manifold pipe union.
5. Remove screws holding the top plate to the oil reservoir. Lift top plate from the oil reservoir.
6. Lift the separator from the oil reservoir.
7. Inspect and/or replace the separator as necessary. Before installing (or reinstalling) any separator be sure gaskets bonded to the separator flanges are not damaged. Remove any gasket material adhering to top plate or reservoir flange from old separator.
8. Lower separator into oil reservoir.
9. Seat top plate to oil reservoir flange; install and tighten all cap screws.
10. Reconnect the discharge manifold pipe union and all tubing.
11. Install original oil return by slipping tube through the fitting at the discharge manifold flange until ferrule bottoms in fitting. If a new fitting and return tube is used, slip tube through fitting until it touches the bottom of the separator, then raise the tube about 1/4 inch off the bottom and tighten fitting nut securely. Connect the other end of the tube to the compressor oil return tube elbow. Do not bend tube or raise further than 1/4"-1/2" from bottom of separator.
12. Reconnect compressor oil return tube to tube elbow.

COMPRESSOR OIL SYSTEM CHECK — The following readings are based on ambient temperature of 80° F for air-cooled oil cooler and 80° F inlet water on a water-cooled oil cooler with the system in good condition. Compressor should be at operating temperature at the time of checks. One-half hour of loaded operation is usually sufficient to reach level-out operating temperatures.

Air and Oil Discharge Temperature — 165° to 195° F — Read at thermometer on the instrument panel or check with a thermometer at the compressor discharge housing.

Compressor Oil Inlet Temperature — 150° to 160° F — Check with a thermometer in the tee out of oil filter.

Oil Inlet Pressure — Check at the fitting in the line near the compressor oil inlet. With air receiver pressure at 100 PSI, oil inlet pressure should be 55-60 PSIG.

Oil Cooler Oil Pressure Differential (Air-Cooled Radiator) — Oil cooler malfunction may be traced by checking oil pressure drop through the cooler by installing pressure gauges at the oil filter inlet tee and the oil reservoir drain valve. At normal operating air service pressures (65 to 150 PSIG) with the unit warm, a pressure drop of 18 to 35 PSIG can be expected between the two test points.

Oil Cooler Oil Pressure Differential (Water-Cooled Heat Exchanger) — 2 to 25 PSI (65 to 150 PSIG Receiver Pressure) — Check at the heat exchanger oil inlet and outlet fittings.

Oil Cooler Temperature Differential (Air-Cooled Radiator) — The oil temperature differential depends on the temperature

of the air at the oil cooler fan and cleanliness of the core faces. As ambient temperatures and core restrictions increase the oil cooler outlet temperature will increase. The oil inlet temperature to the cooler is approximately the same as air discharge temperature — see gauge on instrument panel. The inlet oil temperature and the outlet oil temperature may be checked at the fittings in the oil piping.

Oil Cooler Temperature Differential (Water-Cooled Heat Exchanger) — The oil temperature differential depends on the inlet water temperature and the water flow rate permitted by the water flow control valve setting. The oil inlet temperature to the cooler is approximately the same as air discharge temperature — see gauge on instrument panel. The oil outlet temperature may be checked at the cooler outlet.

Oil Cooler Water Pressure Differential (Water-Cooled Heat Exchanger) — The water pressure differential through the heat exchanger will depend on supply pressure, flow rate, cooler tube cleanliness and outlet pressure. The inlet and outlet water pressures may be checked at pipe fittings and supplied by the customer.

SECTION 6

AIR FILTERS

AIR FILTER (Figure 1-6) furnished as standard equipment is a washable element dry type filter. The air filter must receive proper maintenance if maximum service is to be obtained from the unit. Establishing adequate and timely filter service is **MOST IMPORTANT**. When the outside surface of the element appears to be evenly coated with dirt, it should be cleaned as follows:

1. Remove the wing bolt, lift off top and filter element.
2. Vibrate or blow heavy dirt accumulations from element. Direct air blast at slight inward angle and parallel to element pleats; do not point directly at the element.
3. If required, wash element with a nonsudsing household detergent and water; rinse with clear water. Allow to dry before reinstalling.

C76532




FIGURE 1-6. — DRY TYPE AIR FILTER



WARNING

DO NOT USE OIL, GASOLINE, OR OILY WASTE TO CLEAN.

Replace the element after five (5) cleanings, or if the filter media or seal at the ends are damaged, or if the element cannot be thoroughly cleaned.

Replace the filter element with genuine replacement parts whenever needed. Good judgment should be used in establishing the replacement interval. Do not attempt to over-extend the element life; the small savings involved do not justify the risk.



CAUTION

Do not run the unit with damaged filter or filter parts. Always handle filter parts with care.

C74831




FIGURE 2-6. — HEAVY-DUTY AIR FILTER

Causes of short element life include: severe dust conditions, infrequent servicing, improper cleaning, or contamination by oil or chemical fumes.

HEAVY-DUTY AIR FILTER (Figure 2-6) — Extremely dusty locations require a heavy-duty two-stage dry type air filter. If a unit has been so equipped, service the filter as follows:

Dust Cup — Service every 4 to 120 hours depending on dust conditions. To service, loosen the retaining band clamp and remove the dust cup. Do not wash the dust cup — wipe clean with a clean dry cloth. Do not bend the edge of the cup by striking on a hard surface. When installing the dust cup, make sure the clamp is securely tightened to prevent leakage.

Filter Element — The element should be serviced when the pressure drop through the filter reaches 20 inches of water or when service indicates time for change. Clean every 50 to 150 operating hours depending on dust conditions. Inspect every few days until experience determines the proper time for servicing. Higher than normal current use by the motor or loss of compressor delivery may indicate a need for servicing the filter element.

- a. Loosen the retaining band clamp and remove the dust cup from the body of the filter.
- b. Visually inspect the element in place. If cleaning is not necessary, reinstall the dust cup on the filter. If the element required cleaning, unscrew the wing bolt and withdraw the element from the body.
- c. Wash the element by soaking about 15 minutes in warm water with a mild nonsudsing detergent. Rinse the element thoroughly with clean water; a hose may be used if the water pressure does not exceed 40 PSIG.
- d. Inspect the element for ruptures or cracks in the pleated media; replace the element if any are found. Inspect the gasket on the bottom (outlet end) of the element; replace the entire element if the gasket is damaged.

- e. Allow the element to air dry COMPLETELY. Do not expose the element to heat over 150° F. Install the element in the filter body and fasten securely with the wing bolt. Reinstall the dust cup and retaining band clamp. Make sure the clamp is tightened securely to prevent leakage.



WARNING

Do not oil this element. Do not wash in other cleaning fluids.



CAUTION

Never operate the unit without the element. Never use elements that are damaged, ruptured or wet. Never use gaskets that won't seal. Keep spare elements and gaskets on hand to reduce downtime. Store elements in a protected area free from damage, dirt and moisture. Handle all parts with care.

Filter Element Life — The element should be replaced after six (6) cleanings or if:

- a. Visual inspection indicates a rupture, crack or pin hole in the pleated media. Inspection should be done by placing a bright light inside the element.
- b. Pressure drop through a filter with a freshly cleaned element is below three (3) inches of water with compressor running at full load — this would indicate a rupture or crack.

Inlet Screen and Tube — Inspect the inlet screen and tube for dirt accumulation each time the filter is serviced. Clean the tube when required by ramming a clean dry cloth through the tube. Wipe the inside of the filter body to remove any dirt falling from the inlet tube before reinstalling the element.

SECTION 7

COUPLING




FIGURE 1-7. — COUPLING

COUPLING (Figure 1-7) — The motor and compressor are direct connected by a resilient cushion-type flexible coupling. The coupling does not require lubrication. On all models the coupling cushion member is a one-piece spider-type construction.



CAUTION

The coupling is aligned at the factory. However, since there may have been settling or deflection of the unit through shipment or handling, rechecking coupling alignment is required; refer to Steps 4 through 8 below.

For cases where the motor or the compressor has been removed from the base, proceed as follows for coupling alignment

1. Install motor and/or compressor on mounting pads of base, making sure coupling spider is in place and engage coupling. If shims were used under motor or compressor feet be sure they are in place.




CAUTION

A new compressor or motor may have a different shaft height than the previous one and require entirely new shims.


Install screws in compressor feet and tighten. In unusual cases, it may be necessary to shim and adjust the compressor; however, best alignment procedure is for the compressor to remain fixed while the adjustments/shims

are made on the motor.


2. Position the coupling body on each shaft (motor and compressor) so that shaft ends are about flush with the face of the body, and flanges rest snugly against the raised dots on the coupling spider faces. When positioning either coupling half on the shaft, make sure the shaft doesn't extend through the coupling to interfere with the spider. Approximate distance between shafts is one (1) inch. Tighten the set screws over the key in each coupling body.
3. Check angular alignment (Figure 2-7, View B) by attaching a dial indicator as shown; base and stem attached to the body of one coupling half, the indicator button resting on the face of the flange of the opposite half. Rotate the coupling and indicator assembly to the top 12 o'clock position and zero the dial. Be sure that the dial button is firmly in contact with the face and that sufficient indicator travel is possible. Tap the indicator face several times to insure return to zero. Rotate the coupling and indicator assembly to the 3, 6 and 9 o'clock positions and record indicator reading at each point. **Maximum allowable indicator reading is .010"**. Shim (or lower) motor vertically and/or adjust from side to side until indicator reading is .010" or less.
4. Check parallel alignment (Figure 2-7, View C) by attaching a dial indicator as shown: base and stem attached to the body of one coupling half, the indicator button resting on the outside diameter of the opposite half. Rotate the coupling and indicator assembly to the top 12 o'clock position and zero the dial. Observe the cautions about firm indicator button contact, indicator travel and zeroing outlined in Step 3. Rotate the coupling and indicator assembly to the 3, 6 and 9 o'clock positions and record the indicator reading at each point. **The maximum allowable indicator reading is .010"**. Shim (or lower) motor vertically and/or adjust from side to side until indicator reading is .010" or less.
5. Recheck angular alignment to be sure it has not been disturbed.
6. Tighten screws in motor feet evenly. Recheck tightness of screws in compressor feet and in the coupling body.
7. Recheck coupling alignment and adjust if necessary.



ALIGNED



ANGULAR ALIGNMENT



PARALLEL ALIGNMENT

NOTE: MISALIGNMENT CONDITIONS ARE EXAGGERATED FOR CLARITY.

D76865

FIGURE 2-7. — ALIGNMENT OF COUPLING

SECTION 8

MAINTENANCE SCHEDULE

SERVICE CHECK LIST —

Air Filter — Operating conditions determine frequency of service, refer to Section 6 “Air Filter”, and plan maintenance accordingly.

Oil Separator — The unit is equipped with pressure differential gauging. Change the oil separator element when the pressure differential reaches 8 PSI. Refer to “Compressor Oil Separator” in Section 5 for further details.

Motor Lubrication — Refer to Section 2.

Every 8 Hours Operation

1. Check the reservoir oil level — add oil if required. See Section 5. If oil consumption is high, refer to “Compressor Oil Consumption” in Section 9.
2. Observe if the unit loads and unloads properly.
3. Drain the line filter in the control system. See Section 4.
4. If moisture is noted in the oil level gauge, drain accumulated moisture and see Section 5, “Moisture in the Oil System”.

Every 125 Hours Operation

1. Check for dirt accumulation on oil cooler and aftercooler core faces and the cooling fan. If cleaning is required, clean the exterior fin surfaces of the cores by blowing compressed air carrying a nonflammable safety solvent in a direction opposite that of the cooling fan air flow. This cleaning operation will keep the exterior cooling surfaces clean and ensure effective heat dissipation.

Every 1000 Hours Operation

1. Change oil filter element every 1000 hours or when the indicator on filter body is in red range, whichever occurs first.

Every 2000 Hours Operation

1. If using GD800 Lubricant Coolant, change the compressor lubricant. UNDER ADVERSE CONDITIONS, CHANGE MORE FREQUENTLY (refer to “Oil Change Interval” in Section 5). Flush system if required.
2. The use of GD8000 Lubricating Coolant or other synthetic lubricant may extend the required change interval. See “Synthetic Lubricants” in Section 5.

Every 4000 Hours Operation

1. Check the oil separator element. See Section 5.

SECTION 9

TROUBLE SHOOTING

IF UNIT FAILS TO START, check:

1. Wiring system for wrong lead connections.
2. Unit Start/Stop-Reset (ON-OFF-RESET) switch.
3. Fuses in control enclosure or starter enclosure.
4. Motor starter overload heaters.
5. Air pressure switch setting.

UNIT STARTS BUT STOPS AFTER A SHORT RUN, check:

1. High air discharge temperature caused by:
 - a. Low compressor oil level.
 - b. Clogged oil cooler or oil filter.
 - c. Thermal control (thermostatic mixing) valve stuck.
 - d. Accumulation of grease, oil or dirt on exterior fin surfaces of oil cooler.
 - e. Poor ventilation of unit.
 - f. Water control valve inoperative or water inlet temperature too high.
 - g. Magnetic water shutoff valve inoperative.
2. Reservoir pressure switch setting.
3. Low oil pressure or faulty low oil pressure switch.
4. High discharge temperature switch malfunction.
5. Fuses in control panel enclosure or starter enclosure.
6. Motor starter overloads.
7. Time delay too short on low oil pressure timing relay or faulty timing relay.

COMPRESSOR DOES NOT UNLOAD, check:

1. Low demand 4-way valve or pressure switch for malfunction.
2. Control lines for restriction.
3. Air leaks in control system.
4. Inlet valve struck.
5. Pilot or low demand pressure switch adjustment.
6. Pilot or low demand pressure switch for dirt or leaking diaphragm.

UNIT FAILS TO SHUT DOWN, check:

1. Start/Stop-Reset (ON-OFF-RESET) switch for malfunction.
2. Control lines for restriction or leaks.
3. Low demand pressure switch for dirt or leaking diaphragm.
4. Wiring and tubing to low demand pressure switch.

BLOWDOWN VALVE CONTINUES TO PASS AIR, check for:

1. Air leaks in tubing to blowdown valve.
2. Leaking diaphragm in blowdown valve.
3. Low demand 4-way valve for malfunction, coil failure or loose wiring.

EXCESSIVE OIL CONSUMPTION, check for:

1. Oil carry-over through discharge line caused by:
 - a. Overfilling the reservoir.
 - b. Clogged, broken or loose oil return lines.
 - c. Ruptured oil separator element.
 - d. Loose assembly.
 - e. Incorrect oil causing foam.
 - f. Inoperative minimum pressure valve.
 - g. Dip tube not on bottom of separator.
2. Oil leaks at all fittings and gaskets.

COMPRESSOR LOW ON DELIVERY AND PRESSURE, check for:

1. Clogged air filter.
2. Restricted inlet valve.
3. Broken inlet valve spring.
4. Binding inlet valve piston.
5. Incorrect motor speed.
6. Pilot adjustment and/or malfunction.
7. Minimum pressure valve stuck closed.

SECTION 10

REBUILDING DATA

Rebuilding data for Model SSHM intensive injection bare compressor used in unit Models ECH_HE and ECH_JE is shown below.

(Dimensions in two [2] decimal places may vary ± 0.020 .)

DIMENSIONS	DIMENSIONS (Continued)
Center of Main Bore to Center of Secondary Bore	Secondary Rotor Shaft Bearing Journal Diameter —
. 5.374/5.376	Inlet 1.9696/1.9690
Cylinder Bore Diameter —	Discharge 2.1666/2.1659
Main 6.9997/7.0029	Secondary Rotor Shaft Bearing Journal Length* —
Secondary 6.4562/6.4594	Inlet83
Cylinder Length 12.156/12.152	Discharge 1.78
Rotor Body O.D. —	Main Rotor Bearing Bore Diameter —
Main 6.9916/6.9911	Inlet 4.3307/4.3321
Secondary 6.4492/6.4484	Discharge 4.8730/4.8740
Main Rotor Body Length 12.136/12.134	Secondary Rotor Bearing Bore Diameter —
Secondary Rotor Body Length Note 1	Inlet 3.5433/3.5447
Main Rotor Air Seal Diameter (Inlet and Discharge)	Discharge 3.5435/3.5445
. 2.750/2.749	Main Rotor Bearing Bore Depth* —
Secondary Rotor Air Seal Diameter (Inlet and Discharge)	Inlet 1.07
. 2.750/2.749	Discharge 1.05
Main Rotor Air Seal Bore (Inlet and Discharge)	Secondary Rotor Bearing Bore Depth* —
. 2.760/2.761	Inlet79
Secondary Rotor Air Seal Bore (Inlet and Discharge)	Discharge 1.85
. 2.760/2.761	Drive Shaft Coupling Diameter 1.7495/1.7490
Main Rotor Air Seal Bore Length* —	Drive Shaft Seal Diameter 1.876/1.874
Inlet 1.00	Drive Shaft Coupling Diameter Length* 3.30
Discharge90	Drive Shaft Seal Diameter Length* 2.25
Secondary Rotor Air Seal Bore Length* —	Seal Housing Seal Bore 2.624/2.626
Inlet 1.00	Seal Housing Seal Bore Depth*50
Discharge90	Main Rotor Inlet Bearing Snap Ring Groove —
Main Rotor Shaft Bearing Journal Diameter —	Diameter 4.454/4.466
Inlet 1.9696/1.9690	Width068/.073
Discharge 2.1265/2.1260	Secondary Rotor Inlet Bearing Snap Ring Groove —
Main Rotor Shaft Bearing Journal Length* —	Diameter 3.647/3.659
Inlet98	Width068/.073
Discharge 1.48	

* Includes any radii, chamfer or undercut.

NOTE 1: Secondary rotor body length will vary depending on design horsepower and pressure rating. Commonly used lengths include 12.136/12.134, 11.520/11.480, 10.720/10.680, 9.020/8.980.

FITS

Secondary Rotor Bearing Inner Race to Shaft —	
Inlet	.0005T/.0016T
Discharge	.0005T/.0018T
Secondary Rotor Bearing Outer Face to Shaft —	
Inlet	.0000/.0020L
Discharge	.0002L/.0020L
Main Rotor Bearing Inner Race to Shaft —	
Inlet	.0005T/.0016T
Discharge	.0005T/.0015T
Main Rotor Bearing Outer Race to Bare —	
Inlet	.0000/.0020L
Discharge	.0010T/.0030T

FITS (Continued)

Drive Shaft to Coupling	.0005/.0020L
-----------------------------------	--------------

RUNNING CLEARANCES

Rotor to Cylinder — Diametral — Main and Secondary	
.	.007/.011
End Plate to Rotor — Axial —	
Inlet	.012/.020
Discharge	.002/.004
Air Seals — Diametral	
.	.009/.011

Litho in U.S.A.

1M-10-83



GARDNER-DENVER

INDUSTRIAL MACHINERY DIVISION

1800 GARDNER EXPRESSWAY • QUINCY, ILLINOIS 62301 • (217) 222-5400

SALES AND SERVICE OFFICES IN ALL PRINCIPAL CITIES