




USER MANUAL

INDUSTRIAL AIR COMPRESSOR
3000, 3000P, 3700, 4500
3000V, 3000PV, 3700V, 4500V
30, 37 & 45 kW/40, 50 & 60HP



WARRANTY NOTICE

Failure to follow the instructions
and procedures in this manual or,
misuse of this equipment will
VOID its warranty!

PART NUMBER:
02250176-182 R00

KEEP FOR
FUTURE
REFERENCE

©SULLAIR CORPORATION

The information in this manual is current
as of its publication date, and applies to
compressor **serial number:**

200804210000

and all subsequent serial numbers.



AIR CARE SEMINAR TRAINING

Sullair Air Care Seminars are courses that provide hands-on instruction for the proper operation, maintenance, and servicing of Sullair products. Individual seminars on Industrial compressors and compressor electrical systems are offered at regular intervals throughout the year at Sullair's corporate headquarters training facility located at Michigan City, Indiana.

Instruction includes training on the function and installation of Sullair service parts, troubleshooting common faults and malfunctions, and actual equipment operation. These seminars are recommended for maintenance, contractor maintenance, and service personnel.

For detailed course outlines, schedule, and cost information contact:

SULLAIR CUSTOMER CARE TRAINING DEPARTMENT

1-888-SULLAIR or
219-879-5451 (ext. 5623)
www.sullair.com

- Or Write -

Sullair Corporation
3700 E. Michigan Blvd.
Michigan City, IN 46360
Attn: Service Training Department.



TABLE OF CONTENTS

SECTION 1—SAFETY

5	1.1	GENERAL
5	1.2	PERSONAL PROTECTIVE EQUIPMENT
5	1.3	PRESSURE RELEASE
6	1.4	FIRE AND EXPLOSION
6	1.5	MOVING PARTS
7	1.6	HOT SURFACES, SHARP EDGES AND SHARP CORNERS
7	1.7	TOXIC AND IRRITATING SUBSTANCES
8	1.8	ELECTRICAL SHOCK
8	1.9	LIFTING
9	1.10	ENTRAPMENT

SECTION 2—DESCRIPTION

11	2.1	INTRODUCTION
12	2.2	DESCRIPTION OF COMPONENTS
13	2.3	SULLAIR COMPRESSOR UNIT, FUNCTIONAL DESCRIPTION
16	2.4	COMPRESSOR COOLING AND LUBRICATION SYSTEM, FUNCTIONAL DESCRIPTION
16	2.5	COMPRESSOR DISCHARGE SYSTEM, FUNCTIONAL DESCRIPTION
17	2.6	CONTROL SYSTEM, FUNCTIONAL DESCRIPTION
19	2.7	AIR INLET SYSTEM, FUNCTIONAL DESCRIPTION
20	2.8	INTEGRAL DRYER OPTION

SECTION 3—SPECIFICATIONS

21	3.1	TABLE OF SPECIFICATIONS—3000, 3000P, 3700 AND 4500 SERIES MODELS
22	3.2	TABLE OF SPECIFICATIONS—VARIABLE SPEED DRIVE MODELS
23	3.3	COMPRESSOR SPECIFICATIONS
24	3.4	LUBRICATION GUIDE
24	3.5	APPLICATION GUIDE
25	3.6	LUBRICATION CHANGE RECOMMENDATIONS AND MAINTENANCE, FLUID
26	3.7	IDENTIFICATION, AIR-COOLED

TABLE OF CONTENTS

28	3.8	IDENTIFICATION, WATER-COOLED
30	3.9	IDENTIFICATION, AIR-COOLED W/ INTEGRAL DRYER
32	3.10	PIPING AND INSTRUMENTATION, AIR-COOLED
36	3.11	PIPING AND INSTRUMENTATION, WATER-COOLED
40	3.12	WIRING DIAGRAM, VSD AIR-COOLED
42	3.13	WIRING DIAGRAM, AIR-COOLED MFV WITH INTEGRAL DRYER
44	3.14	WIRING DIAGRAM, AIR-COOLED MFV

SECTION 4—INSTALLATION

47	4.1	MOUNTING OF COMPRESSOR
47	4.2	VENTILATION AND COOLING
51	4.3	SERVICE AIR PIPING
53	4.4	COUPLING ALIGNMENT CHECK
53	4.5	FLUID LEVEL CHECK
53	4.6	ELECTRICAL PREPARATION
54	4.7	MOTOR ROTATION DIRECTION CHECK

SECTION 5—WS CONTROLLER

55	5.1	CONTROLLER LAYOUT
55	5.2	CONTROLLER KEYPAD
56	5.3	LCD DISPLAY
57	5.4	LED LIGHTS

SECTION 6—MAINTENANCE


59	6.1	GENERAL
59	6.2	DAILY OPERATION
59	6.3	MAINTENANCE AFTER INITIAL 50 HOURS OF OPERATION
60	6.4	MAINTENANCE EVERY 2000 HOURS
60	6.5	FLUID MAINTENANCE
60	6.6	FILTER MAINTENANCE
60	6.7	AIR FILTER MAINTENANCE
61	6.8	SEPARATOR MAINTENANCE
63	6.9	TROUBLESHOOTING— INTRODUCTION
64	6.10	TROUBLESHOOTING GUIDE

SECTION 7—OPERATION

67	7.1	DESCRIPTION OF COMPONENTS
67	7.2	CONTROL SYSTEM, FUNCTIONAL DESCRIPTION

Section 1

SAFETY



1.1 GENERAL

Sullair Corporation and its subsidiaries design and manufacture all of their products so they can be operated safely. However, the responsibility for safe operation rests with those who use and maintain these products. The following safety precautions are offered as a guide which, if conscientiously followed, will minimize the possibility of accidents throughout the useful life of this equipment.

The compressor should be operated only by those who have been trained and delegated to do so, and who have read and understood this Operator's Manual. Failure to follow the instructions, procedures and safety precautions in this manual may result in accidents and injuries. **NEVER** start the compressor unless it is safe to do so. **DO NOT** attempt to operate the compressor with a known unsafe condition. Tag the compressor and render it inoperative by disconnecting and locking out all power at source or otherwise disabling its prime mover so others who may not know of the unsafe condition cannot attempt to operate it until the condition is corrected.

Install, use and operate the compressor only in full compliance with all pertinent OSHA regulations and/or any applicable Federal, State, and Local codes, standards and regulations. **DO NOT** modify the compressor and/or controls in any way except with written factory approval.

While not specifically applicable to all types of compressors with all types of prime movers, most of

the precautionary statements contained herein are applicable to most compressors and the concepts behind these statements are generally applicable to all compressors.

1.2 PERSONAL PROTECTIVE EQUIPMENT

- A. Prior to installing or operating the compressor, owners, employers and users should become familiar with, and comply with, all applicable OSHA regulations and/or any applicable Federal, State and Local codes, standards, and regulations relative to personal protective equipment, such as eye and face protective equipment, respiratory protective equipment, equipment intended to protect the extremities, protective clothing, protective shields and barriers and electrical protective equipment, as well as noise exposure administrative and/or engineering controls and/or personal hearing protective equipment.

1.3 PRESSURE RELEASE

- A. Install an appropriate flow-limiting valve between the service air outlet and the shut-off (throttle) valve, either at the compressor or at any other point along the air line, when an air hose exceeding 1/2" (13mm) inside diameter is to be connected to the shut-off (throttle) valve, to reduce pressure in case of hose failure, per OSHA Standard 29 CFR 1926.302(b)(7) and/or any applicable Federal, State and Local codes, standards and regulations.
- B. When the hose is to be used to supply a manifold, install an additional appropriate flow-limiting valve between the manifold and each air hose exceeding 1/2" (13mm) inside diameter that is to be connected to the manifold to reduce pressure in case of hose failure.
- C. Provide an appropriate flow-limiting valve at the beginning of each additional 75 feet (23m) of hose in runs of air hose exceeding 1/2" (13mm)

inside diameter to reduce pressure in case of hose failure.

- D. Flow-limiting valves are listed by pipe size and flow-rated. Select appropriate valves accordingly, in accordance with their manufacturer's recommendations.
- E. **DO NOT** use air tools that are rated below the maximum rating of the compressor. Select air tools, air hoses, pipes, valves, filters and other fittings accordingly. **DO NOT** exceed manufacturer's rated safe operating pressures for these items.
- F. Secure all hose connections by wire, chain or other suitable retaining device to prevent tools or hose ends from being accidentally disconnected and expelled.
- G. Open fluid filler cap only when compressor is not running and is not pressurized. Shut down the compressor and bleed the receiver tank to zero internal pressure before removing the cap.
- H. Vent all internal pressure prior to opening any line, fitting, hose, valve, drain plug, connection or other component, such as filters and line oilers, and before attempting to refill optional air line anti-icer systems with antifreeze compound.
- I. Keep personnel out of line with and away from the discharge opening of hoses or tools or other points of compressed air discharge.
- J. **DO NOT** use air at pressures higher than 2.1 bar for cleaning purposes, and then only with effective chip guarding and personal protective equipment per OSHA Standard 29 CFR 1910.242 (b) and/or any applicable Federal, State, and Local codes, standards and regulations.
- K. **DO NOT** engage in horseplay with air hoses as death or serious injury may result.

1.4 FIRE AND EXPLOSION

- A. Clean up spills of lubricant or other combustible substances immediately, if such spills occur.
- B. Shut off the compressor and allow it to cool. Then keep sparks, flames and other sources of ignition away and **DO NOT** permit smoking in the vicinity when checking or adding lubricant or when refilling air line anti-icer systems with antifreeze compound.
- C. **DO NOT** permit fluids, including air line anti-icer system antifreeze compound or fluid film, to

accumulate on, under or around acoustical material, or on any external surfaces of the air compressor. Wipe down using an aqueous industrial cleaner or steam clean as required. If necessary, remove acoustical material, clean all surfaces and then replace acoustical material. Any acoustical material with a protective covering that has been torn or punctured should be replaced immediately to prevent accumulation of liquids or fluid film within the material. **DO NOT** use flammable solvents for cleaning purposes.

- D. Disconnect and lock out all power at source prior to attempting any repairs or cleaning of the compressor or of the inside of the enclosure, if any.
- E. Keep electrical wiring, including all terminals and pressure connectors in good condition. Replace any wiring that has cracked, cut, abraded or otherwise degraded insulation, or terminals that are worn, discolored or corroded. Keep all terminals and pressure connectors clean and tight.
- F. Keep grounded and/or conductive objects such as tools away from exposed live electrical parts such as terminals to avoid arcing which might serve as a source of ignition.
- G. Remove any acoustical material or other material that may be damaged by heat or that may support combustion and is in close proximity, prior to attempting weld repairs.
- H. Keep suitable fully charged Class BC or ABC fire extinguisher or extinguishers nearby when servicing and operating the compressor.
- I. Keep oily rags, trash, leaves, litter or other combustibles out of and away from the compressor.
- J. **DO NOT** operate the compressor without proper flow of cooling air or water or with inadequate flow of lubricant or with degraded lubricant.
- K. **DO NOT** attempt to operate the compressor in any classification of hazardous environment unless the compressor has been specially designed and manufactured for that duty.

1.5 MOVING PARTS

- A. Keep hands, arms and other parts of the body and also clothing away from couplings, fans and other moving parts.
- B. **DO NOT** attempt to operate the compressor with the fan, coupling or other guards removed.

SECTION 1

- C. Wear snug-fitting clothing and confine long hair when working around this compressor, especially when exposed to hot or moving parts.
- D. Keep access doors, if any, closed except when making repairs or adjustments.
- E. Make sure all personnel are out of and/or clear of the compressor prior to attempting to start or operate it.
- F. Disconnect and lock out all power at source and verify at the compressor that all circuits are de-energized to minimize the possibility of accidental start-up, or operation, prior to attempting repairs or adjustments. This is especially important when compressors are remotely controlled.
- G. Keep hands, feet, floors, controls and walking surfaces clean and free of fluid, water or other liquids to minimize the possibility of slips and falls.

1.6 HOT SURFACES, SHARP EDGES AND SHARP CORNERS

- A. Avoid bodily contact with hot fluid, hot coolant, hot surfaces and sharp edges and corners.
- B. Keep all parts of the body away from all points of air discharge.
- C. Wear personal protective equipment including gloves and head covering when working in, on or around the compressor.
- D. Keep a first aid kit handy. Seek medical assistance promptly in case of injury. **DO NOT** ignore small cuts and burns as they may lead to infection

1.7 TOXIC AND IRRITATING SUBSTANCES

- A. **DO NOT** use air from this compressor for respiration (breathing) except in full compliance with OSHA Standards 29 CFR 1910 and/or any applicable Federal, State or Local codes or regulations.

 **DANGER**



Death or serious injury can result from inhaling compressed air without using proper safety equipment. See OSHA standards and/or any applicable Federal, State, and Local codes, standards and regulations on safety equipment.

- B. **DO NOT** use air line anti-icer systems in air lines supplying respirators or other breathing air utilization equipment and **DO NOT** discharge air from these systems into unventilated or other confined areas.
- C. Operate the compressor only in open or adequately ventilated areas.
- D. Locate the compressor or provide a remote inlet so that it is not likely to ingest exhaust fumes or other toxic, noxious or corrosive fumes or substances.
- E. Coolants and lubricants used in this compressor are typical of the industry. Care should be taken to avoid accidental ingestion and/or skin contact. In the event of ingestion, seek medical treatment promptly. Wash with soap and water in the event of skin contact. Consult Material Safety Data Sheet for information pertaining to fluid of fill.
- F. Wear goggles or a full face shield when adding antifreeze compound to air line anti-icer systems.
- G. If air line anti-icer system antifreeze compound enters the eyes or if fumes irritate the eyes, they should be washed with large quantities of clean water for fifteen minutes. A physician, preferably an eye specialist, should be contacted immediately.
- H. **DO NOT** store air line anti-icer system antifreeze compound in confined areas.
- I. The antifreeze compound used in air line anti-freeze systems contains methanol and is toxic, harmful or fatal if swallowed. Avoid contact with the skin or eyes and avoid breathing the fumes. If

swallowed, induce vomiting by administering a tablespoon of salt, in each glass of clean, warm water until vomit is clear, then administer two teaspoons of baking soda in a glass of clean water. Have patient lay down and cover eyes to exclude light. Call a physician immediately.

1.8 ELECTRICAL SHOCK

- A. This compressor should be installed and maintained in full compliance with all applicable Federal, State and Local codes, standards and regulations, including those of the National Electrical Code, and also including those relative to equipment grounding conductors, and only by personnel that are trained, qualified and delegated to do so.
- B. Keep all parts of the body and any hand-held tools or other conductive objects away from exposed live parts of electrical system. Maintain dry footing, stand on insulating surfaces and **DO NOT** contact any other portion of the compressor when making adjustments or repairs to exposed live parts of the electrical system. Make all such adjustments or repairs with one hand only, so as to minimize the possibility of creating a current path through the heart.
- C. Attempt repairs in clean, dry and well lighted and ventilated areas only.
- D. **DO NOT** leave the compressor unattended with open electrical enclosures. If necessary to do so, then disconnect, lock out and tag all power at source so others will not inadvertently restore power.
- E. Disconnect, lock out, and tag all power at source prior to attempting repairs or adjustments to rotating machinery and prior to handling any ungrounded conductors.

DANGER

All field equipment must be tested for electrostatic fields prior to servicing or making contact with the machine using the following or equivalent test equipment:

- **90-600 VAC: Volt detector such as Fluke Model 1AC-A**
- **600-7000 VAC: Voltage detector such as Fluke Networks Model C9970**

It is the responsibility of each organization to provide/arrange training for all their associates expected to test for electrostatic fields.

1.9 LIFTING

- A. If the compressor is provided with a lifting bail, then lift by the bail provided. If no bail is provided, then lift by sling. Compressors to be air-lifted by helicopter must not be supported by the lifting bail but by slings instead. In any event, lift and/or handle only in full compliance with OSHA standards 29 CFR 1910 subpart N and/or any applicable Federal, State, and Local codes, standards and regulations.
- B. Inspect points of attachment for cracked welds and for cracked, bent, corroded or otherwise degraded members and for loose bolts or nuts prior to lifting.
- C. Make sure entire lifting, rigging and supporting structure has been inspected, is in good condition and has a rated capacity of at least the weight of the compressor. If you are unsure of the weight, then weigh compressor before lifting.
- D. Make sure lifting hook has a functional safety latch or equivalent, and is fully engaged and latched on the bail or slings.
- E. Use guide ropes or equivalent to prevent twisting or swinging of the compressor once it has been lifted clear of the ground.
- F. **DO NOT** attempt to lift in high winds.
- G. Keep all personnel out from under and away from the compressor whenever it is suspended.
- H. Lift compressor no higher than necessary.

SECTION 1

- I. Keep lift operator in constant attendance whenever compressor is suspended.
- J. Set compressor down only on a level surface capable of safely supporting at least its weight and its loading unit.
- K. When moving the compressor by forklift truck, utilize fork pockets if provided. Otherwise, utilize pallet if provided. If neither fork pockets or pallet are provided, then make sure compressor is secure and well balanced on forks before attempting to raise or transport it any significant distance.
- L. Make sure forklift truck forks are fully engaged and tipped back prior to lifting or transporting the compressor.
- M. Forklift no higher than necessary to clear obstacles at floor level and transport and corner at minimum practical speeds.
- N. Make sure pallet-mounted compressors are firmly bolted or otherwise secured to the pallet prior to attempting to forklift or transport them. **NEVER** attempt to forklift a compressor that is not secured to its pallet, as uneven floors or sudden stops may cause the compressor to tumble off, possibly causing serious injury or property damage in the process.

1.10 ENTRAPMENT

- A. If the compressor enclosure, if any, is large enough to hold a man and if it is necessary to enter it to perform service adjustments, inform other personnel before doing so, or else secure and tag the access door in the open position to avoid the possibility of others closing and possibly latching the door with personnel inside.
- B. Make sure all personnel are out of compressor before closing and latching enclosure doors.

NOTES


Section 2

DESCRIPTION

2.1 INTRODUCTION


Your new Sullair flood-lubricated rotary screw air compressor will provide you with a unique experience in improved reliability and simplified maintenance. Compared to other types of compressors, the Sullair rotary screw is unique in

mechanical reliability, with "no wear" and "no inspection" required of the working parts within the compressor unit. Read *Maintenance* on page 59 to see how surprisingly easy it is to keep your air compressor in top operating condition.



- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Fluid Filter 2. Moisture Separator 3. Separator/Sump Tank 4. Fluid Fill 5. Fluid Fill Sight Glass 6. Starter Box 7. WS Controller | <ul style="list-style-type: none"> 8. E-Stop Button 9. Compressor Unit 10. Cooler Fan Motor 11. Cooler 12. Motor 13. Air Inlet Filter Figure |
|--|--|

Figure 2-1: Overall Component Layout, Air-Cooled Model



- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Moisture Separator 2. Fluid Filter 3. Separator/Sump Tank 4. Fluid Fill 5. Fluid Fill Sight Glass 6. Starter Box 7. WS Controller | <ul style="list-style-type: none"> 8. E-Stop Button 9. Compressor Unit 10. Oil Cooler 11. Aftercooler 12. Motor 13. Air Inlet Filter 14. Canopy Vent Fan Figure |
|--|--|

Figure 2-2: Overall Component Layout, Water-Cooled Model

2.2 DESCRIPTION OF COMPONENTS

Refer to *Figure 2-1* and *Figure 2-2*. The components and assemblies of the air compressor are clearly shown. The complete package includes compressor, electric motor, starter, compressor inlet system, compressor discharge system, compressor lubrication and cooling system, capacity control system, WS Controller, aftercooler, a combination separator and trap, all mounted on a heavy gauge steel frame.

On air-cooled models, a fan draws air into the enclosure over the fan and main motors through the

combined aftercooler and fluid cooler thereby removing the compression heat from the compressed air and the cooling fluid, and forces it out the top of the machine.

On water-cooled models, a shell and tube heat exchanger is mounted on the compressor frame. Fluid is piped into the heat exchanger where compression heat is removed from the fluid. Another similar heat exchanger cools the compressed air.

Both air-cooled and water-cooled versions have easily accessible items such as the fluid filter air/oil separator and control valves. The inlet air filter is also easily accessible for servicing.

2.3 SULLAIR COMPRESSOR UNIT, FUNCTIONAL DESCRIPTION

Sullair air compressors feature the Sullair compressor unit, a single-stage, positive displacement, flood lubricated- type compressor. This unit provides continuous compression to meet your needs.

NOTE

With a Sullair compressor, there is no maintenance or inspection of the internal parts of the compressor unit permitted in accordance with the terms of the warranty.

The 3000-4500 Series compressors are factory-filled with Sullube lubricant. For more information on fluid fill, consult *Specifications* on page 21.

Sullair 24KT compressors are filled with a fluid that rarely needs to be changed. Use only Sullair 24KT fluid in the event that a fluid change is required.

! CAUTION

Mixing of other lubricants within the compressor unit will void all warranties.



Sullair recommends that a 24KT sample be taken at the first filter change and sent to the factory for analysis. This is a free service. The sample kit with instructions and self-addressed container is to be supplied by your Sullair dealer at start-up. The user will receive an analysis report with recommendations.

Fluid is injected into the compressor unit hoses and mixes directly with the air as the rotors turn, compressing the air. The fluid flow has three basic functions:

1. As coolant, it controls the rise of air temperature normally associated with the heat of compression.
2. Seals the clearance paths between the rotors and the stator and also between the rotors themselves.
3. Acts as a lubricating film between the rotors allowing one rotor to directly drive the other, which is an idler.

After the air/fluid mixture is discharged from the compressor unit, the fluid is separated from the air. At this time, the air flows through an aftercooler and separator then to your service line while the fluid is being cooled in preparation for reinjection.

COOLING / LUBRICATION SYSTEM



DISCHARGE SYSTEM




Figure 2-3: Air-Cooled, Cooling / Lubrication and Discharge System




Figure 2-4: Water-Cooled, Cooling / Lubrication and Discharge System

2.4 COMPRESSOR COOLING AND LUBRICATION SYSTEM, FUNCTIONAL DESCRIPTION

Refer to *Figure 2-3* or *Figure 2-4*. The Cooling and Lubrication System (air-cooled version) consists of a fan, fan motor, radiator-type aftercooler/fluid cooler, full flow fluid filter, thermal valve, and interconnecting hoses. For water-cooled models, two shell and tube heat exchangers are substituted for the radiator-type cooler listed above. The pressure in the separator/sump tank causes fluid flow by forcing the fluid from the high pressure area of the separator/sump tank to an area of lower pressure in the compressor unit.

Fluid flows from the bottom of the separator/sump tank to the thermal valve. The thermal valve is fully open when the fluid temperature is below 185°F (85°C) [200°F (93°C) for 24KT] and pressures are rated above 150 psig. The fluid passes through the thermal valve, the main filter and directly to the compressor unit where it lubricates, cools and seals the rotors and the compression chamber.

As the discharge temperature rises above 185°F (85°C), due to the heat of compression, the thermal valve begins to adjust and a portion of the fluid then flows through the cooler. From the cooler the fluid flows to the fluid filter and then on to the compressor unit.

A portion of the fluid flowing to the compressor is routed to the anti-friction bearings which support the rotors inside the compressor unit.

The fluid filter has a replacement element and an integral pressure bypass valve. Refer to *Lubrication Change Recommendations and Maintenance, Fluid* on page 25.

Water-cooled models have a water pressure switch to prevent operation with inadequate water pressure.

2.5 COMPRESSOR DISCHARGE SYSTEM, FUNCTIONAL DESCRIPTION

Refer to *Figure 2-3* or *Figure 2-4*. The compressor unit discharges the compressed air/fluid mixture into the combination separator/sump tank.

The separator/sump has three basic functions:

1. 1. It acts as a primary fluid separator.
2. 2. Serves as the compressor fluid sump.
3. 3. Houses the final fluid separator.

The compressed air/fluid mixture enters the separator/sump tank and flows through an internal baffle system. The direction of movement is changed and its velocity significantly reduced, thus causing large droplets of fluid to form and fall to the bottom of the separator/sump tank. The fractional percentage of fluid remaining in the compressed air collects on the surface of the separator element as the compressed air flows through the separator. A return line (or scavenge tube) leads from the dry side of the separator/sump tank to a medium pressure region of the compressor unit. Fluid collecting on the bottom of the separator is returned to the compressor by a pressure differential between the separator/sump and the compressor. A visual sight glass is located on the return line to observe this fluid flow. There is also an orifice in this return line (protected by a strainer) to assure proper flow. The separator system reduces the fluid carry-over at nominal rated pressures to less than 1 ppm (parts per million). A message on the WS Controller indicates if abnormal pressure drop through the separator develops. Refer to *Lubrication Change Recommendations and Maintenance, Fluid* on page 25.

A minimum pressure/check valve, located downstream from the separator, assures a minimum separator/sump pressure of 50 psig (3.4 bar) during loaded conditions. This pressure is necessary for proper air/fluid separation and proper fluid circulation.

A terminal check valve is incorporated into the minimum pressure/check valve to prevent compressed air in the service line from bleeding back into the separator/sump on shutdown and during operation of the compressor in an unloaded condition.

A pressure relief valve (located on the wet side of the separator) is set to open if the separator/sump tank pressure exceeds the separator/sump tank rating. The WS Controller will shut down the compressor if the discharge temperature reaches 235°F (113°C).



WARNING

DO NOT remove caps, plugs, and/or other components when compressor is running or pressurized. Stop compressor and relieve all internal pressure before doing so.


Fluid is added to the separator/sump tank via a capped fluid filler opening, placed low on the tank to prevent overfilling of the separator/sump tank. A sight glass enables the operator to visually monitor the separator/sump tank fluid level.

2.6 CONTROL SYSTEM, FUNCTIONAL DESCRIPTION

Refer to *Figure 2-5* and *Figure 2-6*. The purpose of the compressor control system is to regulate the amount of air being compressed to match the amount of compressed air being used. The capacity control system consists of a solenoid valve, regulator valve and an inlet valve. The functional description of the control system is described below in four distinct phases of operation. For explanatory purposes, this description will apply to a compressor with an operating range of 100 to 110 psig (6.9 to 7.6 bar). A compressor with any other pressure range would operate in the same manner except stated pressures.

START MODE - 0 TO 50 PSIG (0 TO 3.5 BAR)

When the compressor "①" (START) pad is depressed, the separator/sump tank pressure will quickly rise from 0 to 50 psig (0 - 3.4 bar). The compressor initially starts unloaded with the solenoid valve open and the inlet valve closed. It then switches to full load when full rpm has been achieved. During this period, both the pressure regulator and the solenoid valve are closed, the inlet valve is fully open and the compressor pumps at full rated capacity. The rising compressor air pressure is isolated from the service line in this phase by the minimum pressure valve set at approximately 50 psig (3.4 bar).



- | | |
|--------------------------|---------------------------------|
| 1. Air Outlet | 6. Minimum Pressure/Check Valve |
| 2. Unload Solenoid Valve | 7. Separator/Sump Tank |
| 3. Pressure Regulator | 8. Sequencing Solenoid Valve |
| 4. Air Inlet | 9. WS Controller Figure |
| 5. Blowdown Valve | |

Figure 2-5: Standard Sequencing Control System

FULL LOAD MODE - 50 TO 100 PSIG (3.4 TO 6.9 BAR)

When the compressed air pressure rises above 50 psig (3.4 bar), the minimum pressure valve opens allowing compressed air to flow into the service line. From this point on, the line air pressure is continually monitored by the WS Controller. The pressure regulator and the solenoid valve remain closed during this phase. The inlet valve is in the fully open position as long as the compressor is running at 100 psig (6.9 bar) or below.

MODULATING MODE - 100 TO 110 PSIG (6.9 TO 7.6 BAR)

If less than the rated capacity of compressed air is being used, the service line pressure will rise above 100 psig (6.9 bar). The pressure regulator valve gradually opens, directing air pressure to the inlet control valve, reducing air entering the compressor until it matches the amount of air being used. The control system functions continually in this manner between the limits of 100 to 110 psig (6.9 to 7.6 bar) in response to varying demands from the service line. The integrated inlet valve has an orifice which vents a small amount of air to the compressor inlet when the pressure regulator controls the inlet control valve. The orifice also bleeds any accumulated moisture from the control lines.

UNLOAD MODE- IN EXCESS OF 110 PSIG (7.6 BAR)

When a relatively small amount or no air is being used, the service line pressure continues to rise. When it exceeds 110 psig (7.6 bar), the WS Controller control system de-energizes the solenoid valve allowing separator/sump tank air pressure to be supplied directly to close the inlet valve. Simultaneously, the solenoid valve sends a pneumatic signal to the blowdown valve. The blowdown valve opens to the atmosphere, located in the compressor separator/sump tank, reducing the separator/sump tank pressure to approximately 17

psig (1.2 bar). The check valve in the air service line prevents line pressure from returning to the separator/sump tank.

When the line pressure drops to the low setting (cut-in pressure; usually 100 psig (6.9 bar) on low pressure (7 bar) compressors and 125 psig (8.6 bar) on high pressure (9 bar) compressors, 150 psig (10.3 bar) on (10 bar) compressors, 175 psig (12.0 bar) on (12 bar) compressors), the WS Controller energizes the solenoid valve and allows the blowdown valve to close. The re-energized solenoid valve again prevents line pressure from reaching the inlet control valve. Should the pressure begin to rise, the pressure regulator will resume its normal function as previously described.

LOAD / NO LOAD CONTROL

If desired by the customer, the compressor can be set to operate load/no load without modulating control. This control mode is often selected when a large amount of compressed air storage (air tank) is available. Using the WS Controller keypad, select "load/no load control" from the menu. On a machine rated for 100 psig (7 bar) the compressor will run in the full load mode up to 100 psig (7 bar). If less than the rated capacity is required, pressure will rise above 100 psig and the WS Controller will de-energize the solenoid valve, causing the compressor to run in the unload mode. When the system pressure falls to 90 psig (6.3 bar), the WS Controller energizes the solenoid valve, causing the compressor to return to the full load mode. The compressor will thus operate to keep the system pressure in the range of 90-100 psig (6.3 - 6.9 bar).

AUTOMATIC OPERATION

For applications with varied periods of time when there are no air requirements, the WS Controller's AUTOMATIC mode allows the compressor to shutdown (time delayed) when no compressed air requirement is present and restart as compressed air is needed.

2.7 AIR INLET SYSTEM, FUNCTIONAL DESCRIPTION


Refer to *Figure 2-6*. The compressor inlet system consists of a dry-type air filter, a restriction gauge and an air inlet valve.

The restriction gauge (located on the air filter) indicates the condition of the air filter by showing red when filter maintenance is required.

The poppet-type modulating air inlet valve directly controls the amount of air intake to the compressor in response to the operation of the pressure regulator. Refer to Full Load Mode - 50 to 100 PSIG (3.4 to 6.9 BAR) on page 18. The inlet valve also acts as a check valve, thus preventing reverse rotation when the compressor is shut down.

WARNING

"The Plastic Pipe Institute recommends against the use of thermoplastic pipe to transport compressed air or other compressed gases in exposed above ground locations, e.g. in exposed plant piping." (I) Sullube should not be used with PVC piping systems. It may affect the bond at cemented joints. Certain other plastic materials may also be affected.
(I) Plastic Pipe Institute, Recommendation B, Adopted January 19, 1972.



- | | |
|---------------------|---------------------------------|
| 1. Air Inlet Filter | 4. Separator/Sump Tank |
| 2. Air Inlet | 5. Restriction Indicator Figure |
| 3. Compressor Unit | |

Figure 2-6: Air Inlet System

2.8 INTEGRAL DRYER OPTION

An integral refrigerated dryer option is available. The integral dryer is designed to work with the compressor WS controller which controls dryer starting and stopping, condensate drain valve function and monitors dewpoint temperature and dryer warnings and faults. The dryer is fully connected from the factory and is ready to run when the compressor is installed.

Detail of dryer operation and spare parts can be found in a supplement Manual 02250174-308 which is provided with your machine.

Per the controller default settings, on initial start-up the compressor will run unloaded for 5 minutes, allowing the dryer to run and cool down. This prevents condensate from initially being allowed into the compressed air stream. It also delays the supply of compressed air from the compressor until the 5 minute cool-down period is completed. When the

automatic control mode is selected, the compressor will stop after running unloaded for a prescribed time, but the dryer will continue to run to ensure there will not be a surge of condensate when the compressor re-starts. For other settings and control options, refer to the WS controller manual 02250164-411, or to your authorized Sullair servicing distributor.

In case the compressor needs to operate while the dryer is being serviced, the dryer can be bypassed, and removed if necessary for service. To bypass the dryer, disconnect the inlet hose to the dryer, disconnect the outlet hose at the main service connection, and re-connect the dryer inlet hose to the main service connection. Remove the fuses powering the dryer and control wiring located in the compressor electrical box. The WS controller must be set-up for the compressor to run on dryer fault. If necessary, this can be reset by your authorized Sullair servicing distributor.

Section 3

SPECIFICATIONS

3.1 TABLE OF SPECIFICATIONS—3000, 3000P, 3700 AND 4500 SERIES MODELS

MODEL (I)	HP	DIMENSIONS									
		Length		Width		Height		Weight		Weight	
		in	mm	in	mm	in	mm	lbs		kg	
								ODP	TEFC	ODP	TEFC
3000 SERIES											
3007	40	62	1575	34.5	876	61.5	1562	1818	1884	825	855
3009	40	62	1575	34.5	876	61.5	1562	1818	1884	825	855
3010	40	62	1575	34.5	876	61.5	1562	1818	1884	825	855
3000P SERIES											
3007P	40	62	1575	34.5	876	61.5	1562	1993	2059	904	934
3009P	40	62	1575	34.5	876	61.5	1562	1993	2059	904	934
3010P	40	62	1575	34.5	876	61.5	1562	1993	2059	904	934
3700 SERIES											
3707	50	62	1575	34.5	876	61.5	1562	2043	2127	927	965
3709	50	62	1575	34.5	876	61.5	1562	2043	2127	927	965
3710	50	62	1575	34.5	876	61.5	1562	2043	2127	927	965
3712	50	62	1575	34.5	876	61.5	1562	2043	2127	927	965
4500 SERIES											
4509	60	62	1575	34.5	876	61.5	1562	2193	2270	995	1030
4510	60	62	1575	34.5	876	61.5	1562	2193	2270	995	1030
4512	60	62	1575	34.5	876	61.5	1562	2193	2270	995	1030
(I) Includes standard and 24KT. Rated pressure designations appearing after model number are as follows:											
07 - 100 psig (6.9 bar)						10 - 150 psig (10.3 bar)					
09 - 125 psig (8.6 bar)						12 - 175 psig (12 bar)					
Maximum pressure is rated pressure plus 10 psig (0.7 bar).											

3.2 TABLE OF SPECIFICATIONS—VARIABLE SPEED DRIVE MODELS

VSD SERIES (I) - 3000 (MODELS 3007 THROUGH 3010)						
MOTOR	ODP			TEFC		
HZ / VOLTAGE	460/60	575/60	400/50	460/60	575/60	400/50
DRIVE AMP RATING	72	52	87	72	52	87
WEIGHT (lbs / kg)	1894 / 859	1894 / 859	1894 / 859	1960 / 889	1960 / 889	1960 / 889
LENGTH (in / mm)	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575
WIDTH (in / mm)	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876
HEIGHT (in / mm)	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562
VSD SERIES (I) - 3000P (MODELS 3007 THROUGH 3010)						
MOTOR	ODP	TEFC				
HZ / VOLTAGE	460/60	575/60	400/50	460/60	575/60	400/50
DRIVE AMP RATING	72	52	87	72	52	87
WEIGHT (lbs / kg)	2069 / 938	2069 / 938	2069 / 938	2135 / 968	2135 / 968	2135 / 968
LENGTH (in / mm)	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575
WIDTH (in / mm)	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876
HEIGHT (in / mm)	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562
VSD SERIES (I) - 3700 (MODELS 3707 THROUGH 3712)						
MOTOR	ODP			TEFC		
HZ / VOLTAGE	460/60	575/60	400/50	460/60	575/60	400/50
DRIVE AMP RATING	72	52	87	72	52	87
WEIGHT (lbs / kg)	2119 / 961	2171 / 984	2119 / 961	2203 / 999	2255 / 1023	2203 / 999
LENGTH (in / mm)	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575
WIDTH (in / mm)	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876
HEIGHT (in / mm)	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562
VSD SERIES (I) - 4500 (MODELS 4509 THROUGH 4510)						
MOTOR	ODP			TEFC		
HZ / VOLTAGE	460/60	575/60	400/50	460/60	575/60	400/50
DRIVE AMP RATING	72	52	87	72	52	87
WEIGHT (lbs / kg)	2361 / 1071	2244 / 1018	2361 / 1071	2438 / 1106	2296 / 1041	2438 / 1106
LENGTH (in / mm)	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575	62.0 / 1575
WIDTH (in / mm)	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876	34.5 / 876
HEIGHT (in / mm)	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562	61.5 / 1562
(I) Includes standard and 24KT. Rated pressure designations appearing after model number are as follows:						
07 - 100 psig (6.9 bar)			10 - 150 psig (10.3 bar)			
09 - 125 psig (8.6 bar)			12 - 175 psig (12 bar)			
Maximum pressure is rated pressure plus 10 psig (0.7 bar).						

3.3 COMPRESSOR SPECIFICATIONS

COMPRESSOR:	STANDARD MODELS:	
Type:	Rotary Screw	
Standard Operating Pressure:	100 psig (7 bar) 125 psig (9 bar)	150 psig (10 bar) 175 psig (12 bar)
Bearing Type:	Anti-friction	
Ambient Temperature (Max.) (II):	104°F (40°C)	
Cooling:	Pressurized fluid	
Compressor Fluid:	Sullair Sullube; 24KT is optional	
Separator/Sump Capacity:	3.0 gallons (11.4 liters)	
Control:	WS Controller	
(II) Special compressors are available for operation in higher ambient temperature.		

COMPRESSOR:	STANDARD MODELS:	
Size:	40, 50, 60 HP/30, 37, 45 KW	
Type:	C-flanged, Open Drip-proof, Epact Efficiency, Three Phase, 230/460 60Hz, 380-415 (400) 50 Hz	
VSD Type:	C-flanged, Open Drip-proof, Premium Efficiency, Three Phase, 460 60Hz, 380-415V (400V) 50 Hz	
Maximum Ambient Temperature	104°F (40°C)	
Available Options:	200V and 575V 60Hz, 220 50 Hz TEFC also available: CE approved	
Starter:	Full Voltage Magnetic, Wye-Delta or VSD	
Speed - 40, 50, 60 HP:	1780 RPM (60 Hz) or 1475 RPM (50 Hz)	
(III) Multi-frequency and voltage motors are used. The compressors must be used only with the specified electrical frequency and voltage		

3.4 LUBRICATION GUIDE

Refer to *Figure 3-1* for location of fluid fill port. For best value and longest uninterrupted service, the 3000-4500 Series compressors are factory filled and tested with Sullube lubricant.

CAUTION

Mixing of other lubricants within the compressor unit will void all warranties.

If fluid change is required, follow *Section 3.6: Lubrication Change Recommendations and Maintenance, Fluid* on page 25.

WARNING

"The Plastic Pipe Institute recommends against the use of thermoplastic pipe to transport compressed air or other compressed gases in exposed above ground locations, e.g. in exposed plant piping." (I)
 Sullube should not be used with PVC piping systems. It may affect the bond at cemented joints. Certain other plastic materials may also be affected.
 (I) Plastic Pipe Institute, Recommendation B, Adopted January 19, 1972.


Maintenance of all other components is still recommended as indicated in the Operator's Manual.

DO NOT MIX DIFFERENT TYPES OF FLUIDS. Contamination of compressor fluid with mineral oil or other fluids may lead to operational problems such as foaming, filter plugging, orifice or line plugging.

NOTE

Flush system when switching lubricant brands.

When ambient conditions exceed those noted or if conditions warrant use of "extended" life lubricants contact Sullair for recommendation.



1. Fluid Fill Port
2. Sight Glass
3. Fluid Drain Valve
4. Separator/Sump Tank Figure

Figure 3-1: Fluid Fill Location

3.5 APPLICATION GUIDE







Sullair encourages the user to participate in a fluid analysis program with the fluid suppliers. This could result in a fluid change interval differing from that stated in the manual. Contact your Sullair dealer for details.

3.6 LUBRICATION CHANGE RECOMMENDATIONS AND MAINTENANCE, FLUID

LUBRICANT	FLUID CHANGE	FLUID FILTER CHANGE	SEPARATOR CHANGE
Sullube (3.0 gal)	A, E	G, C	A, D
SRF 1/4000 (3.0 gal)	B, E	G, C	B, D
24KT (3.0 gal)	F, E	G, C	A, D
CP-4600-32-F (3.0 gal)	B, E	G, C	B, D

A - 8,000 hours or once a year.
 B - 4,000 hours or more frequently if conditions so require.
 C - When measured pressure loss exceeds 20 psig (1.3 bar).
 D - When measured pressure loss exceeds 10 psig (0.7 bar).
 E - When required by fluid analysis or known contamination.
 F - Does not require replacement during normal service conditions.
 G - Every 2,000 hours.

3.7 IDENTIFICATION, AIR-COOLED




3.7 IDENTIFICATION, AIR-COOLED

KEY NO.	PART NO.	QTY	DESCRIPTION
1			ALLOW 4.00 FEET [1.25 METERS] MINIMUM CLEARANCE AROUND MACHINE FOR ACCESS AND FREE CIRCULATION OF AIR.
2			A FOUNDATION OR MOUNTING CAPABLE OF SUPPORTING THE WEIGHT OF PACKAGE, AND RIGID ENOUGH TO MAINTAIN THE COMPRESSOR FRAME LEVEL IS REQUIRED. THE COMPRESSOR FRAME MUST BE LEVELLED AND SECURED BETWEEN THE FRAME AND THE FOUNDATION. NO PIPING LOADS ARE PERMITTED AT EXTERNAL CONNECTIONS.
3			ALL DIMENSIONS ARE +/- .50" [12.7MM].
4			RECOMMENDED INCOMING CUSTOMER POWER SUPPLY IS SHOWN ON DRAWING.
5			IF DUCTWORK IS TO BE INSTALLED FOR COOLING AIR, HIGH STATIC FAN MUST BE SELECTED. MAX ALLOWABLE ADDITIONAL STATIC PRESSURE 0.4 IN WATER WITH HIGH STATIC FAN.
6			DOORS ARE REMOVABLE USING LIFT-OFF HINGE PINS.
7			ALL DIMENSIONS SHOWN IN INCHES WITH MILLIMETER DIMENSIONS IN PARENTHESES.
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

MACHINE WEIGHTS				
	Main Motor HP	Motor Type	Weight	Cooling Air (CFM)
3000	40	odp	1818 lbs/825 kg	4800
3000	40	tefc	1884 lbs/ 855 kg	4800
3000P	40	odp	1993 lbs/904 kg	4800
3000P	40	tefc	2059 lbs/934 kg	4800
3700	50	odp	2043 lbs/927 kg	4800
3700	50	tefc	2127 lbs/ 965 kg	4800
4500	60	odp	2193 lbs/955 kg	5600
4500	60	tefc	2270 lbs/1030 kg	5600
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

3.8 IDENTIFICATION, WATER-COOLED



02250160-729-R03

3.8 IDENTIFICATION, WATER-COOLED

KEY NO.	PART NO.	QTY	DESCRIPTION
1			ALLOW 4.00 FEET [1.25 METERS] MINIMUM CLEARANCE AROUND MACHINE FOR ACCESS AND FREE CIRCULATION OF AIR.
2			A FOUNDATION OR MOUNTING CAPABLE OF SUPPORTING THE WEIGHT OF PACKAGE, AND RIGID ENOUGH TO MAINTAIN THE COMPRESSOR FRAME LEVEL IS REQUIRED. THE COMPRESSOR FRAME MUST BE LEVELLED AND SECURED BETWEEN THE FRAME AND THE FOUNDATION. NO PIPING LOADS ARE PERMITTED AT EXTERNAL CONNECTIONS.
3			ALL DIMENSIONS ARE +/- .50" [12.7MM].
4			RECOMMENDED INCOMING CUSTOMER POWER SUPPLY IS SHOWN ON DRAWING.
5			IF DUCTWORK IS TO BE INSTALLED FOR COOLING AIR, HIGH STATIC FAN MUST BE SELECTED. MAX ALLOWABLE ADDITIONAL STATIC PRESSURE 0.4 IN WATER WITH HIGH STATIC FAN.
6			DOORS ARE REMOVABLE USING LIFT-OFF HINGE PINS.
7			ALL DIMENSIONS SHOWN IN INCHES WITH MILLIMETER DIMENSIONS IN PARENTHESES.
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			


MACHINE WEIGHTS				
	Main Motor HP	Motor Type	Weight	Cooling Air (CFM)
3000	40	odp	1818 lbs/825 kg	730
3000	40	tefc	1884 lbs/ 855 kg	730
3000P	40	odp	1993 lbs/904 kg	730
3000P	40	tefc	2059 lbs/934 kg	730
3700	50	odp	2043 lbs/927 kg	730
3700	50	tefc	2127 lbs/ 965 kg	730
4500	60	odp	2193 lbs/955 kg	730
4500	60	tefc	2270 lbs/1030 kg	730
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

3.9 IDENTIFICATION, AIR-COOLED W/ INTEGRAL DRYER

KEY NO.	PART NO.	QTY	DESCRIPTION
1.			ALLOW 4.00 FEET [1.25 METERS] MINIMUM CLEARANCE AROUND MACHINE FOR ACCESS AND FREE CIRCULATION OF AIR.
2.			A FOUNDATION OR MOUNTING CAPABLE OF SUPPORTING THE WEIGHT OF PACKAGE, AND RIGID ENOUGH TO MAINTAIN THE COMPRESSOR FRAME LEVEL IS REQUIRED. THE COMPRESSOR FRAME MUST BE LEVELLED AND SECURED BETWEEN THE FRAME AND THE FOUNDATION. NO PIPING LOADS ARE PERMITTED AT EXTERNAL CONNECTIONS.
3.			ALL DIMENSIONS ARE +/- .50" [12.7MM].
4.			RECOMMENDED INCOMING CUSTOMER POWER SUPPLY IS SHOWN ON DRAWING.
5.			IF DUCTWORK IS TO BE INSTALLED FOR COOLING AIR, HIGH STATIC FAN MUST BE SELECTED. MAX ALLOWABLE ADDITIONAL STATIC PRESSURE 0.4 IN WATER WITH HIGH STATIC FAN.
6.			DOORS ARE REMOVABLE USING LIFT-OFF HINGE PINS.
7.			ALL DIMENSIONS SHOWN IN INCHES WITH MILLIMETER DIMENSIONS IN PARENTHESES.
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

MACHINE WEIGHTS				
	Main Motor HP	Motor Type	Weight (Lbs/Kg)	Cooling Air (CFM)
3000	40	odp	2102/953	4800
3000	40	tefc	2168/983	4800
3000P	40	odp	2277/1033	4800
3000P	40	tefc	2343/1063	4800
3700	50	odp	2327/1055	4800
3700	50	tefc	2411/1094	4800
4500	60	odp	2477/1124	5600
4500	60	tefc	2554/1158	5600
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

3.10 PIPING AND INSTRUMENTATION, AIR-COOLED




02250156-203-R11

3.10 PIPING AND INSTRUMENTATION, AIR-COOLED

KEY NO.	PART NO.	QTY	DESCRIPTION	NOTE
1	02250127-683	1	FILTER, AIR 9" PLASTIC	
2	250003-869	1	INDICATOR, RESTRICTION	
3	-	1	INLET	
4	-	1	COMPRESSOR UNIT	
5	-	1	MOTOR	
6	02250155-708	1	FILTER, CORELESS 1-1/16 SAE	
7	02250152-862	1	COOLER, AIR/OIL 60HP	5
7	02250151-493	1	COOLER, AIR/OIL 50HP	5
8	02250148-796	1	VALVE, THERMAL 210DEG 1-1/2"-18	5
8	02250092-081	1	VALVE, THERMAL 195DEG 1-1/2"-18	5
9	02250125-774	1	ORIFICE, 1/8 X 1/32	
10	02250126-129	1	GLS, SIGHT/ORF SAE	
11	02250117-782	1	FILTER, ASSY GENISIS	
12	02250097-610	1	PLUG,SIGHTGLASS 1-5/16" SAE	
13	02250155-175	1	PROBE, THERMISTER 3000 OHM	
14	250006-938	1	VALVE, RELIEF 1/2"	
15	02250155-174	2	XDUCR, 1-250# RADIOMETRIC	
16	408893	1	VALVE, SHUTTLE 1/4" DOUBLE CHK	
17	02250097-598	1	VLV, MIN PRESSURE 1-7/8 SAE	
18	02250100-042	1	VALVE, BLOWDOWN 1/2" 1.8:1	
19	02250166-734	1	SEP,WTR SCWS-235N 1 1/2" L/AD	
20	02250160-774	1	ELEM,SEP ROUND 5.5D X 14.3LNG	
21	02250173-972	1	FLTR,PNEUMATIC 1/8"NPT 5MICRON	
22	02250170-783	1	VLV,DR COMBO 24 VDC	
23	02250155-714	2	VLV,SOL 3WNO 1/4 250# 24VDC	
24	250017-280	1	VALVE, PRESSURE REG	
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

KEY NO.	PART NO.	QTY	DESCRIPTION	NOTE
25	02250149-624	1	TANK, SEPARATOR	
26	02250161-433	1	ORIFICE,.140 X 1/4M X 1/4F	
27	02250078-976	1	GA,DIFF PRESS Z-PURGE ASY REGU	
28	02250115-272	1	VLV,CHK 1/4"NPTF BRASS VITON	
29	02250144-842	1	VLV,BALL/STNR COMB 1/2F X 1/2M	
30	02250111-686	1	DRN,ELECTRIC CONDENSATE-SCD400	
31	02250112-881	1	VENT,ENCL PROT 1/2" SIDE MTG Z-PRG	
32	241771	1	STRAINER, V-TYPE 300PSIX1/4	
1	PART NUMBERS ARE FOR REFERENCE ONLY. REFER TO BILL OF MATERIAL AND OR FACE OF ORDER FOR ACTUAL PARTS.			
2	SECTION BETWEEN LETTERED POINTS ARE TO BE REPLACED WITH CORRESPONDING OPTION PICTURED BELOW, AS REQUIRED BY FACE OF ORDER.			
3	CONTROL/MOISTURE DRAIN LINES ARE 1/4" TUBING EXCEPT AS NOTED.			
4	OPTIONAL HEAT TRACE IS APPLIED ONLY TO CONTROL AND MOISTURE DRAIN LINES AND USED ONLY WITH STAINLESS STEEL TUBING. REFER TO FACE OF ORDER FOR HEAT TRACE REQUIREMENTS.			
5	PART VARIES BY MODEL.			
<i>Continued on page 35</i>				
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

3.10 PIPING AND INSTRUMENTATION, AIR-COOLED



3.10 PIPING AND INSTRUMENTATION, AIR-COOLED


KEY NO.	PART NO.	QTY	DESCRIPTION
(I)	Part varies by model.		
(II)	Used with EES option.		
(III)	Two solenoid valves are required with Sequencing option. Refer to B4.		
A1	Tank pressure - blue color		
A2	Reg pressure - yellow color		
A3	Unload pressure - red color		
A4	Water drain - clear color		
B1	P1 - Wet sump pressure		
B2	P2 - Line pressure		
B3	SOL 1 - Load/unload solenoid valve		
B4	SOL 4 - MEC/sequencing/full load solenoid valve		
B5	SOL 5 - Electric drain/scd drain solenoid valve		
B6	SOL 7 - EES solenoid valve (optional)A to open inside EES damper (winter).B to open outside EES damper (summer).		
B7	T1 - Wet discharge temperature		
C1	1/2" Hose.		
C2	Control moisture drain lines are 1/4" tubing except as noted.		
C3	1 1/2" - 11 1/2 npt air outlet.		
C4	1/4"-18 npt moisture drain connection.		
C5	Section between lettered points (A) and (B) are to be replaced with corresponding option pictured below, as required by face of order. Refer to B4.		
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

KEY NO.	PART NO.	QTY	DESCRIPTION
C6	Optional heat trace is applied only to control and moisture drain lines and used only with stainless steel tubing. Refer to face of order for heat trace requirements.		
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

COMPONENT	DESCRIPTION
P1	WET SUMP PRESSURE
P2	LINE PRESSURE
SOL1	LOAD/UNLOAD SOLENOID VALVE
SOL4	MEC/SEQUENCING/FULL LOAD SOLENOID VALVE
SOL5	ELECTRIC DRAIN/SCD DRAIN SOLENOID VALVE
T1	WET DISCHARGE TEMPERATURE

TUBING COLOR	PURPOSE
Blue	TANK PRESSURE
Yellow	REG PRESSURE
Red	UNLOAD PRESS
Clear	WATER DRAIN

3.11 PIPING AND INSTRUMENTATION, WATER-COOLED





02250162-393-R05

3.11 PIPING AND INSTRUMENTATION, WATER-COOLED

KEY NO.	PART NO.	QTY	DESCRIPTION	NOTE
1	02250127-683	1	FILTER, AIR 9" PLASTIC	
2	250003-869	1	INDICATOR, RESTRICTION	
3	-	1	INLET	
4	-	1	COMPRESSOR UNIT	
5	-	1	MOTOR	
6	02250155-708	1	FILTER, CORELESS 1-1/16 SAE	
7	02250094-744	1	CLR,OIL/WATER 5X36 1-5/16"SAE	
8	02250148-796	1	VALVE, THERMAL 210DEG 1-1/2"-18	5
8	02250092-081	1	VALVE, THERMAL 195DEG 1-1/2"-18	5
9	02250125-774	1	ORIFICE, 1/8 X 1/32	
10	02250126-129	1	GLS, SIGHT/ORF SAE	
11	02250117-782	1	FILTER, ASSY GENISIS	
12	02250097-610	1	PLUG,SIGHTGLASS 1-5/16" SAE	
13	02250155-175	1	PROBE, THERMISTER 3000 OHM	
14	250006-938	1	VALVE, RELIEF 1/2"	
15	02250155-174	2	XDUCR, 1-250# RADIOMETRIC	
16	408893	1	VALVE, SHUTTLE 1/4" DOUBLE CHK	
17	02250097-598	1	VLV, MIN PRESSURE 1-7/8 SAE	
18	02250100-042	1	VALVE, BLOWDOWN 1/2" 1.8:1	
19	02250166-734	1	SEP,WTR SCWS-235N 1 1/2" L/AD	
20	02250160-774	1	ELEM,SEP ROUND 5.5D X 14.3LNG	
21	02250173-972	1	FLTR,PNEUMATIC 1/8"NPT 5MICRON	
22	02250170-783	2	VLV,DR COMBO 24 VDC	
23	02250155-714	2	VLV,SOL 3WNO 1/4 250# 24VDC	
24	250017-280	1	VALVE, PRESSURE REG	
25	02250149-624	1	TANK, SEPARATOR	
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

KEY NO.	PART NO.	QTY	DESCRIPTION	NOTE
26	02250161-433	1	ORF,.140".25 FNPT X .25	
27	02250111-686	1	DRN,ELECTRIC CONDENSATE-SCD400	
28	02250115-272	1	VLV,CHK 1/4"NPTF BRASS VITON	
29	250017-527	1	HT EXCH	
30	250017-992	1	SWITCH, PRESS NO 10 PSI	
31	47398	1	VALVE, WATER REG 3/4"160-230F	
32	02250125-668	1	VLV,SOL 2WNC 3/4 250# N4	
33	02250144-842	1	VLV,BALL/STNR COMB 1/2F X 1/2M	
34	241771	1	STRAINER, V-TYPE 300PSIX1/4	
1 PART NUMBERS ARE FOR REFERENCE ONLY. REFER TO BILL OF MATERIAL AND OR FACE OF ORDER FOR ACTUAL PARTS.				
2 SECTION BETWEEN LETTERED POINTS ARE TO BE REPLACED WITH CORRESPONDING OPTION PICTURED BELOW, AS REQUIRED BY FACE OF ORDER.				
3 CONTROL/MOISTURE DRAIN LINES ARE 1/4" TUBING EXCEPT AS NOTED.				
4 OPTIONAL HEAT TRACE IS APPLIED ONLY TO CONTROL AND MOISTURE DRAIN LINES AND USED ONLY WITH STAINLESS STEEL TUBING. REFER TO FACE OF ORDER FOR HEAT TRACE REQUIREMENTS.				
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

3.11 PIPING AND INSTRUMENTATION, AIR-COOLED WITH INTEGRAL DRYER



SEQUENCING SOLENOID

- CUSTOMER FURNISHED LINE
- WATER LINE Δ
- CONTROL LINE Δ
- FLUID LINE Δ
- AIR/FLUID LINE Δ
- TEMP. CONTROL PROBE Δ
- AIR LINE Δ

Z-PURGE OPTION

3.11 PIPING AND INSTRUMENTATION, AIR-COOLED WITH INTEGRAL DRYER

KEY NO.	PART NO.	QTY	DESCRIPTION	NOTE
1	02250125-369	1	FILTER,AIR INLET 8" (PLASTIC)	5
1	02250127-683	1	FILTER,AIR INLET 9" (PLASTIC)	5
2	250003-869	1	INDICATOR, RESTRICTION	
3	-	1	INLET	
4	-	1	COMPRESSOR UNIT	
5	-	1	MOTOR	
6	02250155-708	1	FILTER, CORELESS 1-1/16 SAE	
7	02250152-862	1	COOLER, AIR/OIL 60HP	5
7	02250151-493	1	COOLER, AIR/OIL 50HP	5
8	02250148-796	1	VALVE, THERMAL 210DEG 1-1/2"-18	5
8	02250092-081	1	VALVE, THERMAL 195DEG 1-1/2"-18	5
9	02250125-774	1	ORIFICE, 1/8 X 1/32	
10	02250126-129	1	GLS, SIGHT/ORF SAE	
11	02250117-782	1	FILTER, ASSY GENISIS	
12	02250097-610	1	PLUG,SIGHTGLASS 1-5/16" SAE	
13	02250155-175	1	PROBE, THERMISTER 3000 OHM	
14	250006-938	1	VALVE, RELIEF 1/2"	
15	02250155-174	2	XDUCR, 1-250# RADIOMETRIC	
16	408893	1	VALVE, SHUTTLE 1/4" DOUBLE CHK	
17	02250097-598	1	VLV, MIN PRESSURE 1-7/8 SAE	
18	02250100-042	1	VALVE, BLOWDOWN 1/2" 1.8:1	
19	02250166-734	1	SEP,WTR SCWS-235N 1 1/2" L/AD	
20	02250160-774	1	ELEM,SEP ROUND 5.5D X 14.3LNG	
21	02250170-783	1	VLV,DR COMBO 24 VDC	
22	241771	1	STRAINER, V-TYPE 300PSI X 1/4	
23	02250155-714	2	VLV,SOL 3WNO 1/4 250# 24VDC	
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				

KEY NO.	PART NO.	QTY	DESCRIPTION	NOTE
24	250017-280	1	VALVE, PRESSURE REG	
25	02250149-624	1	TANK, SEPARATOR	
26	02250161-433	1	ORIFICE, .140 X 1/4M X 1/4F	
27	02250115-272	1	VLV,CHK 1/4"NPTF BRASS VITON	
28	02250168-837	1	VENT,ENCL PROT 1/2" TOP	
29	02250169-612	1	GA,DIFF PRESS Z-PRG ASY BTM	
30	-	1	INTEGRAL REFRIGERANT DRYER	
31	44905	2	VALVE,CHECK	
32	02250175-087	1	PROBE,THERMISTER 3000 OHM NTC 12' L	
33	02250173-972	1	FLTR,PNEUMATIC 1/8"NPT	
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR				





COMPONENT	DESCRIPTION
P1	WET SUMP PRESSURE
P2	LINE PRESSURE
SOL1	LOAD/UNLOAD SOLENOID VALVE
SOL4	MEC/SEQUENCING/FULL LOAD SOLENOID VALVE
SOL5	ELECTRIC DRAIN/SCD DRAIN SOLENOID VALVE
T1	WET DISCHARGE TEMPERATURE

TUBING COLOR	PURPOSE
Blue	TANK PRESSURE
Yellow	REG PRESSURE
Red	UNLOAD PRESS
Clear	WATER DRAIN

3.12 WIRING DIAGRAM, VSD AIR-COOLED

TRANSFORMER CONNECTIONS

PRIMARY		SECONDARY	
VOLTS	TAPS	VOLTS	TAPS
200	H1-H2	110	X1-X4
220	H1-H2	110	X1-X3
230	H1-H2	115	X1-X3
240	H1-H2	120	X1-X3
360	H1-H3	110	X1-X3
400	H1-H3	115	X1-X3
418	H1-H3	120	X1-X3
440	H1-H4	110	X1-X3
460	H1-H4	120	X1-X3
480	H1-H4	115	X1-X3
500	H1-H5	110	X1-X4
525	H1-H5	115	X1-X4
550	H1-H5	110	X1-X3
575	H1-H5	115	X1-X3
600	H1-H5	120	X1-X3




3.12 WIRING DIAGRAM, VSD AIR-COOLED

KEY NO.	DESCRIPTION
COMP	DESCRIPTION
1M	COMPRESSOR MOTOR
2M	COOLER FAN MOTOR STARTER
2MOL	FAN MOTOR OVERLOAD
1FU	FAN MOTOR BRANCH CIRCUIT FUSES
2FU	SCD TRANSFORMER PRIMARY FUSES
3FU	SCD TRANSFORMER SCONDARY FUSE
P1	WET SUMP PRESSURE SENSOR
P2	PACKAGE DISCHARGE PRESSURE SENSOR
T1	UNIT DISCHAGE TEMPERATURE PROBE
PSW1	(OPT'L)INLET AIR FILTER SWITCH 558.9 MM WC-22 IN WC
DPSW 1	(OPT'L)OIL FILTER DIFF PRESS SWITCH 20P SID
INPUT 7	REMOTE RUN/UNLOAD
INPUT 8	CUSTOMER FURNISHED FAULT
INPUT 9	CUSTOMER FURNISHED WARNING
SOL1	LOAD CONTROL SOLENOID VALVE
SOL4	SEQUENCEING SOLENOID VALVE
SOL5	ELECTRIC CONDENSATE DRAIN VALVE
PS	24VDC POWER SUPPLY
K1	INTERNAL FAN RELAY CONTACT TEMP (T1) CONTROLLED
K2	INTERNAL Y-DELTA START RELAY COMPRESSOR RUNNING
K3	INTERNAL WYE-DELTA RUN RELAY COMPRESSOR ENABLED
K4	INTERNAL LOAD CONTROL RELAY
K5	INTERNAL SEQUENCE RELAY
K6	INTERNAL ELECTRIC DRAIN RELAY
K7	INTERNAL COMMON FAULT RELAY

KEY NO.	DESCRIPTION
PMR	OPT'L POWER MONITOR RELAY
HTR1	(OPT'L) SUMP HEATER 800W
HTR2	(OPT'L) HEAT TRACE
HTR3	(OPT'L) TRAP HEATER 70WATTS
HTR4	(OPT'L) CONTROL PANEL HEATER 50WATTS
TH	THERMOSTAT FOR HEAT TRACE OPTION
XFMR1	CONTROL TRANSFORMER FOR SCD DRAIN
SCD	(OPT'L) SCD DRAIN

KEY NO.	PART NO.	QTY	DESCRIPTION
1			CUSTOMER TO FURNISH FUSED OR CIRCUIT BREAKER DISCONNECT PER LOCAL CODES.
2			REMOVE JUMPER FOR AUXILLIARY E-STOP STRING DEVICES.
3			USE ISOLATING RELAYS WITH DRY CONTACTS FOR ANY OPTIONAL INPUTS TO THE WS CONTROLLER. MOUNT THE RELAY LOCALLY IN THE STARTER BOX.
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

3.13 WIRING DIAGRAM, AIR-COOLED MFV WITH INTEGRAL DRYER



3.13 WIRING DIAGRAM, AIR COOLED MFV WITH INTEGRAL DRYER

KEY NO.	DESCRIPTION
DR	DRYER START RELAY
COMP	DESCRIPTION
1MOL	COMPRESSOR OVERLOAD
1M	COMPRESSOR STARTER
2MOL	FAN MOTOR OVERLOAD
P1	WET SUMP PRESSURE SENSOR
P2	PACKAGE DISCHARGE PRESSURE SENSOR
T1	UNIT DISCHARGE TEMPERATURE PROBE
T3	DRYER DEWPOINT TEMPERATURE PROBE
PSW1	(OPT'L)INLET AIR FILTER SWITCH 558.9 MM WC - 22 IN WC
DPSW1	(OPT'L)OIL FILTER DIFF PRESS SWITCH 20PSID
INPUT 7	REMOTE RUN/UNLOAD
INPUT 8	CUSTOMER FURNISHED FAULT
INPUT 9	CUSTOMER FURNISHED WARNING
SOL1	LOAD CONTROL SOLENOID VALVE
SOL4	SEQUENCEING SOLENOID VALVE
SOL5	ELECTRIC CONDENSATE DRAIN VALVE
PS	24VDC POWER SUPPLY
K1	INTERNAL RUN RELAY CONTACT
K2	INTERNAL Y-DELTA START RELAY
K3	INTERNAL WYE-DELTA RUN RELAY
K4	INTERNAL LOAD CONTROL RELAY
K5	INTERNAL SEQUENCE RELAY
K6	INTERNAL ELECTRIC DRAIN RELAY
K7	INTERNAL COMMON FAULT RELAY
PMR	OPT'L POWER MONITOR RELAY
PF CAP	POWER FACTOR CORRECTION CAPACITOR (OPT'L)
HTR1	(OPT'L) SUMP HEATER 800W
HTR2	(OPT'L) HEAT TRACE





KEY NO.	DESCRIPTION
HTR3	(OPT'L) TRAP HEATER 70WATTS
HTR4	(OPT'L) CONTROL PANEL HEATER 50WATTS
TH	THERMOSTAT FOR HEAT TRACE OPTION
1FU	SCD TRANSFORMER PRIMARY FUSES
2FU	SCD TRANSFORMER SECONDARY FUSE
6FU	INTEGRAL DRYER FUSES
7FU	INTEGRAL DRYER FUSES (575V)
SCD	SCD DRAIN OPTION
XFMR1	CONTROL TRANSFORMER FOR OPTIONAL SCD DRAIN
PPR	POWER PRESENT RELAY OPTION
DF	DRYER FAULT

KEY NO.	PART NO.	QTY	DESCRIPTION
1			CUSTOMER TO FURNISH FUSED OR CIRCUIT BREAKER DISCONNECT PER LOCAL CODES.
2			REMOVE JUMPER FOR AUXILLIARY E-STOP STRING DEVICES.
3			1MOL SETTING TO BE 1M FLA. PLUS 2M FLA.
4			USE ISOLATING RELAYS WITH DRY CONTACTS FOR ANY OPTIONAL INPUTS TO THE WS CONTROLLER. MOUNT THE RELAY LOCALLY IN THE STARTER BOX.
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

3.14 WIRING DIAGRAM, AIR-COOLED MFV

TRANSFORMER CONNECTIONS

PRIMARY	TAPS	SECONDARY	TAPS
200	H1-H2	110	X1-X4
220	H1-H2	110	X1-X3
230	H1-H2	115	X1-X3
240	H1-H2	120	X1-X3
380	H1-H3	110	X1-X3
400	H1-H3	115	X1-X3
415	H1-H3	120	X1-X3
440	H1-H4	110	X1-X3
460	H1-H4	120	X1-X3
480	H1-H4	115	X1-X3
500	H1-H5	110	X1-X4
525	H1-H5	115	X1-X4
550	H1-H5	110	X1-X3
575	H1-H5	115	X1-X3
600	H1-H5	120	X1-X3



3.14 WIRING DIAGRAM, AIR COOLED MFV

KEY NO.	DESCRIPTION
P1	WET SUMP PRESSURE SENSOR
P2	PACKAGE DISCHARGE PRESSURE SENSOR
T1	UNIT DISCHAGE TEMPERATURE PROBE
T3	DRYER DEWPOINT TEMPERATURE PROBE
PSW1	(OPT'L)INLET AIR FILTER SWITCH 558.9 MM WC - 22 IN WC
DPSW1	(OPT'L)OIL FILTER DIFF PRESS SWITCH 20PSID
INPUT 7	REMOTE RUN/UNLOAD
INPUT 8	CUSTOMER FURNISHED FAULT
INPUT 9	CUSTOMER FURNISHED WARNING
SOL1	LOAD CONTROL SOLENOID VALVE
SOL4	SEQUENCEING SOLENOID VALVE
SOL5	ELECTRIC CONDENSATE DRAIN VALVE
PS	24VDC POWER SUPPLY
K1	INTERNAL RUN RELAY CONTACT
K2	INTERNAL Y-DELTA START RELAY
K3	INTERNAL WYE-DELTA RUN RELAY
K4	INTERNAL LOAD CONTROL RELAY
K5	INTERNAL SEQUENCE RELAY
K6	INTERNAL ELECTRIC DRAIN RELAY
K7	INTERNAL COMMON FAULT RELAY
PMR	OPT'L POWER MONITOR RELAY
PF CAP	POWER FACTOR CORRECTION CAPACITOR (OPT'L)
HTR1	(OPT'L) SUMP HEATER 800W
HTR2	(OPT'L) HEAT TRACE
HTR3	(OPT'L) TRAP HEATER 70WATTS
HTR4	(OPT'L) CONTROL PANEL HEATER 50WATTS
TH	THERMOSTAT FOR HEAT TRACE OPTION
1FU	SCD TRANSFORMER PRIMARY FUSES
2FU	SCD TRANSFORMER SECONDARY FUSE

KEY NO.	DESCRIPTION
SCD	SCD DRAIN OPTION
PPR	POWER PRESENT RELAY OPTION

KEY NO.	PART NO.	QTY	DESCRIPTION
1			CUSTOMER TO FURNISH FUSED OR CIRCUIT BREAKER DISCONNECT PER LOCAL CODES.
2			REMOVE JUMPER FOR AUXILLIARY E-STOP STRING DEVICES.
3			1MOL SETTING TO BE 1M FLA. PLUS 2M FLA.
4			USE ISOLATING RELAYS WITH DRY CONTACTS FOR ANY OPTIONAL INPUTS TO THE WS CONTROLLER. MOUNT THE RELAY LOCALLY IN THE STARTER BOX.
PLEASE NOTE: WHEN ORDERING PARTS, INDICATE SERIAL NUMBER OF COMPRESSOR			

BLANK PAGE

Section 4

INSTALLATION

4.1 MOUNTING OF COMPRESSOR

A suitable foundation or fabricated support must be established to support the compressor. It should be rigid enough to keep the compressor frame level and maintain alignment of the compressor and motor. Tie-down bolts of sufficient size must be used to provide uniform contact between the foundation and the compressor frame. Materials such as rubber or cork can be used to provide uniform contact between the foundation and compressor frame.

Piping loads must be eliminated through the use of flex connectors or other systems which prevent piping loads from being transmitted to the compressor.

Special consideration should be made to meet national and local electrical codes for the required space around and in front of the electrical panel. Lighting should be provided for future service requirements.

Accessibility for fork lift trucks, overhead cranes and maintenance vehicles should be given careful consideration in order to provide any maintenance that may be required. Adequate space around the unit should be provided for access to all components of the compressor.

Softer surfaces in walls or ceilings will absorb sound and minimize ambient noise levels. Harder, reflective surfaces will increase ambient noise levels.

Water-cooled compressors must have provisions for cooling water supply and drainage available.

NOTE

Ambient temperatures above 104°F (40°C) require that the high ambient option is specified for the compressor.

4.2 VENTILATION AND COOLING

AIR-COOLED COMPRESSORS

An area with adequate space must be provided for the compressor and its components. Air-cooled compressors require a minimum of 3 feet (1 meter) around the perimeter of the compressor.

The location should be free from standing water and allow access to clean air that is free from exhaust and paint fumes, dust, metal filings or caustic chemicals.

Cooling air should be removed from the area in order to prevent the re-introduction of heated exhaust air back into the compressor's cooling system.

Reduced headroom above the compressor will require that cooling air be either ducted or in some way deflected away from the compressor. Inadequate ventilation will result in higher ambient operating temperatures.

NOTE

Systems that employ both a conventional reciprocating compressor and a screw-type axial compressor must be isolated from each other by use of a common separator/sump tank. Individual airlines from each compressor should be piped to the common separator/sump tank.

NOTE

Shipping straps are painted red in order to help identify them for removal. Be sure to remove them prior to operation of the drive assembly.

WATER-COOLED COMPRESSORS

Adequate cooling water flow must be supplied to water-cooled compressors. Water delivery must be verified to assure constant delivery of the volumes outlined in *Table 4-1: WATER FLOW REQUIREMENTS* on page 48. The figures shown are for full-load operation utilizing an aftercooler. Cooler water will reduce water-flow requirements and warmer water will increase water-flow requirements.

Water piping to and from the compressor unit must be a minimum of 1 inch diameter. Isolation valves with side drains should be installed on both input and return lines. Input water should have a 2 mm strainer installed in-line. A normally closed solenoid valve should be connected to the water outlet of the compressor. The compressor control circuit switches this circuit. Consult the Sullair Service Department for assistance in these setups.

Water quality is critical to proper cooling of the compressor. Excessive build-up of lime, scale or other deposits can restrict the flow of water to the compressor. These deposits act as a thermal insulator and reduce the efficiency of the water cooler.

The cleaning of piping and water coolers is the customer's responsibility. Inspect all piping for deposits and clean as necessary. Refer to *Water Quality Recommendations* on page 49.

Table 4-1: WATER FLOW REQUIREMENTS

Water Temp °F/°C	Water Flow Gallons Per Minute/Liters Per Minute (l)		
	40HP/30kW	50HP/37kW	60HP/45kW
70/21	5.6	7.0 (26.5)	9.0 (31.6)
80/27	8.4	10.5 (35.7)	11.5 (41.6)

(l) Water pressure should be maintained between 25 and 75 psig (1.7 and 5.2 bar), but not to exceed 145 psig (10 bar)

Table 4-2: VENTILATION REQUIREMENTS on page 49 indicates the minimum ventilation requirements necessary to keep the compressor running at its normal operating temperature. The fan air requirement is the amount of air, which must flow through the compressor for proper ventilation. The heat rejection requirement is the amount of heat that is radiated by the compressor. This heat must be removed to assure a normal operating temperature. With air-cooled compressors it is possible to use this heat for space heating, providing additional pressure drop across the fan does not exceed 0.2 in H₂O. Consult a Sullair office for assistance in utilizing this heat. If ductwork is added, the high static fan option is required.

DO NOT install a water-cooled or an air-cooled/after-cooled compressor where it will be exposed to temperatures less than 32°F (0°C). Consult factory for machine operation in ambient temperature less than 32°F (0°C).

If machine is equipped with water regulating valve, use the water regulating valve to adjust compressor temperature to maintain a minimum of 180°F (82.2°C); 190°F (87.8°C) for 24KT.

Temperature and pressure gauges should be installed in the water piping for use in troubleshooting of the water system. Water pressure should ideally be between 25 and 75 psig (1.7 and 5.2 bar) but must not be above 145 psi (10 bar).

Table 4-2: VENTILATION REQUIREMENTS

Cooling Type	Air-Cooled with Aftercooler			Water-Cooled		
	40/30	50/37	60/45	40/30	50/37	60/45
Motor HP/kW	40/30	50/37	60/45	40/30	50/37	60/45
Fan Air cfm/m ³ /hr	5,000/8,500	5,000/8,500	6,000/10,200	700/1,200	700/1,200	700/1,200
Ventilating Air/Heat Rejection BTU/Hour	114,500	142,000	171,000	10,600	13,300	15,800
KCal/Hour	28,800	35,700	46,216	2,670	3,350	4,000
Cooling Water/Heat Rejection BTU/Hour				114,500	142,000	171,100
KCal/Hour				28,800	35,700	43,040

WATER SYSTEM VENTING

Vent the system upon installation or after draining the system on start-up:

1. Open the water valve(s) allowing water to flow to the system.
2. Open the vent cocks (located on top of the aftercooler and the lubricant cooler) and allow all air to escape from the system. When water is observed at the vent cocks, close them.

The system is now vented.

DRAINING THE WATER SYSTEM

If the system needs to be drained completely, follow the steps outlined below:

1. At the rear of the unit. Disconnect both the inlets and discharge water lines.
2. Remove the drain plugs located at the bottom of the aftercooler and lubricant cooler.
3. Allow the system to drain completely.

WATER QUALITY RECOMMENDATIONS

Water quality considerations are crucial to the effective operation of a water-cooled compressor and yet are the most often ignored. Premature failure of components can often be traced to a reduction in heat-transfer rate that has resulted from a reduced flow rate due to scale build-up in water-cooling lines or the coolers themselves.

SCALE

Scale is formed from calcium carbonate, which precipitates out of water. Calcium content tends to be higher in water taken from wells than water taken from the surface of lakes. A higher pH value will also

assist in the formation of lime scale. In all cases calcium will form scale when water that has dissolved calcium is heated. It then forms lime-scale on surfaces such as the inside of pipes and the tubing that comprises water coolers. Scale formation on the inside of pipes and inside of heat exchangers acts as a thermal insulator. This causes coolers to be less effective, and piping to have reduced water flow, making them less effective. Over time lime scale build-up can reduce water flow by 80% or greater. This renders the cooling system ineffective and will damage the system. Scale can be controlled with water treatment.

CORROSION

As contrasted to lime scale build-up, corrosion eventually causes a reduction in the wall thickness of pipes. High levels of dissolved oxygen and low pH levels assist in the creation of corrosive scale. A thin coating of lime scale is often beneficial in helping to prevent corrosion from forming.

BIOLOGICAL AND ORGANIC FOULING (SLIME)

The heightened temperatures of compressor cooling operations help to reduce the likelihood that organic fouling will become a major concern. In the event of an infestation, commercial chemical shock treatments are available to control any outbreaks.

To ensure maximum life expectancy and best performance of the compressor cooling system, refer to *Table 4-3: WATER TESTS* on page 50.

Table 4-3: WATER TESTS

Substances	Test Interval	Acceptable Concentration
Corrosivity Hardness, pH, Total Dissolved-Solids, Temperature at inlet, Alkalinity	Monthly-if stable for 3 to 4 months, analyze quarterly.	Langerlier Index 0 to 1
Iron	Monthly	<2ppm
Sulphate	Monthly	<50 ppm
Chloride	Monthly	<50 ppm
Nitrate	Monthly	<2 ppm
Silica	Monthly	<100 ppm
Desolated Oxygen	Daily-if stable, analyze weekly	0 ppm (as low as possible)
Oil & Grease	Monthly	<5 ppm
Ammonia	Monthly	<1 ppm

SEAWATER-COOLED UNITS

NOTE

If seawater is to be used for cooling, optional copper-nickel coolers must be selected.

Water cleanliness is critical for operation of the compressor. A strainer must be installed in the inlet piping of the water system. It is also recommended that a solenoid valve (normally closed) be installed into the water outlet side of the compressor system. Consult the Sullair Service Department for assistance in setting up these recommended precautionary functions. In addition, be aware that cleaning of coolers as a result of fouling is a customer responsibility.

Isolation valves with side drains should be installed on both the inlet and outlet lines.

The recommended flow rate cannot be exceeded. An orifice plate must be installed in the pipe-work at least 3.3 ft (1 m) before the cooler. The orifice size must be calculated to ensure that the maximum seawater flow rate cannot be exceeded. Without these precautions, the seawater flow rate through the cooler may be several times the recommended maximum, which will lead to rapid system failure.

Seawater pressure psi (bar)	Orifice diameter in inch (mm) to give a maximum seawater flow or 40 US gal/min (152 l/min)
25 (1.7)	0.675 (17)
35 (2.4)	0.62 (16)

Seawater pressure psi (bar)	Orifice diameter in inch (mm) to give a maximum seawater flow or 40 US gal/min (152 l/min)
45 (3.1)	0.58 (15)
55 (3.8)	0.55 (14)
65 (4.5)	0.53 (13.5)
75 (5.2)	0.51 (13)

No oil cooler manufacturer can guarantee that its products will have an indefinite life and for this reason, we suggest that the cooling system be designed to minimize any damage caused by oil cooler leaking. This can be achieved as follows:

1. The oil pressure should be maintained at a pressure higher than the seawater pressure. In the event of a leak occurring, the oil will be prevented from becoming contaminated.
2. When the hydraulic system is not in use, the coolers should be isolated from incoming seawater under pressure.
3. The seawater outlet pipe from the cooler should have an open run to waste piping.

OUTDOOR INSTALLATION (SHELTERED)

Many times a compressor must be installed outside due to available space or other jobsite conditions. When this is necessary, there are certain items that should be incorporated into the system to help ensure trouble-free operation. The unit must be purchased with a TEFC motor. The standard machine has NEMA 4 rated controls, which are watertight.

NOTE

Variable speed drive compressors are NEMA 12 rated and must not be installed outside or exposed to the elements.

The compressor should be on a concrete pad, which is designed to drain water away from it. If the concrete pad is sloped, then the compressor must be mounted so that it is level. The base or skid must be fully supported where it contacts the concrete pad.

A weatherhood option should be selected to prevent direct rain and snow from falling on the unit. If local weather conditions can be extreme such that direct rain or snow may fall on the unit, it should be in a fully enclosed room or building.

If installed under a shelter, air-cooled machines must be positioned in a way that prevents air recirculation (i.e., hot exhaust being allowed back to the system air inlet).

In installations that include more than one compressor, hot air exhaust should not be directed toward the fresh air intake of the second unit or an air dryer.

NOTE

Compressors with integral dryers can be damaged by ambient temperatures below freezing. The dryer electrical system is Nema 12 rated and should not be installed outdoors or in an unheated space, subject to freezing temperatures.

For installation in a below freezing climate, a low ambient option with heat tracing and a separator/sump tank heater must be installed.

4.3 SERVICE AIR PIPING

Review carefully the total air system before installing a new compressor. Items to consider for the total air system include liquid carryover, pipe sizing, and the use of an auxiliary separator/sump. The installation of a drip leg or multiple drip legs, installation of a line filter(s) and the installation of isolation valve or valves. These considerations are important to ensure a safe and effective system. See *Figure 4-1*.




Figure 4-1: Service Air Piping, Typical Installation

- | | |
|------------------------|--------------------------|
| 1. Sullair Compressor | 5. Water Leg Drain Valve |
| 2. Sullair Dryer | 6. By-Pass Gate Valve |
| 3. Shut-Off Gate Valve | 7. Standard Gate Valve |
| 4. Sullair Filter | |

NOTE

Discharged air contains a very small amount of compressor lubricating oil, and care should be taken to ensure that this oil would not interfere with downstream equipment. Downstream filters and an air dryer can remove any carryover.

PIPE SIZING

Pipe should be sized at least as large as the discharge connection of the compressor. Piping and fittings should all be suitably rated for the discharge pressure.

USE OF AUXILIARY SEPARATOR/SUMP TANK

An auxiliary separator/sump tank should be used in cases where large demand swings are expected. Isolation Valve(s) If isolation of the compressor from the service lines is required, isolation valves should be installed close to the discharge of the compressor. They should be installed with drip legs that drain sloping downward from the base in order to drain properly. Install a vent to the piping downstream of the compressor outlet connection.

When two compressors are operated in parallel, provide an isolation valve and a drain trap for each compressor before the common separator/sump.

A built-in aftercooler reduces the discharge air temperature below the dew point. For most ambient conditions, considerable water vapor is condensed. To remove the condensation, each compressor with built-in aftercooler is supplied with a combination condensate separator/trap. A drain line should be installed on the condensate drain.

NOTE

For low-volume systems that do not require an auxiliary separator/sump, compressor response time may need to be adjusted. Consult the Sullair Service Department for assistance.

FLUID CONTAINMENT

Compressors are equipped with a fluid containment pan to catch any fluid in the event of a leak or spill. The drain for the pan is located on the air intake end of the machine. For indoor installations, the drain should be plugged to contain fluids. For outdoor applications, the drain must be connected to a separate, customer supplied system to allow rainwater or any accumulated compressor fluid to drain out.

**CAUTION**

The use of plastic bowls on line filters and other plastic airline components without metal guards can be hazardous. Synthetic coolants or the additives used in mineral oils can alter their structural integrity and create hazardous conditions. Metal bowls should be used on any pressurized system for safety concerns.

"The Plastic Pipe Institute recommends against the use of thermoplastic pipe to transport compressed air or other compressed gases in exposed above ground locations, e.g. in exposed plant piping." (I) Sullube should not be used with PVC piping systems. It may affect the bond at cemented joints. Certain other plastic materials may also be affected.

(I) Plastic Pipe Institute, Recommendation B, Adopted January 19, 1972.

4.4 COUPLING ALIGNMENT CHECK

No coupling alignment is required.

4.5 FLUID LEVEL CHECK

The air compressor is shipped with the proper amount of fluid installed. However, it is necessary to check the fluid level at the time of installation and during continued operation of the compressor. The fluid level is to be checked when the compressor is in the SHUT DOWN MODE (fluid level may not be visible when operating), and by looking at the sight glass on the separator/sump tank. To be able to see the fluid level it may be necessary to start the machine and build the separator/sump tank pressure up to 10/20 psi and then shut down. If no fluid level is seen in the sight glass add fluid to the center of the glass. Do not overfill in any case. When a complete fluid change is performed, fill the separator/sump tank to the maximum allowable fluid level, which is center of the sight glass.

4.6 ELECTRICAL PREPARATION

Interior electrical wiring is performed at the factory. Required customer wiring should be done by a qualified electrician in compliance with OSHA, National Electric Code and/or any applicable local electrical code concerning isolation switches, fused disconnects, etc. Sullair provides a wiring diagram for use by the installer. An electrical check should be made to help assure that the first start-up will be trouble-free. The compressor and drive should be properly grounded/earthed in accordance with Local and National Code requirements.

Installation of this compressor must be in accordance with recognized electrical codes and any local Health and Safety Codes.

Feeder cables should be sized by the customer/ electrical contractor to ensure that the circuit is


balanced and not overloaded by other electrical equipment. The length of wiring from a suitable electrical feed point is critical as voltage drops may impair the performance of the compressor. Cable sizes may vary considerably so the mains terminals will accept up to 50 mm² (1 awg) (37/4 Sk & 50/60 H) and up to 90 mm² (3/0 awg) (55/75 k & 75/100 H) cable.

Feeder cable connections to incoming terminals L1-L2-L3 should be tight and clean.

The applied voltage must be compatible with the motor and compressor data plate ratings.

A starter hole is provided for incoming power connection. If it is necessary to make a hole in the control box in a different location, care should be taken to not allow metal shavings to enter the starter and other electrical components within the box. If another hole is used, the original hole must be blocked off:

DANGER Lethal shock hazard inside. Disconnect all power at source before opening or servicing.


1. Check incoming voltage. Be sure that the incoming voltage is the same voltage that the compressor was wired for.
2. Check motor starter and overload heater sizes.
3. Check all electrical connections for tightness.
4. "DRY RUN" the electrical controls by disconnecting the three (3) motor leads from the starter. Energize the control circuits by pushing the "  " (START) pad and check all protective devices to be sure that they will de-energize the starter coil when tripped.
5. Reconnect the three (3) motor leads and jog the motor for a direction of rotation check, as explained in *Motor Rotation Direction Check* on page 54.

4.7 MOTOR ROTATION DIRECTION CHECK

Motor rotation check must be made at compressor start-up. The compressor can be damaged if it runs in the wrong direction for more than a few seconds. Motor rotation can be viewed through the opening in the drive adapter housing. After the electrical wiring has been done, it is necessary to check the direction of the motor rotation. Pull out the EMERGENCY STOP button and press once, quickly and in succession, the "I" (START) and "O" (STOP) pads. This action will bump start the motor for a very short time. When looking at the motor from the end opposite the compressor unit, the shaft should be turning clockwise. If the reversed rotation is noted, disconnect the power to the starter and exchange any two of the three power input leads, then re-check rotation. A "Direction of Rotation" decal is located on the motor drive housing to show proper motor/compressor rotation. An alternative to this procedure is to set the WS Controller to display P1 separator/

sump tank pressure. Pull out the EMERGENCY STOP button and press once, quickly and in succession, the "I" (START) and "O" (STOP) pads. This action will bump start the motor for a very short time. If motor rotation is correct there will be immediate pressure shown. If no pressure is present, reverse rotation is occurring. Disconnect the power to the starter and exchange any two of the three power input leads. Recheck rotation as outlined above.


Fan motor rotation should also be checked. It should rotate counter-clockwise when viewing the fan motor from the backside of the motor.



Section 5

WS CONTROLLER

5.1 CONTROLLER LAYOUT



- | | |
|-----------------------|--------------------------|
| 1. ON | 6. Maintenance Indicator |
| 2. OFF | 7. Fault Indicator |
| 3. LCD Display | 8. Up Key |
| 4. Power Indicator | 9. Down Key |
| 5. Run Mode Indicator | 10. Enter Key |

Figure 5-1: WS Controller

5.2 CONTROLLER KEYPAD

See WS Controller manual P/N 02250165-411 for complete operation capabilities. The WS Controller keypad has two main pads for compressor control.

- To start the compressor operation, press the green Start pad "I".
- To stop compressor operation, press the red Stop pad "⊙".
- The Run mode indicator "⊙" lights up whenever the control is in an operating mode.

5.3 LCD DISPLAY

The display's normal view shows the compressor package's discharge pressure, internal temperature, and the operating mode. The modes are MANUAL, OFF, AUTOMATIC, or FAULTED.




Figure 5-2:

Refer to *Figure 5-2* and *Figure 5-3*. The lower line is occasionally interrupted to describe the compressor package's operating state.



Figure 5-3:

Refer to *Figure 5-4*. If a machine fault occurs, the red fault "X" indicator will light up, and the display will indicate that a fault has occurred.



Figure 5-4:

Refer to *Figure 5-5*. The lower line periodically will display the cause of the fault. Refer to service instructions to correct the cause. Press the Stop pad "Ⓞ" to reset the controller.




Figure 5-5:

Refer to *Figure 5-6*. Press the Down arrow "▽" to display additional information about the compressor. The upper line will indicate "Compressor Status" and the name of the temperature, pressure, or other measurement. The lower line indicates the present reading.



Figure 5-6:

Refer to *Figure 5-7*. When you continue beyond the status information, the display will show a list of control settings. The upper line will indicate "Show Setting" and the name of the setting. The lower line shows the present value.




Figure 5-7:

Refer to *Figure 5-8*. To change the setting, press the Enter pad "↵". The display indicates that you are in a change mode with reverse characters. Use the Up "▲" or Down "▽" arrow keys to change the setting, and press Enter again to save the new setting.




Figure 5-8:

Refer to *Figure 5-8*. If there is no keypad activity, the display will return to normal view in about one minute. If the Start or Stop buttons are pressed, the display also returns to normal view. If either of these occur, the setting will not be altered.

If there are any warnings or recommended service instructions, these will be periodically displayed on the normal view.

The list of displays may be navigated from either direction by using the Up "▲" or Down "▼" arrow keys. For example, to change language from normal view, press the Up arrow pad once, press the Enter key "↵", select your language, and press Enter again. The number of displays varies with compressor model, but will follow this pattern.

The large Emergency Stop button located near the controller overrides all electronic functions to turn off the control devices. The controller senses this, and will display E-stop. To reset, twist and pull out the Emergency Stop button, then press the Stop pad to reset the WS Controller.

5.4 LED LIGHTS

The four LED lights indicate the general condition of the machine.

The green Power indicator "⚡" simply indicates that power is applied to the controller. It will blink very slowly if the WS Controller is set up to automatically restart after power failure.

The green Run mode indicator "⊙" indicates compressor operation is enabled. It lights steadily if the motor is running. If the motor stops while in Automatic mode, this LED will blink to indicate that the motor may restart.

The yellow Maintenance indicator "🔧" comes on whenever there is recommended maintenance or a warning. The text display will periodically indicate the recommended actions or the cause of the warning.

The red Fault indicator "⊗" indicates that a compressor fault has occurred and needs to be repaired before further operation. The text display will indicate the cause of the fault.

The PC support program for the WS controller provides additional information about compressor operation and advanced setup adjustments to optimize operation.

Software part numbers are shown in the display following a power interruption or other interruption of communication with the controller. The P/N remains on the display until satisfactory communications are established with the Input/Output module.

BLANK PAGE

Section 6

MAINTENANCE

6.1 GENERAL

WARNING

Before any repairs are attempted, refer to *Section 1: Safety* before proceeding.

As you proceed in reading this section, it will be easy to see that the Maintenance Program for the air compressor is quite simple. The use of the service indicators provided for the fluid filter, air filter and fluid separator will alert you when service maintenance is required. When the WS Controller display indicates service, maintenance for that specific item is required. See instructions for each item in *Filter Maintenance* on page 60.

6.2 DAILY OPERATION

Prior to starting the compressor, it is necessary to check the fluid level in the separator/sump tank . Should the level be low, simply add the necessary amount. If the addition of fluid becomes too frequent, a simple problem has developed which is causing this excessive loss. See the *Troubleshooting—Introduction* Section under EXCESSIVE COMPRESSOR FLUID CONSUMPTION for a probable cause and remedy.

WARNING



WARNING

HIGH-PRESSURE HAZARD!

- DO NOT remove caps, plugs, and/or other components when compressor is running or pressurized. Stop compressor and relieve all internal pressure before doing so.
- Failure to comply could result in death or serious injury.

After a routine start has been made, observe the controller display and be sure it monitors the correct readings for their particular phase of operation. After the compressor has warmed up, it is recommended that a general check on the overall compressor be made to assure that the compressor is running properly.

6.3 MAINTENANCE AFTER INITIAL 50 HOURS OF OPERATION


After the initial 50 hours of operation, a few maintenance requirements are needed to clean the system of any foreign materials. Perform the following maintenance operations to prevent unnecessary problems:

1. Clean the return line strainer. Refer to *Maintenance Every 2000 Hours* on page 60 for location.
2. Clean the return line orifice.

6.4 MAINTENANCE EVERY 2000 HOURS

After 2000 hours of operation, it will be necessary to perform the following:

1. Clean the return line strainer. Refer to *Discharge, Separator/sump and Piping System, 3000P, 3700 and 4500* on page 34 of the Parts Manual.
2. Replace the fluid filter element.
3. Pull oil sample for analysis
4. Check air filter. Change if necessary.



1. Filter Head
2. Element*
3. Body

Fluid Filter Assembly: P/N 02250155-708

*Fluid Filter Replacement Kit: P/N 02250155-709

Figure 6-1: Fluid Filter Assembly

6.5 FLUID MAINTENANCE

Drain the separator/sump tank and change the compressor fluid using instructions shown in *Lubrication Guide* on page 24.

6.6 FILTER MAINTENANCE

Refer to *Figure 6-1*. Replace your fluid filter element under any of the following conditions, whichever occurs first:


1. As indicated by the WS Controller.
2. Every fluid change.

FLUID FILTER ELEMENT REPLACEMENT

Refer to *Figure 6-1*.

1. Using a wrench, remove the filter canister.
2. Remove and dispose of filter element. Observe all laws and regulations for filter disposal.
3. Clean gasket seating surface.
4. Apply a light film of fluid to the element seal.
5. Install the element into the filter canister.
6. Screw the canister to the filter head. Tighten to 10 to 12 ft•lb (13.5 to 16.0 N•m).
7. Restart compressor and check for leaks.

6.7 AIR FILTER MAINTENANCE



1. Housing
2. Element*
3. Cover

Air Filter Assembly: P/N 02250127-683

* Replacement Air Filter Element Kit: P/N 02250127-684

Figure 6-2: Air Filter Assembly

Refer to *Figure 6-2*. Air filter maintenance should be performed when the maintenance gauge shows red with the compressor running full load, or once a year, whichever comes first. If the filter needs to be replaced, order a replacement element. Below you will find procedures on how to replace the air filter element.

AIR FILTER ELEMENT REPLACEMENT

1. Clean exterior of air filter housing.
2. Rotate end cover counterclockwise and remove
3. Remove air filter element by pulling it out of the housing.
4. Clean interior of housing using a damp cloth. DO NOT blow dirt out with compressed air.
5. At this time replace the element.
6. Reassemble in the reverse order of the disassembly.

6.8 SEPARATOR MAINTENANCE

Replace the separator element when indicated by the WS Controller or after one (1) year, whichever comes first. The separator element must be replaced. DO NOT attempt to clean the separator element.

SEPARATOR ELEMENT REPLACEMENT


Refer to *Figure 6-3*. The separator element must be changed when indicated by the WS Controller, or once a year, whichever occurs first. Follow the procedure explained below for separator element replacement:

NOTE

Relieve all pressure from the separator/ sump tank and all compressor lines.

1. Loosen and remove the eight (8) hex head capscrews (M12 x 40mm) from the cover plate.
2. Lift the cover plate from the separator/sump tank.
3. Remove the separator element.
4. Inspect the separator/sump tank for rust, dirt, etc.
5. Reinsert the separator element into the separator/sump tank taking care not to dent the element against the tank opening.

6. Install a new lubricated O-ring in the O-ring groove on the underside of the separator/ sump tank cover.
7. Replace the cover plate, washers and cap-screws. Torque to 89 ft-lbs. (121 N-m).
8. Clean the return line strainer before restarting the compressor.



1. Cover
2. Ground Spring*
3. Spring Fastener*
4. Cover Gasket*
5. Element*
6. Separator/Sump Tank


Separator Element: P/N 02250160-774

*Separator Element Replacement Kit: P/N 02250160-776

Figure 6-3: Separator Element Assembly

OIL RETURN/SIGHT GLASS MAINTENANCE

Refer to *Figure 6-4*. The oil return/sight glass subassembly is attached to the side of the separator tank. Oil return/sight glass maintenance should be performed on a routine basis parallel to that of the fluid filter, or as indicated in the troubleshooting section of this manual. The maintenance on an oil return/sight glass is mainly concerned with the condition of the filter assembly. Order filter assembly No. 02250117-782, and use the following instructions as a guide:



1. To Separator/Sump Tank
2. Male Tube Connector
3. 90° Pipe Elbow
4. Filter Assembly*
5. Sight Glass/Orifice Block
6. Brass Plug Orifice
7. Female Tube Connector
8. To Unit


* Oil Return Filter Replacment Kit: P/N 02250117-782

Figure 6-4: Oil Return/Sight Glass

1. Disconnect the tube at bottom of sight glass.
2. Unscrew the sight glass assembly where the elbow fitting joins the strainer/filter.
3. Remove used filter assembly, and replace with new assembly.
4. Inspect and clean the orifice inside the sight glass blocks. The orifice must be removed with an allen wrench.
5. Coat/lubricate the O-rings with silicone grease.
6. Reattach the connectors to the sight glass/orifice blocks.

PRESSURE REGULATOR ADJUSTMENT

Refer to *Figure 6-5*. Start the compressor and adjust the service valve to maintain service air pressure approximately at 1 psi over rated pressure. Turn the inlet valve regulator adjusting screw until air just begins to escape from the control air orifice, located at the bottom of the regulator. Lock the adjusting screw in place with the locknut. The regulator is now properly set.



1. Locking Nut
2. Adjustment Screw

Figure 6-5: Regulator Adjustment

Water Condensate Drain Maintenance If your compressor is fitted with the standard solenoid condensate drain valve, it is necessary to periodically clean the strainer. Remove the hex cap from the strainer and remove the strainer screen. Clean the screen and reinstall. If the screen is damaged, the strainer assembly must be replaced (P/N 241772).

CONTROL LINE STRAINER

The regulator and solenoid valve(s), which control the compressor, are protected by a strainer. Every 12 months it is necessary to clean the strainer. Remove the hex cap from the strainer and remove the strainer screen. Clean the screen and reinstall. If the screen is damaged, the strainer assembly must be replaced (P/N 241772).

SHAFT COUPLING MAINTENANCE

The compressor unit and motor are rigidly connected via a mounting adapter housing. This arrangement makes coupling alignment unnecessary. The coupling is a jaw type in shear. If the elastomeric element requires replacement due to wear or breakage, order replacement element no. 02250152-670, and follow the following steps:

1. Remove the protective grill from the adapter housing.
2. Loosen the retaining screw located on the outer sleeve. Slide the sleeve to one side, exposing the coupling element.
3. Unwrap the coupling element from the coupling jaws.
4. Install the new element by wrapping it around the jaws, engaging the cogs on the element into the jaws.
5. Reinstall the outer sleeve and the protective grill. Secure the outer sleeve by tightening the two screws to 45 in·lbs (5 N·m).

6.9 TROUBLESHOOTING— INTRODUCTION

The information contained in the Troubleshooting Guide has been compiled from field report data and factory experience. It contains symptoms and usual causes for the described problems. However, DO NOT assume that these are the only problems that may occur. All available data concerning a problem should be systematically analyzed before undertaking any repairs or component replacement procedures.

A detailed visual inspection is worth performing for almost all problems and may avoid unnecessary additional damage to the compressor. Always remember to:

1. Check for loose wiring.
2. Check for damaged piping.
3. Check for parts damaged by heat or an electrical short circuit, usually apparent by discoloration or a burnt odor.

Should your problem persist after making the recommended check, consult your nearest Sullair representative.

6.10 TROUBLESHOOTING GUIDE

SYMPTOM	PROBABLE CAUSE	REMEDY
Compressor Will Not Start	Main Disconnect Switch Open	Close switch.
	Line Fuse Blown	Replace fuse.
	Motor Starter Overload Tripped	Reset. Should trouble persist, check whether motor starter contacts are functioning properly.
	Low Incoming Line Voltage	Check voltage. Should voltage check low, consult power company.
Compressor Shuts Down With Air Demand Present	Loss of Control Voltage	Check power supply for 24V DC output. Replace power supply if necessary.
	Low Incoming Voltage	Consult power company.
	Excessive Operating Pressure	Reset. If trouble persists, check that line pressure does not exceed maximum operating pressure of the compressor (specified on nameplate).
	Separator Requires Maintenance Indicated by WS Controller	Replace separator.
	Machine Programmed for Wrong Pressure Setting	Reprogram with WSPC equipped laptop.
	Defective Regulator Valve	Regulator valve should cause inlet valve to close when the pressure switch contacts open. Repair if defective.
	Defective Blowdown Valve	Blowdown valve should exhaust separator/ sump tank pressure to 18 psig (1.2 bar) when maximum operating pressure is reached. Repair if defective.
	Cooling Water Temperature Too High	Reduce water temperature to 85F (29.4C) or less. Water-cooled only.
	Cooling Water Flow Insufficient	Check water lines and valves (water-cooled only).
	Cooler Plugged	Clean tubes. If plugging persists, install water conditioner (water-cooled only).
	Cooling Air Flow Restricted	Clean cooler and check for proper ventilation.
	Ambient Temperature Is Too High	Provide sufficient ventilation.
	Low Fluid Level	Add fluid.
	Clogged Filter	Change the fluid filter element.
	Thermal Valve Not Functioning Properly	Replace element.
Water Flow Regulating Valve Not Functioning Properly	Change (water-cooled only).	

SYMPTOM	PROBABLE CAUSE	REMEDY
Compressor Will Not Build Full Discharge Pressure	Air Demand is Too Great	Check service lines for leaks or open valves.
	Dirty Air Filter	Check the filter indicator and inspect and/or change element if required.
	Inlet Valve Bleed Orifice Plugged	Ensure control line bleed orifice located inside inlet valve is not plugged.
	Pressure Regulator Out of Adjustment	Adjust regulator according to control adjustment instructions in the Maintenance section.
	Defective Pressure Regulator	Replace regulator.
	Defective Unload Solenoid Valve	Check that the valve closes when energized. Replace the coil or the complete valve if defective.
Line Pressure Rises Above Unload Pressure Set-Point	Leak in Control System Causing Loss of Pressure Signals	Check for leaks.
	Inlet Valve Stuck Open	Remove the intake hose and check for inlet valve operation.
	Defective Unload Solenoid Valve	Check that the valve is open when de-energized. Replace if necessary.
	Plugged Control Line Strainer	Clean strainer (screen and O-ring replacement kit available).
	Defective Blowdown Valve	Check that separator/sump tank pressure is exhausted to the atmosphere when the solenoid valve opens. Repair or replace if necessary (kit available).
Excessive Compressor Fluid Consumption	Clogged Return Line or Orifice	Clean strainer (screen and O-ring replacement kit available).
		Clean orifice.
	Separator Element Damaged or Not Functioning Properly	Change separator.
	Leak in the Lubrication System	Check all pipes, connections and components.
	Excess Fluid Foaming	Drain and change.
	Fluid Level Too High	Drain and change. Check that the compressor temperature has not dropped below 170F (76.7C).
Pressure Relief Valve Opens Repeatedly	Defective Pressure Relief Valve	Replace.
	Plugged Separator	Check separator differential.

SYMPTOM	PROBABLE CAUSE	REMEDY
Liquid Water In Compressed Air Lines	Plugged Strainer in Moisture Drain Line	Clean and service strainer located in the line off the bottom of the water separator.
	Water Vapor Condensation from Cooling and Compression Occurs Naturally	Remove the water vapor from compressed air prior to distribution through the air system. Check operation of aftercooler and moisture separator. Install a compressed air dryer sized for the flow and dryness level required. (Note: Filters may also be required to remove particulates, liquid oil aerosols or for oil vapor removal. Change cartridges as recommended by the filter manufacturer). Check all drain traps routinely to insure their proper operation. Maintain them regularly.
	Defective Drain Solenoid Valve	Ensure valve opens and closes as signaled by the WS Controller.
	Inadequate Drain Timer Settings	Check WS Controller control drain interval and drain time, and adjust accordingly. High humidity conditions require longer drain times or more frequent openings.

Section 7

OPERATION

7.1 DESCRIPTION OF COMPONENTS

The variable speed drive unit is located in the machine electrical enclosure. The heat sink for the drive extends through the back of the enclosure, and is cooled by airflow through the compressor enclosure.

7.2 CONTROL SYSTEM, FUNCTIONAL DESCRIPTION

Refer to *Figure 2-5*. The purpose of the compressor control system is to regulate the amount of the air being compressed to match the amount of compressed air being used. The Capacity Control System consist of variable speed drive, solenoid valve, regulating valve, and the inlet valve. The functional description of the control system is described below in six distinct phases of operation. The following description text applies to 3000V, 3000PV, 3700V and 4500V series variable speed drive compressors with WS Controller. Depending on the model, the compressor can be operated at a setpoint pressure from 60 to 175 psig (4.1 to 12.1 bar). Refer to the nameplate for operating pressure range. The WS Controller will automatically set the frequency range based on the selected pressure. For explanatory purposes, this description will apply to a compressor with an operating pressure of 100 psig (6.9 bar), and load delta setting of 6 psi (0.4 bar). The load delta has a default setting of 10 psi (0.7 bar), but is recommended to set at 6 psi (0.4 bar) for most efficient operation. A compressor with any other pressure range would operate in the same manner except stated pressures.

START MODE- 0 TO 50 PSIG (0 TO 3.5 BAR)

When the WS Controller "Ⓛ" (START) button is depressed, the VSD ramps the motor to full speed and the separator/sump tank pressure will quickly rise from 0 to 50 psig (0-3.4 bar). During this period, both the regulator and solenoid valves are closed, the inlet valve is fully open and the air-end delivers

full capacity to the separator/sump tank. The rising compressor air pressure is isolated from the service line in this phase by the minimum pressure valve set at approximately 50 psig (3.4 bar).

FULL LOAD MODE- 50 TO 100 PSIG (3.4 TO 6.9 BAR)

When the compressed air pressure rises over 50 psig (3.4 bar) the minimum pressure valve opens allowing compressed air to flow into the service line. From this point on the line pressure is continually monitored by the WS Controller, which controls the variable speed drive. The pressure regulator and solenoid valve remain closed with the inlet valve fully open running at 100 psig (6.9 bar) or below.

VARIABLE SPEED DRIVE PART LOAD CONTROL

If less than rated capacity of compressed air is being used, the service line pressure will rise above 100 psig (6.9 bar). Consequently, the Variable Speed Drive will begin to decelerate the motor, thereby reducing the output capacity to match demand. The drive will continuously adjust the motor speed (accelerate or decelerate) to maintain a line pressure of 100 psig (6.9 bar). In this mode the VSD will operate within the appropriate frequency range determined by the WS Controller.

MODULATING MODE- 100 TO 106 PSIG (7.3 TO 6.9 BAR)

During low demand periods and with the Variable Speed Drive at minimum speed, the line pressure can continue to rise. When the line pressure reaches 101-102 psig (approximately 7 bar), the regulator valve gradually opens, directing air pressure to the inlet control valve piston. This action causes the inlet valve to partially close, thereby reducing the air entering the compressor until it matches the amount of air being used. The control system functions continually in this manner between the limits of > 101 psig (7.0 bar) to 106 psig (7.3 bar), in response to varying flow demand. The pressure regulator has an orifice which vents a small amount of air to the atmosphere when the pressure regulator controls the

inlet valve. The orifice also bleeds any accumulated moisture from the control line. When the discharge pressure rises above 106 psig (7.3 bar), or alternatively set unload pressure the compressor unloads.

NOTE

With a Sullair compressor, there is no maintenance or inspection of the internal parts of the compressor unit permitted in accordance with the terms of the warranty.

UNLOAD MODE- IN EXCESS OF 106 PSIG (7.3 BAR)

When a relatively small amount or no air is being used, the service line pressure continues to rise. When it exceeds 106 psig (7.3 bar), or alternatively

set unload pressure, the WS control system de-energizes the solenoid valve allowing separator/ sump tank air pressure to be supplied directly to close the inlet valve. Simultaneously, the solenoid valve sends a pneumatic signal to the blow down valve. The blowdown valve opens to the atmosphere, reducing the separator/sump tank pressure. The check valve in the air service line prevents line pressure from returning to the separator/sump tank . The compressor will shut down after the unload time setting expires if programmed (the default setting is zero [0] seconds for an immediate shutdown upon unload). When the line pressure drops to the low setting pressure of 100 psig (6.9 bar) The WS Controller starts the motor and energizes the solenoid valve which closes the blow down valve. The re-energized solenoid valve prevents line pressure from reaching the inlet control valve, thereby allowing it to fully open, and the compressor again delivers compressed air to the system.



WORLDWIDE SALES AND SERVICE

SULLAIR ASIA, LTD.

Sullair Road, No. 1
Chiwan, Shekuo
Shenzen, Gunagdong PRV.
PRC POST CODE 518068
Telephone: 755-6851686
Fax: 755-6853473
www.sullair-asia.com

SULLAIR CORPORATION

3700 East Michigan Boulevard
Michigan City, Indiana, 46360 U.S.A.
www.sullair.com
Telephone: 1-800-SULLAIR (U.S.A. only)
Fax: 219-874-1273

CUSTOMER CARE for PARTS and Service

1-888-SULLAIR (7855247)
219-874-1835

SULLAIR EUROPE, S.A.

Zone Des Granges BP 82
42602 Montbrison, France
Telephone: 33-477968470
Fax: 33-477968499
www.sullaireurope.com

Champion Compressors, LTD.

Princess Highway
Hallam, Victoria 3803
Australia
Telephone: 61-3-9703-8000
Fax: 61-3-9703-8053
www.championcompressors.com.au

Printed in the U.S.A.

Specifications subject to
change without prior notice.
E07EP