

Supervisor I and II Controller

In November of 1991 the Industrial Product Group began installing the Supervisor I micro-processor controller on all standard production compressors 200HP and above. In addition, the soon-to-be in production 8E and later the dry screw compressor as well as new 20 series with spiral valve will come with Supervisor II. Although very similar in operation, the Supervisors do have some different parts.

Since any compressor with either of these controllers will not operate if the controller or its related parts should fail, we strongly recommend our distributors have repair parts on hand if they have any Supervisor-controlled compressors in their territory. For troubleshooting requirements, consult the Sullair Factory Service Department 1-800-SULLAIR.

Recommended Spare Parts

SUPERVISOR I

Qty.	Part No.	Description
1	250038-779	Control, Supervisor
1	250039-909	Probe, Temperature 12 Ft.
1	02250044-985	Probe, Temperature 20 Ft.
1	250039-910	Transducer, Pressure
1	250039-911	Control, Temperature
1	250028-588	Switch, Emergency Stop
1	250027-125	Block, Contact for E. Stop
1	250041-060	Fuse External 1/2 Amp. T.D.
1	250041-061	Fuse, Secondary 2A

SUPERVISOR II

Qty.	Part No.	Description
1	250042-022	Control, Supervisor Standard
1	250042-023	Control, Supervisor Delux & Dry Screw
1	250039-909	Probe, Temperature 12 Ft.
1	02250048-457	Probe, Temperature 90 Degree Angle
1	250039-910	Transducer, Pressure
1	250028-588	Switch, Emergency Stop
1	250027-125	Block, Contact for Emergency Stop